

ALPHABETICAL INDEX

NAME AND PART DESCRIPTION	GROUP NUMBER	NAME AND PART DESCRIPTION	GROUP NUMBER
A			
Access Cover, Front Fender Splash Shield	18.010	Arm, Front Door Check	30.112
Adapter, Distributor Mounting	7.342	Arm, Front Suspension Lower	13.018
Adapter, Door Lock Cylinder	30.114	Arm, Front Suspension Upper	13.014
Adapter, Overdrive Housing	9.145	Arm, Rear Door Check	30.132
Adapter, Temperature Gauge - To Block	19.132	Arm, Steering Gear Lever - Pitman ...	14.200
Adapter, Water Temperature Gauge - Engine Unit	6.444	Arm, Steering Knuckle	13.006
Adapter Ring, Thermostat	6.410	Arm, W/S Wiper	30.360
Adjuster, Front Seat	30.554	Arm and Cap Assy, Carb. Anti- Percolator Rocker	3.640
Adjusting Cam, Front Brake	15.000	Arm and Screw Assy, Carb. Throttle Shaft	3.640
Adjusting Cam, Rear Brake	15.002	Arm Assy, Carb. Pump and Metering Rod	3.660
Adjusting Screw, Carb. Throttle Lever	3.640	Arm Rest, Door	30.614
Air Conditioner Package	40.002	Arm Rest, Front Seat Back Center	30.616
Air Duct, Air Conditioner	40.002	Arm Rest, Rear Seat Back Center	30.620
Air Horn and Climatic Control Assy, Carb.	3.660	Ash Receiver Complete	30.806
Air Horn and Climatic Control Assy, Carb.	3.640	Ash Receiver Complete, Door	30.125
Air Horn Assy, Carb.	3.640	Ash Receiver Complete, Inst. Board ..	30.406
Alarm, Fuel Tank Filler Vent	3.535	Auto Cleaner and Wax	40.134
Ammeter	19.132	Auto Polish and Cleaner	40.134
Anchor, Clutch Pedal Assist Spring ..	8.160	Axle, Rear	12.000
Antenna, Radio	40.102	B	
Anti-Rattler, Bellcrank	30.122	Back Plate, Instrument Cluster	19.132
Anti-Squeak, Deflector to Body	30.048	Back Plate, Oil and Fuel Cluster	19.122
Anti-Squeak, Front Door Hinge Arm ...	30.108	Back Plate, Speedometer	19.140
Anti-Squeak, Front Door Hinge	30.108	Back Up Light Package	40.108
Anti-Squeak, Rear Door Hinge	30.126	Baffle, Parking Light	7.561
Anti-Squeak, Front Fender	18.000	Baffle, Radiator Grille	6.491
Anti-Squeak, Front Fender Splash Shield	18.010	Baffle, Radiator Grille	6.490
Anti-Squeak, Front Stone Deflector ..	6.492	Baffle, Trans. Main Shaft Brg.	9.140
Anti-Squeak, Hood	18.100	Baffle, Valve Chamber Oil	1.750
Anti-Squeak, Hood Lock Bolt Plate ...	18.148	Baffle, Wheel Housing	30.040
Anti-Squeak, Hood Lock Latch Plate ..	18.150	Baffle Plate, Carb. Climatic Control	3.660
Anti-Squeak, Hood Lock Latch Support Plate	18.147	Bail, Fuel Pump Bowl	3.490
Anti-Squeak, Inst. Board	30.402	Bail, Hydraulic Pump Reservoir	30.906
Anti-Squeak, Lower Flange to Body Deflector	30.048	Ball, Carb. Accelerating Pump Check .	3.640
Anti-Squeak, Parking Light Baffle ...	7.561	Ball, Radiator Grille and Rear Deck Guard	40.143
Anti-Squeak, Parking Light Housing ..	7.560	Ball, Tran. Shifting Lever Poppet ...	9.190
Anti-Squeak, Radiator Grille	6.491	Ball and Rollers, Prop. Shaft Joint .	11.037
Anti-Squeak, Radiator Grille Bar	6.490	Band, Generator Cover	7.426
Anti-Squeak, Radiator Shroud	6.480	Band, Hydraulic Pump Motor Head	30.906
Anti-Squeak, Rear License Plate Bracket	20.115	Band, Starting Motor Cover	7.238
Anti-Squeak, Roof Bow and Dome Light Support	30.052	Bar, Front Bumper	20.200
Arm and Bracket, Sun Visor Panel	30.626	Bar, Front Door Vent Division	30.206
Armature, Generator	7.402	Bar, Front Sway Eliminator	13.200
Armature, Hydraulic Pump Motor	30.906	Bar, Radiator Grille	6.490
Armature, Starting Motor	7.224	Bar, Rear Bumper	20.250
Arm, Distributor Advance	7.308	Bar, Rear Door Vent Division	30.216
		Bar, Rear Window Division	30.088
		Bar, Windshield Division	30.094
		Bar, Windshield Division-Inner	30.306
		Base, Distributor	7.302
		Base, Jack	20.300

ALPHABETICAL INDEX

NAME AND PART DESCRIPTION	GROUP NUMBER	NAME AND PART DESCRIPTION	GROUP NUMBER
Base and Clamp, Cigar Lighter	7.652	Black Rubber Finish	40.134
Bearing, Accelerator Cross Shaft	3.430	Blade, Clutch Release Bearing	8.120
Bearing, Camshaft	1.510	Blade, Radiator Grille and Rear Deck Guard	40.143
Bearing, Clutch Release	8.120	Blade, W/S Wiper	30.360
Bearing, Connecting Rod	1.405	Bleeder Valve, Front Brake Cylinder .	15.016
Bearing, Crankshaft Main	1.315	Bleeder Valve, Rear Brake Cylinder ..	15.018
Bearing, Generator Commutator End Plate	7.412	Block, Crankshaft Bearing Filler, Front	1.325
Bearing, Generator Drive End Plate ..	7.428	Block, Crankshaft Bearing Filler, Rear	1.326
Bearing, Prop Shaft Center Support ..	11.006	Block, Engine	1.100
Bearing, Starting Motor Drive Housing	7.242	Block, Headlight Cable Terminal	7.550
Bearing, Steering Column Jacket	14.108	Block, Instrument Panel Wiring Junction	7.642
Bearing, Steering Drag Link End Socket	14.206	Block, Tail Light Cable Junction	7.578
Bearing, Steering Knuckle King Pin ..	13.004	Blocking Ring, Trans. Overdrive Gear Stationary	9.205
Bearing, Trans. Countershaft Gear ...	9.160	Blocking Ring, Trans. Second and High Synchronizer	9.130
Bearing, Trans. Drive Pinion	9.105	Blower Complete, Air Conditioner	40.002
Bearing, Trans. Main Shaft-Roller ...	9.120	Board, Instrument	30.402
Bearing, Trans. Main Shaft	9.140	Body, Front Wheel Brake Cylinder	15.016
Bearing, Trans. Overdrive Free Wheeling Cam	9.230	Body, Inst. Board Ash Receiver	30.406
Bearing, Trans. Overdrive Main Shaft.	9.240	Body, License Light	30.0702
Bearing and Sleeve, Clutch Release ..	8.120	Body, Oil Pump	2.205
Bearing Cone, Front Wheel	16.010	Body, Prop. Shaft Joint	11.035
Bearing Cone, Rear Axle Differential.	12.035	Body, Rear Wheel Brake Cylinder	15.018
Bearing Cone, Rear Axle Drive Pinion-Front	12.050	Body, Tail Light	7.571
Bearing Cone, Rear Axle Drive Pinion-Rear	12.060	Body, Water Pump	6.300
Bearing Cone, Rear Axle Shaft	12.080	Body and Handle, Ash Receiver	30.806
Bearing Cup, Front Wheel	16.010	Body Flange Assy, Carb.	3.660
Bearing Cup, Rear Axle Differential .	12.035	Body Flange Assy, Carb.	3.640
Bearing Cup, Rear Axle Drive Pinion- Front	12.050	Bolt, Air Cleaner	1.200
Bearing Cup, Rear Axle Drive Pinion- Rear	12.060	Bolt, Arm Rest Base	30.614
Bearing Cup, Rear Axle Shaft	12.080	Bolt, Battery Cable	7.510
Bell Crank, Accelerator-Lower	3.090	Bolt, Body Hold Down	30.012
Bell Crank, Carburetor Extension Shaft	3.450	Bolt, Camshaft Thrustplate	1.500
Bell Crank, Locking Rod	30.122	Bolt, Clutch Housing	8.130
Bell Crank, Trans. Gear Shift Rod ...	9.345	Bolt, Clutch Pressure Plate	8.104
Belt, Fan	6.000	Bolt, Clutch Pressure Plate	8.106
Bendix Drive, Starting Motor	7.244	Bolt, Connecting Rod	1.400
Bezel, Back-up Light	40.108	Bolt, Crankshaft Bearing Front Filler Block	1.325
Bezel, Clock	19.155	Bolt, Crankshaft Bearing Rear Filler Block	1.326
Bezel, Ignition Switch	7.350	Bolt, Crankshaft Main Bearing Cap ...	1.320
Bezel, Instrument Mounting	30.412	Bolt, Cylinder Block Front End Plate.	1.105
Bezel, Instrument Cluster	19.122	Bolt, Cylinder Head	1.200
Bezel, Instrument Cluster	19.132	Bolt, Distributor Advance Arm	7.308
Bezel, Instrument	30.412	Bolt, Flywheel	1.360
Bezel, Parking Light Lens	7.563	Bolt, Folding Top Frame to Power Link	30.902
Bezel, Speedometer	19.140	Bolt, Folding Top Frame to Rear Female Hinge	30.902
Bezel, Spotlight	40.104	Bolt, Front Brake Support Plate	15.000
Binding, Headlining Wire-On	30.612	Bolt, Front Bumper Bar	20.200
Binding, Rear Deck Wire-On	30.6125	Bolt, Front Bumper Guard	20.260
		Bolt, Front Fender	18.000

ALPHABETICAL INDEX

NAME AND PART DESCRIPTION	GROUP NUMBER	NAME AND PART DESCRIPTION	GROUP NUMBER
Bolt, Front Prop. Shaft	11.000	Bracket, Accelerator Bell Crank, Lower	3.090
Bolt, Front Suspension Lower Arm Inner Pivot	13.020	Bracket, Accelerator Cross Shaft	3.430
Bolt, Front Suspension Upper Arm Pivot, Inner	13.016	Bracket, Accelerator Pedal	3.070
Bolt, Fuel Tank Mounting	3.520	Bracket, Air Cleaner Support	4.060
Bolt, Hood Lock	18.148	Bracket, Back Up Light Switch	40.108
Bolt, Master Brake Cylinder	15.035	Bracket, Body Hold Down Bolt	30.012
Bolt, Radiator Mounting	6.400	Bracket, Clutch Pedal Cross Shaft ...	8.155
Bolt, Rear Axle Differential Case ...	12.015	Bracket, Clutch Pedal Return Spring .	8.140
Bolt, Rear Axle Drive Gear	12.045	Bracket, Directional Signal Light Flasher	7.635
Bolt, Rear Axle Housing Cover	12.005	Bracket, Directional Signal Light Flasher	40.142
Bolt, Rear Axle Outer Oil Seal	12.080	Bracket, Door Check Arm	30.132
Bolt, Rear Brake Support Plate	15.002	Bracket, Dust Pan	18.030
Bolt, Rear Bumper Bar	20.250	Bracket, Exhaust Muffler	5.060
Bolt, Rear Bumper Guard	20.265	Bracket, Front Door Vent	30.206
Bolt, Rear Door Vent Upper Pivot	30.216	Bracket, Front Fender Splash Shield .	18.010
Bolt, Rear Prop. Shaft	11.014	Bracket, Front License Plate	20.100
Bolt, Spare Wheel Mounting	16.030	Bracket, Generator Mounting	7.465
Bolt, Steering Column Jacket Clamp ..	14.106	Bracket, Grille Guard	20.262
Bolt, Steering Drag Link Socket Clamp	14.202	Bracket, Hood Lock Control Cable	18.158
Bolt, Steering Gear Housing End	14.104	Bracket, Horn	7.520
Bolt, Steering Gear Mounting	14.000	Bracket, Hydraulic Pump Motor Mounting	30.906
Bolt, Steering Gear Shaft Cover	14.118	Bracket, Ignition Coil Mounting	7.346
Bolt, Steering Knuckle Arm	13.006	Bracket, Ignition Switch	7.350
Bolt, Steering Tie Rod End Clamp	14.216	Bracket, Instrument Board Clock Opening Medallion	30.408
Bolt, Storage Battery	7.500	Bracket, Lid Lock Latch	30.074
Bolt, Timing Chain Cover	1.610	Bracket, Lid Support	30.074
Bolt, Trans. Drive Pinion Bearing Retainer	9.115	Bracket, Oil Filter	2.300
Bolt, Trans. Gear Shift Tube Upper Bracket	9.315	Bracket, Overdrive Kick Down Switch .	7.806
Bolt, Trans. Overdrive Housing	9.200	Bracket, Pump Mounting	30.906
Bolt, Vibration Damper	1.330	Bracket, Rear License Plate	20.115
Bolt, Wheel	16.000	Bracket, Rear Wheel Shield Lock	30.057
Bolt with L/W, Deck Lid Handle	30.068	Bracket, Seat Back Strap	30.556
Bolt with L/W, Distributor	7.300	Bracket, Spare Wheel Mounting	16.030
Bolt with L/W, Fan	6.000	Bracket, Spotlight Mounting	40.104
Bolt with L/W, Front Brake Cylinder .	15.010	Bracket, Steering Gear Support "U" Bolt	14.121
Bolt with L/W, Oil Pan	2.400	Bracket, Steering Gear Support	14.120
Bolt with L/W, Rear Brake Cylinder ..	15.012	Bracket, Tail Pipe	5.070
Boot, Accelerator Pedal	3.070	Bracket, Top Control Valve	30.908
Boot, Cylinder Support	30.904	Bracket, Trans. Gear Shift Rod Cross Shaft	9.342
Boot, Front Brake Cylinder	15.020	Bracket, Trans. Gear Shift Shaft, Lower	9.335
Boot, Master Brake Cylinder	15.035	Bracket, Trans. Gear Shift Shaft, Upper	9.315
Boot, Overdrive Governor	9.265	Bracket, Trans. Gear Shift Tube, Upper	9.315
Boot, Rear Brake Cylinder	15.030	Bracket, Trans. Gear Shift Tube, Lower	9.335
Boot And Clamps, Prop. Shaft Joint ..	11.045	Bracket, Trans. Overdrive Control ...	30.057
Bow, Headlining	30.612	Bracket, Trans. Gear Shift Support	14.120
Bowl, Fuel Pump	3.490		
Box, Instrument Board Glove	30.404		
Brace, Front Fender	18.005		
Brace, Grille Guard	20.262		
Brace, Instrument Board To Dash	30.402		
Brace, Instrument Board To Steering Column Brkt.	14.120		

ALPHABETICAL INDEX

NAME AND PART DESCRIPTION	GROUP NUMBER	NAME AND PART DESCRIPTION	GROUP NUMBER
Breather, Oil Filler Tube	2.412	Bushing, Front Suspension Lower Arm .	13.018
Brush, Hydraulic Pump Motor	30.906	Bushing, Front Suspension Upper Arm .	13.014
Brush Set, Generator	60.7	Bushing, Front Suspension Upper Arm Outer Pivot	13.010
Brush Set, Generator	7.420	Bushing, Front Suspension Lower Arm Outer Pivot	13.012
Brush Set, Starting Motor	7.236	Bushing, Headlight Beam Indicator Light Socket	7.556
Brush Set, Starting Motor	60.7	Bushing, Instrument Lights Wiring Harness	7.643
Bulb, Back-Up Light	40.108	Bushing, Oil Pump	2.200
Bulb, Clock Lighting	19.155	Bushing, Oil Pump Body	2.205
Bulb, Directional Indicator Light ...	7.637	Bushing, Prop. Shaft Center Bearing Support	11.008
Bulb, Directional Light	7.574	Bushing, Rear Shock Absorber	20.010
Bulb, Directional Signal Indicator Jewel	40.142	Bushing, Rear Spring, Front	12.200
Bulb, Dome Light	30.704	Bushing, Rear Spring Shackle	12.220
Bulb, Door Indicator Light Jewel	30.718	Bushing, Steering Gear Housing	14.102
Bulb, Glove Comp't Light	30.710	Bushing, Steering Idler Lever	14.214
Bulb, Headlight Beam Indicator Light.	7.556	Bushing, Steering Knuckle King Pin ..	13.002
Bulb, Inst. Board Courtesy Light	7.646	Bushing, Speedometer Drive Pinion ...	9.290
Bulb, Instrument Light	7.643	Bushing, Trans. Drive Pinion	9.100
Bulb, License Lamp	30.0702	Bushing, Trans. Gear Shift Rod Cross Shaft	9.342
Bulb, Parking and Directional Light .	7.563	Bushing, Trans. Reverse Idler Gear ..	9.170
Bulb, Parking Light	7.564	Button, Folding Top Quarter Panel Fastener	30.632
Bulb, Parking Light	40.142	Button, Front Door Locking Rod	30.104
Bulb, Tail and Stop Light	7.574	Button, Front Door Remote Control Rod Push	30.106
Bulb, Underhood Light	40.114	Button, Front Door Vent Handle Push .	30.206
Bulb, Utility Light	40.110	Button, Front Door Trim Panel	30.604
Bumper, Front Door	30.112	Button, Prop. Shaft Joint Centering .	11.038
Bumper, Front Door Glass, Upper	30.204	Button, Rear Door Locking Rod	30.122
Bumper, Front License Plate	20.100	Button, Rear Door Remote Control Rod Push	30.124
Bumper, Front Suspension Arm	13.022	Button, Rear Door Trim Panel	30.608
Bumper, Fuel Tank Filler Cover	30.040	Button, Rear Door Vent Handle Push ..	30.216
Bumper, Glove Box Door	30.404		
Bumper, Hood	18.100	C	
Bumper, Instrument Board Ash Receiver	30.406	"C" Washer, Trans. Overdrive Shift Fork	9.250
Bumper, License Light Brace	30.072	Cable, Air Conditioner Feed	40.002
Bumper, Rear	30.132	Cable, Battery	7.510
Bumper, Rear Door Glass, Upper	30.212	Cable, Cigar Lighter	7.657
Bumper, Rear Spring	12.230	Cable, Clock Reset	19.155
Bumper, Steering Drag Link End Socket	14.206	Cable, Courtesy Light	7.646
Bumper, Steering Gear Jacket Cover ..	14.122	Cable, Defroster Control	40.008
Bumper, Wheel Shield Moulding	30.085	Cable, Directional Signal Light	40.142
Bumper, Window Lift Frame	30.208	Cable, Dome Light Connector	30.704
Bus Bar, Window Lift Switch	30.208	Cable, Fuel Gauge-Tank Unit	7.660
Bushing, Brake and Clutch Pedal Shaft	15.104	Cable, Hand Brake Front	15.218
Bushing, Brake Pedal	15.102	Cable, Hand Brake Rear	15.236
Bushing, Clutch Pedal	8.140	Cable, Headlight	7.546
Bushing, Clutch Pedal Shaft	8.145	Cable, Horn Blowing Ring	7.536
Bushing, Connecting Rod	1.400	Cable, Ignition	7.360
Bushing, Crankshaft Pilot	1.300	Cable, License Light	30.0702
Bushing, Cylinder Mounting	30.904		
Bushing, Directional Indicator Light Cable Socket	7.637		
Bushing, Directional Signal Light Wiring Socket	40.142		
Bushing, Distributor	7.302		
Bushing, Exhaust Manifold Heat Control	5.010		

ALPHABETICAL INDEX

NAME AND PART DESCRIPTION	GROUP NUMBER	NAME AND PART DESCRIPTION	GROUP NUMBER
Cable, Lower Deck Lid	30.074	Carpet, Front Floor	30.630
Cable, Overdrive Rail Switch to Governor	7.810	Carpet, Front Seat Foot Rest	30.616
Cable, Relay to Horn	7.525	Carpet, Fuel Tank Filler Neck Cover .	30.630
Cable, Roof Sign Switch	30.702	Carpet, Rear Compartment Trim Panel .	30.611
Cable, Spark Plug	7.360	Carpet, Rear Compartment	30.630
Cable, Starting Motor Solenoid	7.265	Carpet, Rear Floor	30.630
Cable, Ventilator Control	30.034	Carpet, Tool Compartment	30.630
Cable, Water Temperature Control	40.002	Case, Rear Axle Differential	12.015
Cable, Window Lift Vacuum Pump Feed .	30.714	Case, Transmission	9.005
Cable, And Housing, Speedometer	9.282	Catch, Hood Lock Safety	18.152
Cable And Socket, Door License Light.	30.0702	Chain, Timing	1.605
Cable And Socket, License Light	30.0702	Chamber, Distributor Vacuum	7.334
Cable And Socket, Parking Light	7.568	Channel, Front Door Sash	30.202
Cable And Socket, Parking Light	40.142	Channel, Front Door Glass, Lower	30.202
Cable And Socket, Tail Light	7.576	Channel, Front Door Glass, Lower	30.202
Cable And Socket, Taxi Roof Sign	30.702	Channel, Front Door Window Felt Run .	30.202
Cable Set, Ignition	7.360	Channel, Rear Door Glass, Lower	30.210
Cable Set, Ignition	60.7	Channel, Rear Door Sash	30.210
Cage, Trans Overdrive Stationary		Channel, Rear Seat Back Board	30.560
Gear Pinion	9.220	Check Needle, Carb. Pump Discharge ..	3.660
Cam, Directional Signal Switch Cut- Off	7.630	Chrome Polish	40.134
Cam, Folding Top Locking Mechanism ..	30.902	Circuit Breaker, Hydraulic Pump	30.906
Cam, Front Door Lock Cylinder	30.114	Clamp, Air Cleaner	4.000
Cam, Trans. Overdrive Free Wheeling .	9.225	Clamp, Air Conditioner Hose	40.002
Cam And Pin Assy, Carb. Fast Idle ...	3.640	Clamp, Distributor Breaker Upper Plate	7.310
Cam And Shaft, Distributor	7.332	Clamp, Exhaust Muffler	5.055
Cam Assy, Carb, Fast Idle	3.660	Clamp, Exhaust Muffler	5.060
Camshaft	1.500	Clamp, Exhaust Pipe Hanger	5.050
Cancelling Pin, Directional Signal Light	40.142	Clamp, Fuel Tank Filler Tube	3.530
Cap And Retainer, Steering Gear Support	14.120	Clamp, Grille Guard	20.262
Cap, Crankshaft Main Bearing	1.320	Clamp, Hand Brake Front Cable	15.226
Cap, Distributor	7.302	Clamp, Hand Brake Front Cable Support	15.228
Cap, Front Wheel Grease	16.010	Clamp, Hose	40.002
Cap, Fuel Tank	3.520	Clamp, Instrument Mounting Bezel	30.412
Cap, Instrument Board Side Plate	30.412	Clamp, Muffler To Tail Pipe	5.060
Cap, Oil Filler Tube	2.412	Clamp, Parking Light Lens	7.563
Cap, Radiator Grille And Rear Deck Guard'	40.143	Clamp, Radiator Hose	6.400
Cap, Radiator Filler	6.400	Clamp, Spare Wheel Mounting	16.030
Cap, Rear Door Window Frame	30.212	Clamp, Steering Column Jacket	14.106
Cap, Rear Window Garnish Moulding ...	30.503	Clamp, Steering Drag Link Socket	14.202
Cap, Rear Window Moulding	30.088	Clamp, Steering Gear Support "U" Bolt	14.121
Cap, Steering Gear Support	14.120	Clamp, Steering Tie Rod End	14.216
Cap, Trans. Gear Shift Lever	9.300	Clamp, Tail Pipe	5.070
Cap, Trans. Gear Shift Lower Bracket	9.335	Cleaner, Air	4.000
Cap, Trans. Gear Shift Shaft Upper Bracket	9.315	Clevis, Clutch Adjusting Rod	8.165
Cap, Wheel Hub	16.026	Clevis, Clutch Pedal Shaft	8.145
Carburetor, WA1 622SB	3.640	Clevis, Trans. Gear Shift Rod	9.340
Carburetor, WCD 685SA	3.660	Clevis Pin, Clutch Pedal Cross Shaft Coupling	8.155
Carpet, Center Pillar Brace, Lower Rear	30.606	Clevis Pin, Clutch Pedal Shaft	8.140
		Clevis Pin, Lower Deck Lid Cable	30.074
		Clevis Pin, Master Cylinder Operating Rod	15.100
		Clevis Pin, Trans. Gear Shift Rod ...	9.340

ALPHABETICAL INDEX

NAME AND PART DESCRIPTION	GROUP NUMBER	NAME AND PART DESCRIPTION	GROUP NUMBER
Clevis Pin, Rear Seat Front Hinge Pivot	30.556	Clip, Radiator Grille And Rear Deck Guard	40.143
Clevis Pin, Top Operating Cylinder Yoke	30.904	Clip, Rear Axle Brake Tube	15.078
Clevis Rod, Clutch Adjusting	8.165	Clip, Rear Belt Moulding Joint	30.086
Clip, Accelerator Bell Crank Link Rod	3.410	Clip, Rear Brake Hose	15.074
Clip, Accelerator Pedal to Bell Crank Rod	3.080	Clip, Rear Brake Tube	15.070
Clip, Base Retainer License Light ...	30.0702	Clip, Rear Compartment Drain Trough .	30.040
Clip, Battery to Starting Motor Cable	7.510	Clip, Rear Door Garnish Moulding Trim Panel	30.119
Clip, Body Wiring Harness	30.702	Clip, Rear Door Glass Channel	30.210
Clip, Brake Shoe	15.004	Clip, Rear Door Window Glass Lifter .	30.218
Clip, Carb. Extension Shaft	3.450	Clip, Rear Door Window Glass Run	30.212
Clip, Center Pillar Belt Moulding ...	30.090	Clip, Rear Quarter Panel Crease Line Moulding	30.092
Clip, Chassis Wiring Harness	7.700	Clip, Rear Quarter Panel Moulding ...	30.091
Clip, Cowl Crease Line Moulding	30.092	Clip, Rear Wheel Shield Moulding	30.085
Clip, Defroster Control Cable	40.008	Clip, Rear Window Moulding Joint	30.088
Clip, Directional Signal Light Junction Block Cable	40.142	Clip, Rocker Panel Moulding	30.084
Clip, Distributor Breaker Point Set .	7.316	Clip, Speedometer Cable	9.282
Clip, Dome Light Cable	30.704	Clip, Steering Gear Jacket Cover Moulding	14.122
Clip, Door Arm Rest Moulding	30.614	Clip, Tail Light Cable	7.576
Clip, Door Belt Moulding	30.090	Clip, Trans. Overdrive Control	9.270
Clip, Door Crease Line Moulding	30.092	Clip, Trans. Overdrive Free Wheeling Cam	9.225
Clip, Door Exterior Moulding	30.091	Clip, Vacuum Pump to W/S Wiper Tube .	3.560
Clip, Door Glass Channel	30.202	Clip, Vacuum Window Lift Hose And Tube	30.914
Clip, Front Brake Hose	15.068	Clip, Vent Control Cable	30.034
Clip, Front Brake Tube	15.064	Clip, Water Control To Engine Tube ..	40.002
Clip, Front Door Garnish Moulding Trim Panel	30.101	Clip, Water Temperature Control Cable	40.002
Clip, Front Door Glass Lifter	30.208	Clip, Water Temperature Control Valve	40.002
Clip, Front Door Window Frame Arm ...	30.208	Clip, Wheel Hub Cap Spring	16.026
Clip, Front Fender Exterior Moulding.	30.091	Clip, Window Lift Hose	30.910
Clip, Front Door Window Glass Run Channel	30.204	Clip, Window Lift Vacuum Pump Feed Cable	30.714
Clip, Front Door Window Glass Run....	30.204	Clip, Window Lift Wiring Harness	30.714
Clip, Fuel Gauge Tank Unit Cable	7.660	Clip, Windshield Garnish Moulding ...	30.304
Clip, Fuel Gauge Wire	30.0702	Clip, Windshield Wiper Tube	3.560
Clip, Fuel Tank to Fuel Pump Line ..	3.550	Clip, Windshield Wiper Tube	30.364
Clip, Generator Adjusting Link	7.460	Clock Package	40.136
Clip, Glove Box Door Lock Attaching .	30.404	Clock Package	19.155
Clip, Glove Box Door Name Plate	30.404	Cluster, Ammeter And Water Temperature Gauge	19.132
Clip, Hand Brake Front Cable	15.218	Cluster, Oil Pressure And Fuel Gauge	19.122
Clip, Hand Brake Front Cable to Steering Gear	15.228	Coil, Ignition	7.346
Clip, Hand Brake Rear Cable	15.236	Collar, Trans. Overdrive Stationary Gear	9.210
Clip, Horn Relay	7.525	Column And Worm, Steering Gear	14.110
Clip, Hydraulic Tube	30.910	Commutator End Head And Holder, Hydraulic Motor	30.906
Clip, Instrument Board Radio Control Panel	30.410	Condenser, Distributor	7.318
Clip, License Light Cable	30.070	Connector, Carb. Extension Shaft	3.460
Clip, Master Brake Cylinder Tube	15.060	Connector, Directional Signal Light Flasher	7.635
Clip, Moulding To Rocker Panel	30.084		
Clip, Oil Pressure Gauge Tube	2.425		
Clip, Oil Return Tube	2.405		
Clip, Overdrive Wiring Harness	7.812		

ALPHABETICAL INDEX

NAME AND PART DESCRIPTION	GROUP NUMBER	NAME AND PART DESCRIPTION	GROUP NUMBER
Connector, Directional Signal Light Flasher	40.142	Cover, Instrument Board Ash Receiver	30.406
Connector, Distributor Vacuum Chamber Tube	7.340	Cover, Lower Deck Lid Lock	30.074
Connector, Door Hinge Tube	30.910	Cover, Master Brake Cylinder	15.035
Connector, Fuel Tank To Fuel Pump Tube	3.550	Cover, Master Brake Cylinder Access Hole	15.036
Connector, Headlight Cable	7.546	Cover, Oil Filter	2.300
Connector, Hydraulic Pump Pressure Line	30.910	Cover, Oil Pump	2.230
Connector, Oil Filter Outlet Tube	2.316	Cover, Prop. Shaft Joint Body	11.035
Connector, License Light Cable "y" ..	30.0702	Cover, Rear Axle Housing	12.005
Connector, Pump To Carb. Fuel Tube ..	3.560	Cover, Rear Door Drain Hole	30.120
Connector, Pump To W/S Wiper Hose Tube	30.364	Cover, Rear Seat Cushion	30.620
Connector, Taxi Roof Sign Switch Cable "Y"	30.702	Cover, Rear Window	30.6126
Connector, Top Operating Cylinder Tube	30.910	Cover, Rear Window Lower To Shelf Panel Trim	30.612
Connector, Vacuum Window Lift Tube ..	30.914	Cover, Roof	30.634
Connector Rod, Carb. Fast Idle	3.660	Cover, Spare Tire	30.607
Connector Rod, Carb. Throttle	3.660	Cover, Steering Drag Link Stud	14.204
Control, Heater And Defroster	40.008	Cover, Steering Gear Housing End	14.104
Control, Hood Lock	18.154	Cover, Steering Gear Jacket	14.122
Control Trans. Overdrive	9.270	Cover, Steering Gear Shaft	14.118
Control, Ventilator	30.034	Cover, Timing Chain	1.610
Control, Water Temperature Air Conditioner	40.002	Cover, Trans. Case	9.007
Control, Window Lift	30.208	Cover, Trans. Gear Shift Lower Lever ..	9.325
Control, Windshield Wiper	30.354	Cover, Valve Tappet	1.750
Cord, Robe Rail	30.628	Cover, Water Pump	6.300
Core, Air Conditioner	40.002	Cover, Windshield Pillar	30.612
Core, Speedometer Cable	9.284	Cowl	30.054
Counter Shaft, Transmission	9.165	Crankshaft	1.300
Counterweight, Heat Control Valve	5.020	Cross, Hydraulic Pump Pressure Tube ..	30.910
Coupling, Clutch Pedal Cross Shaft ..	8.155	Crossmember No. 2, Frame	17.010
Coupling, Distributor Drive Shaft	7.330	Crossmember No. 3, Frame	17.025
Cover, Air Cleaner	4.000	Cup, Front Brake Cylinder Piston	15.020
Cover, Air Duct Heater Opening	30.034	Cup, Master Brake Cylinder Piston	15.035
Cover, Carb. Bowl	3.640	Cup, Rear Brake Cylinder Piston	15.030
Cover, Carb. Dust	3.660	Cup, Steering Gear Worm Thrust Bearing	14.112
Cover, Carb. Dust	3.640	Cup, Trans. Overdrive Shift Fork	9.250
Cover, Clutch Pressure Plate	8.104	Curtain, Folding Top, Back	30.632
Cover, Clutch Pressure Plate	8.106	Cushion, Air Ride	40.137
Cover, Deck Hinge	30.6129	Cushion, Complete, Front Seat	30.616
Cover, Deck Lid Handle	30.068	Cushion Complete, Rear Seat	30.620
Cover, Deck Lid Hinge	30.064	Cushion, Front Sway Eliminator Bar ..	13.200
Cover, Distributor Breaker Plate Terminal Slot	7.310	Cushion, Shock Absorber	20.002
Cover, Door Drain Hole	30.102	Cushion, Shock Absorber	20.004
Cover, Door Hinge Tube, Vacuum Window Lift	30.910	Cylinder, Front Brake	15.010
Cover, Door Hinge Tube, Hydraulic	30.914	Cylinder, Master Brake	15.035
Cover, Folding Top Linkage Inclosure ..	30.632	Cylinder, Rear Brake	15.012
Cover, Front Seat Cushion	30.616	Cylinder, Top Operating	30.904
Cover, Fuel Gauge	3.590	Cylinder, Window Lift	30.208
Cover, Fuel Tank Filler	30.040		
Cover, Heat Control	5.015		

ALPHABETICAL INDEX

NAME AND PART DESCRIPTION	GROUP NUMBER	NAME AND PART DESCRIPTION	GROUP NUMBER
D			
Damper, Vibration	1.330	Elbow, Distributor Vacuum Chamber Tube	7.340
Deflector, Air Duct	30.034	Elbow, Fitting To Fuel Pump Tube	3.550
Deflector, Exhaust	5.070	Elbow, Hydraulic Pump Return	30.910
Deflector, Exhaust	40.126	Elbow, Oil Filter Inlet Tube	2.315
Deflector, Rear Stone	30.048	Elbow, Oil Filter Outlet Tube	2.316
Dial, Ammeter And Water Temperature..	19.132	Elbow, Oil Pressure Gauge Tube	2.425
Dial, Oil And Fuel Cluster	19.122	Elbow, Oil Pressure Gauge Tube	2.440
Dial, Speedometer	19.140	Elbow, Pump Outlet To Carb Fuel Line.	3.560
Diaphragm Kit, Fuel Pump	3.500	Elbow, Pump To Carb. Fuel Tube	3.560
Diaphragm Kit, Fuel Pump	60.3	Elbow, Water Temperature Control	40.002
Directional Signal Light Package	40.142	Elbow And Bracket, Oil Pressure Gauge Tube	2.440
Disc, Carb. Metering Rod.....	3.640	Element, Air Cleaner	4.000
Disc, Clutch	8.100	Element, Cigar Lighter	7.652
Disc, Clutch	8.102	Element, Oil Filter	2.300
Disc Check Assy, Carb Intake	3.660	Element, Oil Filter, Heavy Duty	40.145
Display (With Fuses)	40.138	Element And Cover, Air Cleaner	4.000
Distributor	7.300	End, Steering Tie Rod	14.216
Dog, Carb. Throttle Lever.....	3.660	End Tip, Folding Top Wire on Binding.	30.612
Donut Disc, Wheel Trim	16.028	Engine	1.000
Door, Front	30.102	Escutcheon, Deck Lid Handle	30.068
Door, Headlight	7.540	Escutcheon, Door Push Button	30.106
Door, Inst. Board Glove Compt	30.404	Escutcheon, Front Door Regulator Handle	30.208
Door, License Light	30.0702	Escutcheon, Front Door Lock Locking Rod	30.104
Door, Rear	30.120	Escutcheon, Folding Top Locking Mechanism Handle	30.902
Dowel, Crankshaft Main Bearing	1.320	Escutcheon, Rear Door Lock Locking Rod	30.122
Dowel, Rear Seat Back Board Stop	30.556	Escutcheon, Rear Door Regulator Handle	30.218
Dowel Pin, Crankshaft Main Bearing ..	1.320	Escutcheon, Rear Door Remote Control Push Button	30.124
Dowel Pin, Generator Commutator End Plate	7.412	Escutcheon, Robe Rail Cord	30.628
Dowel Pin, Starting Motor Commutator End Plate	7.234	Extension, Front Stone Deflector Panel	6.492
Dowel Pin, Starting Motor Drive Housing	7.242	Extension, Rear Stone Deflector	30.048
Dowel Ring, Crankshaft Main Bearing..	1.320	Extension, Seat Back Ash Receiver ...	30.806
Dowel Screw, Cylinder Block End Plate	1.110	Eyebolt And Nut, Clutch Pressure Plate Lever	8.104
Draincock, Cylinder Block	1.110	Eyebolt, Clutch Pedal Assist Spring..	8.160
Draincock, Radiator	6.400	Eyelet, Folding Top Back Curtain	30.632
Drive Body, Windshield Wiper.....	30.358	F	
Driver, Windshield Wiper Motor.....	30.352	Fabric Cleaner	40.134
Drive Screw, Front Seat Foot Rest Side Carpet	30.616	Facing, Rear Door Lock Pillar	30.038
Drive Screw, Steering Gear Jacket Cover Retainer	14.122	Facing Set, Clutch Disc.	8.100
Drum, Front Wheel Brake	16.006	Facing Set, Clutch Disc.	8.102
Drum, Rear Wheel Brake	16.022	Fan	6.000
Dust Cap, Speedometer and Taximeter Drive Pinion Sleeve	9.290	Fan, Air Conditioner Blower	40.002
Dust Cover, Steering Tie Rod	14.216	Fastener, Dash Insulating Pad	30.630
Dust Seal, Brake Pedal	15.102	Fastener, Front Door Glass Weather- strip	30.204
Dust Seal, Clutch Pedal	8.140	Fastener, Front Door Trim	30.604
Dust Seal, Clutch Pedal Cross Shaft .	8.155	E	
E			
Elbow, Center Pillar Hydraulic Tube .	30.910		
Elbow, Cylinder Head Water Outlet ...	6.425		

ALPHABETICAL INDEX

NAME AND PART DESCRIPTION	GROUP NUMBER	NAME AND PART DESCRIPTION	GROUP NUMBER
Fastener, Front Seat Frame Back Trim Panel	30.616	Flatwasher, Trans. Gear Shift Shaft..	9.310
Fastener, Rear Belt Moulding	30.086	Flatwasher, Trans. Overdrive Control Shaft Lever	9.260
Fastener, Rear Compartment Windbreak.	30.611	Flatwasher, Trans. Shifting Lever, Outer	9.195
Fastener, Rear Door Glass Weatherstrip	30.212	Flatwasher, Vacuum Antenna Valve	40.102
Fastener, Rear Door Trim Panel	30.608	Float And Lever Assy, Carb.	3.640
Fastener, Rear Luggage Shelf Trim Panel	30.624	Float And Lever Assy, Carb.	3.660
Fastener, Rear Quarter Panel Moulding	30.091	"Floato", Oil Pump	2.235
Fastener, Rocker Panel Moulding	30.084	Flywheel	1.360
Felt, Distributor Cam	7.332	Fog Light Package	40.112
Fender, Front	18.000	Fork, Clutch Release	8.125
Filler, Fuel Gauge Cover	3.590	Fork, Trans. Overdrive Shift	9.250
Filler, Upper Deck Hinge Cover	30.6129	Fork, Trans. Shifting	9.185
Filter, Oil	2.300	Frame	17.000
Filter Package, Oil	40.145	Frame And Glass, Front Door Vent	30.206
Fitting, Fuel Tank To Fuel Pump Tube.	3.550	Frame And Glass, Rear Door Vent	30.216
Fitting, Master Brake Cylinder Outlet	15.035	Frame Complete, Folding Top	30.902
Flange, Front Prop. Shaft Companion..	11.004	Frame, Door Window	30.201
Flange, Prop. Shaft Center Companion.	11.012	Frame, Front Seat	30.552
Flange, Rear Prop. Shaft Companion ..	11.020	Frame, License Plate	40.128
Flasher, Directional Signal Light ...	7.635	Frame, Rear Door Glass	30.212
Flasher, Directional Signal Light ...	40.142	Frame, Rear Seat Back, Tubular	30.560
Flatwasher, Air Cleaner	1.200	Frame, Rear Window	30.503
Flatwasher, Center Companion Flange..	11.012	Frame, Window Lift	30.208
Flatwasher, Clutch Pedal Assist Spring Link	8.160	Funnel, Air Duct Inlet	30.034
Flatwasher, Clutch Pressure Plate ...	8.106	Fuse, Cigar Lighter	7.657
Flatwasher, Crankshaft Main Bearing..	1.320	Fuse, Fog Light	40.112
Flatwasher, Crankshaft Pulley	1.350	Fuse, Heater Switch Feed	40.002
Flatwasher, Cylinder Head	1.200	Fuse, Overdrive Solenoid Relay	7.804
Flatwasher, Distributor Advance Arm..	7.308	Fuse, Window Lift Wiring Harness	30.714
Flatwasher, Distributor Breaker Point Set Clip	7.316	G	
Flatwasher, Exhaust Manifold	5.000	Gasket, Air Cleaner	4.000
Flatwasher, Front Bumper Bar	20.200	Gasket, Back-Up Light Lens	40.108
Flatwasher, Front Bumper Guard	20.260	Gasket, Brake Pedal Floor Plate	15.112
Flatwasher, Front Door Glass Lifter..	30.208	Gasket, Carb. Air Horn	3.660
Flatwasher, Front Door Vent	30.206	Gasket, Carb. Body Flange	3.660
Flatwasher, Front Wheel Hub And Drum.	16.002	Gasket, Carb. Bowl Cover	3.640
Flatwasher, Fuel Gauge Tank Unit	3.580	Gasket, Carb. Bowl Cover	3.660
Flatwasher, Intake Manifold	3.000	Gasket, Carb. Bowl Strainer Plug	3.640
Flatwasher, Linkage Enclosure Panel..	30.904	Gasket, Carb. Bowl Strainer Plug	3.660
Flatwasher, No. 1 Auxiliary Body Hold Down Bolt	30.012	Gasket, Carb. Climatic Control Housing	3.660
Flatwasher, Prop. Shaft Center Bearing Support.....	11.008	Gasket, Carb. Float Needle Seat	3.640
Flatwasher, Prop. Shaft Companion Flange	11.004	Gasket, Carb. Main Body	3.640
Flatwasher, Rear Axle Shaft	12.080	Gasket, Carb. Main Discharge Nozzle..	3.640
Flatwasher, Rear Bumper Bar	20.250	Gasket, Carb. Metering Rod Jet	3.640
Flatwasher, Rear Bumper Guard	20.265	Gasket, Carb. Metering Rod Jet	3.660
Flatwasher, Rear Door Glass Lifter... 30.218		Gasket, Carb. Needle Seat	3.660
Flatwasher, Rear Prop. Shaft Companion Flange	11.020	Gasket, Carb. Pump Discharge Passage Plug	3.660
Flatwasher, Rear Wheel Hub And Drum..	16.020	Gasket, Carb. Throttle Body To Main Body	3.640
Flatwasher, Shock Absorber Bushing...	20.010	Gasket, Carb. to Manifold	3.640
Flatwasher, Steering Gear Mounting...	14.000	Gasket, Carb. To Manifold	3.660
Flatwasher, Trans. Gear Shift Lever..	9.305	Gasket, Clock Lens	19.155

ALPHABETICAL INDEX

NAME AND PART DESCRIPTION	GROUP NUMBER	NAME AND PART DESCRIPTION	GROUP NUMBER
Gasket, Clutch Pedal Floor Plate	8.170	Gasket, Steering Gear Shaft Cover ...	14.118
Gasket, Cylinder Block Front End Plate	1.105	Gasket, Tail Light Lens	7.572
Gasket, Cylinder Head	1.200	Gasket, Timing Chain Cover	1.610
Gasket, Deck Lid Handle Escutcheon...	30.068	Gasket, Trans. Case Cover	9.007
Gasket, Deck Lid Hinge	30.064	Gasket, Trans. Drive Pinion Bearing Retainer	9.117
Gasket, Distributor Vacuum Chamber Plug	7.338	Gasket, Trans. Main Shaft Bearing Retainer	9.145
Gasket, Exhaust Manifold	5.000	Gasket, Trans. Overdrive Housing	9.200
Gasket, Exhaust Pipe	5.040	Gasket, Valve Tappet Cover	1.750
Gasket, Female Hinge	30.064	Gasket, Water Outlet Elbow	6.425
Gasket, Front Door Handle Escutcheon.	30.114	Gasket, Water Pump	6.300
Gasket, Front Brake Hose	15.068	Gasket Assortment, Carb.....	3.640
Gasket, Fuel Gauge Cover	3.590	Gasket Assortment, Carb.....	3.660
Gasket, Fuel Gauge Tank Unit	3.580	Gasket Assortment, Carb.....	60.3
Gasket, Fuel Pump	3.470	Gasket Set, Engine Overhaul	1.000
Gasket, Fuel Pump Bowl	3.490	Gasket Set, Engine Overhaul	60.1
Gasket, Generator Commutator End Plate Bearing	7.412	Gasket Set, Engine Valve Grind	1.720
Gasket, Generator Drive End Plate Bearing Retainer	7.428	Gasket Set, Engine Valve Grind	60.1
Gasket, Headlight	7.540	Gasket Set, Manifold	5.000
Gasket, Hydraulic Pump Reservoir	30.906	Gasket Set, Manifold	60.5
Gasket, Instrument Bezel	19.122	Gasket Set, Oil Pan	2.400
Gasket, Instrument Bezel	19.132	Gasket Set, Oil Pan	60.2
Gasket, Instrument Lens	19.122	Gasket Set, Transmission	9.003
Gasket, Instrument Lens	19.132	Gasket Set, Transmission	60.9
Gasket, Instrument Lens Spacer.....	19.122	Gauge, Fuel	19.122
Gasket, Instrument Lens Spacer.....	19.132	Gauge, Fuel, Tank Unit	3.580
Gasket, Intake Manifold	3.000	Gauge, Oil Depth	2.415
Gasket, License Light Lens	30.0702	Gauge, Oil Pressure	19.122
Gasket, Master Brake Cylinder	15.035	Gauge, Oil Pressure, Engine Unit	2.430
Gasket, Master Brake Cylinder Access Hole Cover	15.036	Gauge, Water Temperature.....	19.132
Gasket, Master Brake Cylinder Outlet Fitting	15.035	Gauge, Water Temperature, Engine Unit.	6.444
Gasket, Oil Filter Cover	2.300	Gear, Oil Pump Drive.....	2.210
Gasket, Oil Pan	2.400	Gear, Oil Pump Idler.....	2.215
Gasket, Oil Pressure Relief Valve Plug	2.410	Gear, Speedometer and Taximeter Drive	9.290
Gasket, Oil Pump Cover	2.230	Gear, Speedometer Drive	9.286
Gasket, Overdrive Housing To Adapter.	9.145	Gear, Steering	14.000
Gasket, Overdrive Rail Switch	7.802	Gear, Timing	1.600
Gasket, Parking Light Lens	7.563	Gear, Trans. Overdrive Governor	9.265
Gasket, Prop. Shaft Joint Body	11.035	Gear, Trans. Overdrive Stationary ...	9.210
Gasket, Rear Axle Drive Pinion Rear Bearing	12.060	Gear, Trans. Reverse Idler	9.170
Gasket, Rear Axle Housing Cover	12.005	Gear, Trans. Sliding	9.135
Gasket, Rear Axle Shaft Bearing Retainer	12.080	Gear And Blocking Ring, Trans. Overdrive Stationary	9.205
Gasket, Rear Axle Shaft Outer Oil Seal	12.080	Gear And Pinion, Rear Axle Drive	12.045
Gasket, Rear Brake Hose	15.074	Gear And Pinion Kit, Rear Axle Differential	12.020
Gasket, Rear Door Handle Escutcheon..	30.134	Gear And Pinion Kit, Rear Axle Differential.....	60.12
Gasket, Spark Plug	7.375	Gear Cluster, Trans. Countershaft ...	9.155
Gasket, Speedometer Bezel	19.140	General Use Oil	40.134
Gasket, Speedometer Cable	9.282	Generator	7.400
		Glass, Center Pillar	30.201
		Glass, Door	30.201
		Glass, Rear Window	30.501
		Glass, Windshield	30.301
		Glass Cleaner.....	40.134
		Governor, Trans. Overdrive	9.265

ALPHABETICAL INDEX

NAME AND PART DESCRIPTION	GROUP NUMBER	NAME AND PART DESCRIPTION	GROUP NUMBER
Governor Weight, Distributor Drive		Handle, Rear Door Regulator	30.218
Shaft	7.324	Handle, Rear Door Vent	30.216
Grille, Instrument Board Radio	30.410	Handle, Top Locking Mechanism	30.902
Grille, Radiator	6.491	Hanger, Exhaust Pipe	5.050
Grommet, Air Conditioner Blower		Hanger, Rear Spring Front	12.200
Cable	40.002	Hardware Package, Windshield Visor ..	40.115
Grommet, Chassis Wiring Harness	7.700	Harness, Body Wiring	30.702
Grommet, Defroster Control Cable	40.008	Harness, Chassis Wiring	7.700
Grommet, Directional Signal Light		Harness, Clock Wiring	19.155
Cable	40.142	Harness, Courtesy Light Wiring	7.648
Grommet, Hand Brake Front Cable	15.218	Harness, Generator To Voltage	
Grommet, Headlight Cable	7.546	Regulator	7.470
Grommet, Headlight Dimmer Switch	7.554	Harness, Headlight Cable Terminal	
Grommet, Headlining Bow	30.612	Block	7.552
Grommet, Hood Lock Control	18.154	Harness, Instrument Lights Wiring ...	7.643
Grommet, Horn Relay	7.525	Harness, Overdrive Wiring	7.812
Grommet, Hose	30.914	Harness, Top Lift Wiring	30.714
Grommet, Hydraulic Pump Hose	30.908	Harness, Window Lift Wiring	30.714
Grommet, Instrument Tubes To Dash ...	19.150	Head, Cylinder	1.200
Grommet, License Light Feed Cable ...	30.0702	Headlight	7.540
Grommet, Overdrive Control	9.270	Headlining	30.612
Grommet, Spare Tire Cover Clamp Bolt.	30.607	Hinge, Deck Lid	30.064
Grommet, Vacuum Antenna	40.102	Hinge, Folding Top	30.902
Grommet, Vent Control Cable	30.034	Hinge, Front Door	30.108
Grommet, Windshield Wiper Control ...	30.354	Hinge, Front Door Vent	30.206
Guard, Crankshaft Bearing Filler		Hinge, Glove Box Door Inner	30.404
Block, Rear	1.326	Hinge, Hood	18.200
Guard, Front Bumper	20.260	Hinge, Rear Door	30.126
Guard, Grille	20.262	Holder, Overdrive Solenoid Relay	
Guard, Radiator Grille	40.143	Fuse	7.804
Guard, Rear Bumper	20.265	Hood	18.100
Guard, Rear Deck	40.143	Horn	7.520
Guard, Rear Door Finger	30.609	Hose, Air Conditioner	40.002
Guide, Carb. Pump Plunger	3.660	Hose, Center Pillar Window Lift	30.914
Guide, Trans. Gear Shift Lever	9.305	Hose, Center Pillar Window Lift	30.910
Guide, Trans. Gear Shift Shaft	9.310	Hose, Defroster	40.008
Guide, Trans. Overdrive Shift Fork ..	9.250	Hose, Door Tube To Window Lift	30.914
Guide, Valve	1.720	Hose, Engine To Temperature Water	
		Control	40.002
H		Hose, Front Brake	15.068
Handle, Ash Receiver	30.806	Hose, Front Pillar Window Lift	30.910
Handle, Deck Lid	30.068	Hose, Front Pillar Window Lift	30.914
Handle, Front Door Push Button		Hose, Fuel Tank Filler Tube	3.530
Escutcheon	30.106	Hose, Hydraulic Pump To Control	
Handle, Front Door Vent	30.206	Valve	30.910
Handle, Front Door	30.114	Hose, Hydraulic Pump To Dash	
Handle, Front Door Regulator	30.208	Connection	30.910
Handle, Front Seat Back Assist	30.810	Hose, Radiator	6.420
Handle, Instrument Board Ash Receiver	30.406	Hose, Rear Brake Tube To Axle Tee ...	15.074
Handle, Rear Door	30.134	Hose, Temperature Control To Air	
Handle, Rear Door Push Button		Conditioner	40.002
Escutcheon	30.124	Hose, Window Lift Vacuum Pump	30.914
Handle, Rear Door Regulator	30.218	Housing, Clutch	8.130
		Housing, Dome Light	30.704
		Housing, Hydraulic Pump	30.906
		Housing, Parking Light	7.560
		Housing, Rear Axle	12.005

ALPHABETICAL INDEX

NAME AND PART DESCRIPTION	GROUP NUMBER	NAME AND PART DESCRIPTION	GROUP NUMBER
Housing, Starting Motor Drive	7.242	Jet, Carb. Pump	3.640
Housing, Steering Gear	14.102	Jet, Windshield Washer	40.116
Housing, Tail Light Body	7.571	Jet And Gasket Assy, Carb. Metering Rod	3.640
Housing, Trans. Overdrive	9.200	Jet And Gasket Assy, Carb. Metering Rod	3.660
Housing And Coil Assy., Carb. Climatic Control	3.660	Jet And Housing Assy, Carb. Pump	3.660
Housing And Coil Assy., Carb. Climatic Control	3.640	Jet Assy, Carb Low Speed	3.640
Housing And Socket, Courtesy Light ..	7.646	Jet Assy, Carb Low Speed	3.660
Hub, Crankshaft Pulley	1.350	Jewel, Directional Signal Indicator .	40.142
Hub, Directional Signal Light Switch Lever	7.626	Jewel, Door Light Indicator	30.718
Hub, Fan Pulley	6.000	Joint, Rear Belt Moulding	30.086
Hub, Trans. Second And High Synchronizer	9.125	Junction Block, Directional Signal Light	40.142
Hub And Drum, Front Wheel	16.002		
Hub And Drum, Rear Wheel	16.020	K	
Hydraulic Brake Fluid	15.040		
I		Key, Deck Lid Lock Cylinder	30.068
Impeller, Water Pump	6.300	Key, Door Lock	30.114
Insert, Radiator Grille And Rear Deck Guard	40.143	Key, Gas Tank Locking Cap	40.124
Insulation, Roof Rail	30.630	Key, Glove Box Lock	30.404
Insulator, Engine Support, Front	1.010	Key, Crankshaft Pulley	1.350
Insulator, Engine Support, Rear	1.020	Key, Deck Lid Lock Cylinder	30.068
Insulator, Front Bumper Support	20.208	Key, Door Lock	30.114
Insulator, Front Suspension Spring ..	13.024	Key, Gas Tank Locking Cap	40.124
Insulator, Fuel Tank Filler Tube	3.530	Key, Glove Box Lock	30.404
Insulator, Horn Blowing Ring Contact Plate	7.534	Key, Front Door Vent Handle	30.206
Insulator, Muffler	5.060	Key, Generator Drive Pulley	7.434
Insulator, Prop. Shaft Center Bearing Support	11.008	Key, Heat Control Valve Counterweight	5.020
Insulator, Prop. Shaft Center Support Bearing	11.006	Key, Ignition Switch Lock	7.352
Insulator, Rear Spring Mounting Plate	12.215	Key, Oil Pump Drive Gear	2.210
Insulator, Seat Back Ash Receiver ...	30.806	Key, Rear Axle Shaft	12.080
Insulator, Spark Plug	40.144	Key, Rear Door Vent Handle	30.216
Insulator, Steering Gear Support Bracket	14.120	Key, Rear Wheel Hub And Drum	16.020
Insulator, Tail Pipe Bracket	5.070	Key, Robe Rail Cord	30.628
Insulator, Trans. Gear Shift Lever ..	9.320	Key, Starting Motor Bendix Drive	7.244
Insulator, Trans. Gear Shift Rod	9.340	Key, Timing Gear	1.600
Insulator, Trans. Gear Shift Rod Cross Shaft	9.342	King Pin, Steering Knuckle	13.002
Insulator, Trans. Shifting Lever	9.195	Knob, Air Conditioner Switch	40.002
Insulator, Windshield Wiper Motor Driver Coupling	30.352	Knob, Front Seat Adjuster Operating Handle	30.554
J		Knob, Headlight Switch	7.553
Jack	20.300	Knob, Heater Lever Control	40.008
Jacket, Steering Column	14.106	Knob, Instrument Board Courtesy Light Switch	7.644
		Knob, Instrument Panel Switch	7.640
		Knob, Top Control Rod	30.908
		Knob, Trans. Gear Shift Lever	9.300
		Knob, Vacuum Antenna Valve	40.102
		Knob, Ventilator Control	30.034
		Knob, Water Temperature Control	40.002
		Knob, Windshield Wiper Control	30.354
		Knob And Element, Cigar Lighter.....	7.652
		Knuckle, Steering.....	13.000

ALPHABETICAL INDEX

NAME AND PART DESCRIPTION	GROUP NUMBER	NAME AND PART DESCRIPTION	GROUP NUMBER
L			
Latch, Deck Lid	30.074	License Light	30.0702
Latch, Glove Box Door	30.404	Lid, Rear Deck	30.062
Latch, Lower Deck Lid	30.074	Lift, Front Window	30.208
Latch, Upper Lid Support	30.074	Lift, Rear Window	30.218
Lead, Distributor Breaker Plate	7.310	Lifter, Front Door Glass	30.208
Lens, Back-Up Light	40.108	Lifter, Rear Door Glass	30.218
Lens, Clock	19.155	Light, Courtesy	7.646
Lens, Courtesy Light	7.646	Light, Dome	30.704
Lens, Instrument Cluster	19.122	Light, Utility	40.110
Lens, Instrument Cluster	19.132	Light, Parking	7.560
Lens, License Light	30.0702	Light, Tail, Stop And Directional ...	7.570
Lens, Parking Light	7.563	Light, Underhood	40.114
Lens, Speedometer	19.140	Lighter, Cigar	7.652
Lens, Tail Light	7.572	Lining Set, Brake	15.006
Lens, Tail Light Reflex	7.572	Lining Set, Brake	60.15
Lens And Bezel, Ammeter And Temperature Gauge	19.132	Link, Carburetor Pump	3.640
Lens And Bezel, Courtesy Light	7.646	Link, Carburetor Pump	3.660
Lens And Bezel, Dome Light	30.704	Link, Carburetor Vacuum Piston	3.660
Lens And Bezel, Oil Pressure And Fuel Gauge	19.122	Link, Clutch Pedal Assist Spring ...	8.160
Lever, Accelerator Bell Crank Link Rod	3.410	Link, Clutch Pedal Shaft Adjusting ..	8.145
Lever, Accelerator Cross Shaft	3.430	Link, Cross Shaft Adjusting	8.150
Lever, Carburetor Extension Shaft ...	3.440	Link, Generator Adjusting	7.460
Lever, Clutch Pressure Plate	8.104	Link, Hand Brake Operating Lever ...	15.008
Lever, Clutch Pressure Plate	8.106	Link, Steering Drag	14.202
Lever, Directional Signal Light Switch	40.142	Link And Spring, Carb. Pump Operating	3.640
Lever, Directional Signal Light Switch	7.626	Linkage, Front Seat Back Center Arm Rest	30.616
Lever, Hand Brake	15.200	Linkage, Rear Seat Back Center Arm Rest	30.620
Lever, Hand Brake Operating	15.008	Listing Wire, Folding Top Well	30.632
Lever, Steering Idler	14.212	Lock, Front Door	30.104
Lever, Trans. Gear Shift Lower, Low And Reverse	9.320	Lock, Glove Box Door	30.404
Lever, Trans. Gear Shift Lower, Second And High	9.325	Lock, Rear Door	30.120
Lever, Trans. Gear Shift, Lower	9.320	Lock, Steering Idler Lever Bushing ..	14.214
Lever, Trans. Gear Shift Rod Cross Shaft	9.342	Lock, Timing Gear Key	1.600
Lever, Trans. Gear Shift Upper	9.300	Lock, Upper Deck Lid	30.074
Lever, Trans. Overdrive Control Shaft	9.260	Lock, Valve Spring Retainer	1.720
Lever, Trans. Shifting Outer	9.195	Lock And Key Package, Gas Tank Locking Cap	40.124
Lever And Countershaft, Carb. Pump Operating	3.640	Lock Cylinder and Keys, Deck Lid	30.068
Lever And Countershaft, Carb. Pump Operating	3.660	Lock Cylinder and Keys, Door	30.114
Lever And Screw Assembly, Carb. Choke	3.660	Lock Cylinder and Keys, Ignition Switch	7.352
Lever And Shaft, Trans. Shifting	9.180	Lock Cylinder and Key Kit, Deck Lid and Glove Box	30.068
Lever, Link And Screw Assembly, Carb. Choke	3.640	Lock Cylinder and Key Kit, Door and Ignition Switch	30.114
Lever, Link And Shaft Assembly, Carb. Choke Piston	3.660	Lock Cylinder and Key Kit, Glove Box and Deck Lid	30.404
		Lock Cylinder and Key Kit, Ignition Switch and Door	7.352
		Locknut, Clutch Pressure Plate	8.106
		Locknut, Connecting Rod Bolt	1.400
		Locknut, Engine Support Rear Insulator	1.020
		Locknut, Front Shock Absorber	20.000

ALPHABETICAL INDEX

NAME AND PART DESCRIPTION	GROUP NUMBER	NAME AND PART DESCRIPTION	GROUP NUMBER
Locknut, Front Suspension Lower Arm, Inner Pivot	13.020	Lockwasher, Instrument Board Switch .	7.640
Locknut, Fuel Tank Mounting	3.520	Lockwasher, Overdrive Kickdown Switch	7.806
Locknut, Prop. Shaft Center Bearing Support	11.008	Lockwasher, Roof Sign Switch Screw ..	30.702
Locknut, Rear Spring Shackle	12.220	Lockwasher, Starting Motor Commutator End Plate	7.234
Locknut, Steering Gear Mounting	14.000	Lockwasher, Starting Motor Field Coil Terminal Stud	7.228
Locknut, Steering Gear Shaft And Roller	14.116	Lockwasher, Starting Motor Solenoid . Relay Terminal	7.265
Locknut, Valve Tappet Screw	1.740	Lockwasher, Starting Motor Solenoid Switch Terminal	7.265
Lockpin, Rear Axle Differential Gear Shaft	12.020	Lockwasher, Starting Motor Terminal Nut	7.222
Lockpin, Steering Idler Lever	14.212	Lockwasher, Starting Switch Terminal.	7.270
Lockpin, Steering Knuckle King Pin ..	13.002	Lockwasher, Steering Gear Lever Arm .	14.126
Lockplate, Rear Axle Drive Bolt	12.045	Lubriplate	40.134
Lockplate, Steering Gear Shaft And Roller	14.116	Luster Seal	40.134
Lockplate, Trans. Reverse Idler Gear Shaft	9.175	Luster Seal Applicator	40.134
Lockring, Brake Pedal	15.102	Luster Seal Buffer Pad Backing Plate.	40.134
Lockring, Clutch Pedal Thrustwasher .	8.140	Luster Seal Haze Cream	40.134
Lockring, Horn Medallion Retainer Plate	7.531	M	
Lockring, Starting Motor Spring Anchor Plate	7.244	Manifold, Exhaust	5.000
Lockwasher, Air Conditioner Switch ..	40.002	Manifold, Intake	3.000
Lockwasher, Distributor Advance Arm .	7.308	Mat, Front Floor	30.630
Lockwasher, Distributor Breaker Plate	7.310	Mat, Rear Compartment Floor	30.630
Lockwasher, Distributor Breaker Plate Lead	7.310	Mat, Rear Floor	30.630
Lockwasher, Distributor Breaker Point Set	7.316	Mat, Rear Floor Riser	30.630
Lockwasher, Distributor Condenser ...	7.318	Medallion, Hood	18.130
Lockwasher, Distributor Terminal	7.300	Medallion, Horn	7.531
Lockwasher, Distributor Vacuum Chamber	7.334	Medallion, Instrument Board Clock Opening	30.408
Lockwasher, Door Indicator Light Jewel	30.718	Metering Rod, Carburetor	3.660
Lockwasher, Door Lock Striker Plate..	30.104	Metering Rod, Carburetor	3.640
Lockwasher, Door Lock Striker Plate .	30.122	Metering Rod Kit, Carburetor	3.640
Lockwasher, Front Suspension Lower Arm Outer Pivot	13.012	Mirror, Outside Rear View	40.118
Lockwasher, Generator Armature Field. Terminal	7.402	Mirror, Rear View	30.802
Lockwasher, Generator Armature Terminal Nut	7.402	Mirror, Vanity	40.120
Lockwasher, Generator Brush	7.420	Motor, Air Conditioner Blower	40.002
Lockwasher, Generator Commutator End Plate	7.412	Motor, Windshield Wiper	30.352
Lockwasher, Generator Drive End Plate Seal Retainer	7.428	Motor And Drive, Windshield Wiper ...	30.352
Lockwasher, Generator Drive Pulley ..	7.434	Motor And Pump,Hydraulic	30.906
Lockwasher, Generator Ground Terminal	7.400	Motor And Pump, Vacuum	30.912
Lockwasher, Headlight Dimmer Switch .	7.554	Motor And Solenoid, Hydraulic Pump ..	30.906
Lockwasher, Horn Relay Terminal	7.525	Moulding, Center Pillar Belt	30.090
Lockwasher, Instrument Board Courtesy Light Switch	7.644	Moulding, Center Pillar Crease Line .	30.092
		Moulding, Center Pillar Exterior	30.091
		Moulding, Cowl Crease Line	30.092
		Moulding, Door Arm Rest	30.614
		Moulding, Front Door Belt	30.090
		Moulding, Front Door Crease Line	30.092
		Moulding, Front Door Exterior	30.091
		Moulding, Front Door Garnish	30.101
		Moulding, Front Door Garnish Trim Panel	30.101
		Moulding, Front Door Trim Panel	30.604
		Moulding, Front Fender Exterior	30.091
		Moulding, Hood	18.130

ALPHABETICAL INDEX

NAME AND PART DESCRIPTION	GROUP NUMBER	NAME AND PART DESCRIPTION	GROUP NUMBER
Moulding, Instrument Board	30.412	Nut, Folding Top Frame To Power Link Bolt.....	30.902
Moulding, Rear Belt	30.086	Nut, Front Brake Support Plate	15.000
Moulding, Rear Door Belt	30.090	Nut, Front Brake Tube	15.064
Moulding, Rear Door Crease Line	30.092	Nut, Front Door Vent. Lower Pivot ...	30.206
Moulding, Rear Door Exterior	30.091	Nut, Front Prop. Shaft	11.000
Moulding, Rear Door Garnish	30.119	Nut, Front Seat Adjuster Connecting Rod	30.554
Moulding, Rear Door Trim Panel	30.608	Nut, Front Suspension Lower Arm Outer Pivot	13.012
Moulding, Rear Quarter Panel Crease Line	30.092	Nut, Fuel Tank Filler Cover Bolt	30.040
Moulding, Rear Quarter Panel	30.091	Nut, Fuel Tank To Fuel Pump Line Tube	3.550
Moulding, Rear Quarter Panel Trim ...	30.610	Nut, Generator Armature	7.402
Moulding, Rear Wheel Shield	30.085	Nut, Generator Cover Band	7.426
Moulding, Rear Window Finish	30.008	Nut, Generator Drive End Plate Seal Retainer	7.428
Moulding, Rear Window Garnish	30.503	Nut, Generator Drive Pulley	7.434
Moulding, Rocker Panel	30.084	Nut, Headlight Beam Adjusting Screw .	7.540
Moulding, Roof Drain Trough	30.087	Nut, Headlight Switch	7.553
Moulding, Roof Drip	30.052	Nut, Instrument Board Clock Opening Medallion	30.408
Moulding, Roof Front	30.087	Nut, Instrument Board Courtesy Light Switch	7.644
Moulding, Steering Column Cover	30.412	Nut, Instrument Board Radio Grille Screen	30.410
Moulding, Steering Gear Jacket Cover.	14.122	Nut, Instrument Mounting Bezel	30.412
Moulding, Windshield Finish	30.094	Nut, Instrument Cluster	19.122
Moulding, Windshield Garnish	30.304	Nut, Instrument Cluster	19.132
Moulding, Windshield Visor	40.115	Nut, Instrument Panel Switch	7.640
Moulding And Retainer, Cowl Trim Panel	30.602	Nut, Intake Manifold	3.000
Moulding And Retainer, Front Door Trim Panel	30.604	Nut, Linkage Enclosure Panel	30.904
Moulding And Retainer, Rear Door Trim Panel	30.608	Nut, Master Brake Cylinder Tube	15.060
Mounting Kit, Engine	1.000	Nut, Oil Filter Inlet Tube	2.315
Mounting Kit, Engine	60.1	Nut, Oil Filter Outlet Tube	2.316
Muffler, Exhaust	5.055	Nut, Oil Pressure Gauge Tube	2.425
		Nut, Oil Pressure Gauge Tube	2.440
N		Nut, Overdrive Kickdown Switch	7.806
Needle And Seat Assy., Carburetor ...	3.660	Nut, Prop. Shaft Companion Flange ...	11.004
Needle And Seat Assy., Carburetor ..	3.640	Nut, Prop. Shaft Joint Clamp	11.045
Nipple, Engine To Hose	40.002	Nut, Pump Mounting Bracket	30.906
Nipple, Ignition Cable	7.360	Nut, Pump To Carb. Fuel Tube	3.560
Nozzle, Carb. Main Discharge	3.640	Nut, Radiator Mounting	6.400
Nozzle, Defroster Inlet.....	40.008	Nut, Rear Axle Brake Tube	15.078
Nut, Air Conditioner Switch.....	40.002	Nut, Rear Axle Shaft	12.080
Nut, Air Conditioner Water Temperature Control Tube.....	40.002	Nut, Rear Brake Support Plate	15.002
Nut, Battery Ground Cable.....	7.510	Nut, Rear Brake Tube	15.070
Nut, Body Hold Down Bolt.....	30.012	Nut, Rear Prop. Shaft	11.014
Nut, Carb. Choke Lever Clamp.....	3.660	Nut, Rear Prop. Shaft Companion Flange	11.020
Nut, Carburetor Choke Tube.....	3.010	Nut, Rear Spring "U" Bolt	12.215
Nut, Clock Mounting.....	19.155	Nut, Rear Wheel Hub And Drum	16.020
Nut, Courtesy Light Dummy Knob Mounting Stud.....	7.644	Nut, Rear Window Lift Support	30.218
Nut, Defroster Control.....	40.008	Nut, Speedometer Mounting	19.140
Nut, Distributor Vacuum Chamber Tube.	7.340	Nut, Starting Motor Cover Band	7.238
Nut, Door Indicator Light Jewel.....	30.718	Nut, Starting Motor Field Coil Terminal Stud	7.228
Nut, Exhaust Manifold.....	5.000		
Nut, Flywheel.....	1.360		
Nut, Folding Top Linkage Enclosure Panel.....	30.904		

ALPHABETICAL INDEX

NAME AND PART DESCRIPTION	GROUP NUMBER	NAME AND PART DESCRIPTION	GROUP NUMBER
Nut, Starting Motor Solenoid Relay Terminal	7.265	P	
Nut, Starting Motor Solenoid Switch Terminal	7.265	Pad, Brake Pedal	15.102
Nut, Starting Motor Terminal	7.222	Pad, Clutch Pedal	8.140
Nut, Starting Switch	7.270	Pad, Dash Insulating	30.630
Nut, Steering Gear Lever Arm	14.200	Pad, Folding Top Support	30.632
Nut, Steering Wheel	14.126	Pad, Front Seat Cushion	30.616
Nut, Timing Gear	1.600	Pad, Horn Blowing Ring Contact Plate	7.534
Nut, Vacuum Antenna Valve	40.102	Pad, Horn Blowing Ring Damper	7.533
Nut, Vacuum Pump Support Bolt	30.912	Pad, Hydraulic Pump Motor Mounting ..	30.906
Nut, Valve Tappet Cover	1.750	Pad, License Light Mounting	30.0702
Nut, Ventilator Control Mounting Stud	30.034	Pad, Luster Seal Buffer	40.134
Nut, Wheel	16.000	Pad, Parking And Directional Light...	7.560
Nut, Window Lift Tube	30.910	Pad, Rear Seat Cushion	30.620
Nut, Windshield Wiper Arm Drive Body ..	30.358	Pad, Steering Column Dash Panel	14.124
Nut, Windshield Wiper Control	30.354	Pad, Tail Stop And Directional Light	7.570
Nut, Windshield Wiper Pump Tube	30.364	Pad, Taxi Roof Sign Mounting	30.716
O		Pad, Upper Deck Hinge Cover	30.6129
Oiler, Brake Pedal	15.102	Pan, Clutch Housing	8.135
Oiler, Clutch Pedal	8.140	Pan, Engine Dust	18.015
Oiler, Clutch Pedal Cross Shaft	8.155	Pan, Oil	2.400
Oiler, Clutch Release Bearing Shaft ..	8.130	Pan, Rear Floor	30.058
Oiler, Distributor	7.302	Panel, Ash Receiver Front	30.806
Oiler, Front Suspension Lower Arm ...	13.018	Panel, Center Pillar Trim	30.606
Oiler, Front Suspension Upper Arm ...	13.014	Panel, Cowl Trim	30.602
Oiler, Front Suspension Lower Arm Outer Pivot	13.012	Panel, Front Door Garnish Moulding Trim	30.101
Oiler, Front Suspension Upper Arm Pivot	13.010	Panel, Front Door Trim	30.604
Oiler, Generator Commutator End Plate	7.412	Panel, Front Seat Frame Back Trim ...	30.616
Oiler, Generator Drive End Plate	7.428	Panel, Front Stone Deflector Center..	6.492
Oiler, Steering Drag Link End Socket	14.210	Panel, Instrument Board Control.....	30.414
Oiler, Steering Idler Lever Bushing ..	14.214	Panel, Instrument Board Radio Control	30.410
Oiler, Steering Knuckle	13.000	Panel, Lower Deck	30.058
Oiler, Steering Tie Rod	14.216	Panel, Rear Compartment Side	30.040
Oiler, Trans. Gear Shift Lower Lever ..	9.325	Panel, Rear Compartment Trim	30.611
Oiler, Trans. Gear Shift Rod Bellcrank	9.345	Panel, Rear Door Garnish Moulding Trim	30.119
Oil Seal, Overdrive Solenoid	7.800	Panel, Rear Door Trim	30.608
Oil Seal, Rear Axle Drive Pinion Rear Bearing	12.060	Panel, Rear Luggage Shelf Trim	30.624
Oil Seal, Rear Axle Shaft	12.080	Panel, Rear Quarter	30.040
Oil Seal, Crankshaft Bearing Rear Filler Block	1.326	Panel, Rear Quarter Trim	30.610
Oil Seal, Trans. Main Shaft Bearing Retainer	9.145	Panel, Rear Wheel Housing	30.040
Oil Seal, Trans. Overdrive Main Shaft	9.235	Panel, Rocker	30.056
Oil Seal, Trans. Overdrive Shift Control Shaft	9.255	Panel, Roof	30.052
Oil Seal, Trans. Shifting Lever	9.180	Panel, Seat Protector	40.129
Ornament Package, Hood	40.140	Panel, Sun Visor	30.626
Outlet, Air Duct	30.034	Panel, Tool Compartment Trim	30.611
		Panel, Top Linkage Enclosure	30.904
		Panel, Ventilator And Heater Cover ..	30.410
		Panel, Windshield Header Trim	30.6127
		Pawl, Deck Lid Handle	30.068
		Pawl, License Light Handle	30.0702
		Pawl, Trans. Overdrive Stationary Gear	9.210
		Pedal, Accelerator	3.070
		Pedal, Brake	15.102

ALPHABETICAL INDEX

NAME AND PART DESCRIPTION	GROUP NUMBER	NAME AND PART DESCRIPTION	GROUP NUMBER
Pedal, Clutch	8.140	Piston And Pin Assy., Carb. Vacuum ..	3.640
Perfect Seal Gasket Paste	40.134	Piston And Pin Assy., Carb. Vacuum ..	3.660
Pillar, Body	30.038	Piston, Link And Shaft Assy., Carb. Choke.....	3.640
Pin, Carb. Anti-Percolator Rocker Arm	3.640	Pivot, Clutch Pedal Cross Shaft	8.155
Pin, Carb. Choke Piston	3.640	Pivot, Front Door Vent.....	30.206
Pin, Carb. Choke Piston	3.660	Pivot, Front Suspension Lower Arm Inner	13.020
Pin, Carb. Float Lever Fulcrum	3.640	Pivot, Front Suspension Upper Arm Outer	13.010
Pin, Carb. Float Lever Fulcrum	3.660	Pivot, Front Suspension Upper Arm Inner	13.016
Pin, Clutch Pressure Plate Lever.....	8.106	Pivot, Rear Door Vent.	30.216
Pin, Clutch Pressure Plate Lever	8.104	Pivot, Rear Seat Back Hinge	30.560
Pin, Directional Signal Light Switch Cut Off	7.630	Pivot, Rear Seat Hinge	30.556
Pin, Distributor Drive Shaft	7.330	Pivot, Upper Lid Support	30.064
Pin, Front Door Check Arm.....	30.112	Plastigage	1.315
Pin, Front Door Regulator Handle.....	30.208	Plate, Brake Pedal Floor	15.112
Pin, Front Door Upper Hinge Arm To Cage.....	30.108	Plate, Clutch Pedal Floor	8.170
Pin, Front Door Vent. Handle.....	30.206	Plate, Clutch Pressure	8.104
Pin, Hood Lock Safety Catch Pivot....	18.152	Plate, Clutch Pressure	8.106
Pin, Oil Pump Drive Gear.....	2.210	Plate, Cylinder Block Front End	1.105
Pin, Piston.....	1.420	Plate, Cylinder Block Rear End	1.110
Pin, Prop. Shaft Joint.....	11.037	Plate, Dome Light Switch Hole Cover .	30.706
Pin, Rear Door Check Arm.....	30.132	Plate, Folding Top Locking Mechanism Handle Escutcheon Anchor	30.902
Pin, Rear Door Handle.....	30.134	Plate, Folding Top Locking Striker ..	30.902
Pin, Rear Door Regulator Handle.....	30.218	Plate, Folding Top No. 1 Bow Striker Anchor	30.902
Pin, Rear Door Upper Hinge Arm To Cage.....	30.126	Plate, Front Brake Support	15.000
Pin, Rear Door Vent. Handle.....	30.216	Plate, Front Bumper Bar Spacer	20.200
Pin, Steering Idler Lever.....	14.212	Plate, Front Door Lock Striker	30.104
Pin, Top Locking Mechanism Handle....	30.902	Plate, Front Door Trim Panel Kick ...	30.604
Pin, Trans. Gear Shift Lever.....	9.300	Plate, Front Door Vent. Upper Tapping	30.206
Pin, Trans. Gear Shift Shaft Upper ..	9.310	Plate, Front Fender Name	18.004
Pin, Trans. Gear Shift Tube Lower ...	9.310	Plate, Generator Commutator End	7.412
Pin, Trans. Overdrive Shift Control Shaft	9.255	Plate, Generator Drive End	7.428
Pin, Trans. Shifting Lever	9.180	Plate, Glove Box Door Name	30.404
Pin, Trans. Shifting Lever Poppet Ball	9.190	Plate, Glove Box Door Striker	30.404
Pin and Bushing Kit, Steering Idler Lever	14.212	Plate, Heater And Defroster Control .	40.008
Pin And Bushing Kit, Steering Idler Lever.....	60.4	Plate, Hood Lock Latch	18.150
Pin Spring, Carburetor.....	3.640	Plate, Hood Lock Latch Support	18.147
Pin Spring, Carburetor.....	3.660	Plate, Horn Blowing Retaining	7.533
Pinion, Speedometer.....	9.286	Plate, Horn Blowing Ring	7.533
Pinion, Taximeter Drive.....	9.290	Plate, Horn Blowing Ring Contact	7.534
Pinion, Transmission Drive	9.100	Plate, Horn Blowing Ring Grounding ..	7.533
Pinion, Trans. Overdrive Governor ...	9.265	Plate, Horn Medallion Retainer	7.531
Pipe, Exhaust	5.040	Plate, Hydraulic Pump	30.906
Pipe, Exhaust	5.020	Plate, Instrument Board Name	30.408
Pipe, Tail	5.070	Plate, Lower Lid Hinge Reinforcing ..	30.064
Piston	1.410	Plate, Master Brake Cylinder Piston Stop	15.035
Piston, Carburetor Choke	3.640	Plate, Rear Brake Support	15.002
Piston, Carburetor Choke	3.660	Plate, Rear Bumper Bar Spacer	20.250
Piston, Front Brake Cylinder	15.020	Plate, Rear Bumper Guard	20.265
Piston, Master Brake Cylinder	15.035	Plate, Rear Door Arm Rest	30.128
Piston, Rear Brake Cylinder	15.030	Plate, Rear Door Lock Striker	30.122

ALPHABETICAL INDEX

NAME AND PART DESCRIPTION	GROUP NUMBER	NAME AND PART DESCRIPTION	GROUP NUMBER
Plate, Rear Door Trim Panel Kick	30.608	Pulley, Generator Drive	7.434
Plate, Rear Door Vent. Upper Pivot ..	30.216	Pulley, Windshield Wiper Cable	
Plate, Rear Seat Rear Hinge Anchor ..	30.560	Tension	30.356
Plate, Rear Spring Mounting	12.215	Pump, Fuel And Vacuum	3.470
Plate, Rear Wheel Shield Anchor	30.057	Pump, Hydraulic	30.906
Plate, Scuff	30.808	Pump, Oil	2.200
Plate, Starting Motor Center	7.240	Pump, Water	6.300
Plate, Starting Motor Commutator End.	7.234		
Plate, Starting Motor Spring Anchor .	7.244	R	
Plate, Steering Gear Support Bracket		Radiator	6.400
Tapping	14.120	Radiator Flush	40.134
Plate, Tail Light Cable Socket	7.576	Radiator Rust Resistor	40.134
Plate, Tire Well Cover	30.058	Radiator Stopleak	40.134
Plate, Trans. Overdrive Stationary		Radio Conversion Kit.....	40.100
Gear Cover	9.215	Radio Package.....	40.100
Plate, Trans. Second and High		Rail, Radiator Grille Guard	40.143
Synchronizer Sleeve Shifting	9.130	Rail, Rear Deck Guard	40.143
Plate, Water Temperature Control	40.002	Rail, Transmission Overdrive Shift	
Plate And Nut, Hood Lock Bolt	18.148	Fork	9.250
Plate Assembly, Distributor Breaker .	7.310	Reflector, Glove Compartment Light ..	30.710
Plug, Carb. Main Discharge Nozzle		Regulator, Front Door Glass	30.208
Retaining	3.640	Regulator, Generator Voltage	7.470
Plug, Carb. Nozzle Passage	3.660	Regulator, Rear Door Glass	30.218
Plug, Carb. Pump Discharge Check	3.660	Reinforcement, Body Pillar	30.038
Plug, Crankshaft Pulley Keyway	1.350	Reinforcement, Front Suspension Lower	
Plug, Cylinder Block Oil Header	1.100	Arm Inner Pivot	13.020
Plug, Distributor Cap	7.302	Reinforcement, Lower Deck Panel.....	30.058
Plug, Distributor Vacuum Chamber	7.338	Reinforcement, Steering Column Dash	
Plug, Garnish Moulding Defroster	30.304	Panel Pad.....	14.124
Plug, Hydraulic Pump Valve	30.906	Reinforcement, Steering Column	
Plug, Master Brake Cylinder Filler ..	15.035	Jacket.....	14.106
Plug, Oil Pan Drain	2.400	Reinforcement, Windshield Garnish	
Plug, Oil Pressure Relief Valve	2.410	Moulding.....	30.304
Plug, Rear Floor Pan Tire Well	30.058	Relay, Horn.....	7.525
Plug, Steering Drag Link End Socket .	14.206	Relay, Overdrive Solenoid	7.804
Plug, Steering Gear Shaft Cover Oil .	14.118	Repair Kit, Accelerator Linkage.....	3.075
Plug, Tool Compartment Drain Hole ...	30.040	Repair Kit, Accelerator Linkage.....	60.3
Plug, Trans. Filler And Drain	9.005	Repair Kit, Brake Cylinder.....	15.014
Plug, Water Pump	6.300	Repair Kit, Brake Cylinder.....	60.15
Plug And Gasket Assembly, Carburetor.	3.640	Repair Kit, Carburetor.....	3.660
Plug And Gasket Assembly, Carburetor		Repair Kit, Carburetor.....	3.640
Strainer	3.660	Repair Kit, Carburetor.....	60.3
Plug And Gasket Assembly, Carburetor		Repair Kit, Front Suspension Lower	
Bowl Strainer	3.640	Arm Inner Pivot.....	13.020
Plug And Gasket Assembly, Carburetor		Repair Kit, Front Suspension Lower	
Idle Passage	3.640	Arm Inner Pivot.....	60.13
Plug And Gasket Assembly, Carburetor		Repair Kit, Front Suspension Lower	
Pump Check Ball	3.640	Arm Outer Pivot.....	13.012
Plug And Gasket Assembly, Carburetor		Repair Kit, Front Suspension Lower	
Pump Discharge Passage	3.660	Outer Pivot.....	60.13
Plunger, Rod Spring And Retainer		Repair Kit, Front Suspension Upper	
Assy., Carb. Pump.....	3.660	Arm Inner Pivot.....	13.016
Point Set, Distributor Breaker	7.316	Repair Kit, Front Suspension Upper	
Point Set, Distributor Breaker	60.7	Arm Inner Pivot.....	60.13
Pointer, Timing	1.370	Repair Kit, Front Suspension Upper	
Presstite Cord, Windshield Sealer ...	40.133	Arm Outer Pivot.....	13.010
Pulley, Crankshaft	1.350	Repair Kit, Front Suspension Upper	
Pulley, Fan	6.000	Arm Outer Pivot.....	60.13

ALPHABETICAL INDEX

NAME AND PART DESCRIPTION	GROUP NUMBER	NAME AND PART DESCRIPTION	GROUP NUMBER
Repair Kit, Fuel Pump.....	3.480	Retainer, Instrument Board Ash	
Repair Kit, Fuel Pump.....	60.3	Receiver	30.406
Repair Kit, Steering Knuckle King Pin	13.002	Retainer, Instrument Tubes Grommet ..	19.150
Repair Kit, Steering Knuckle King Pin	60.13	Retainer, Intake Manifold	3.000
Repair Kit, Master Brake Cylinder....	15.040	Retainer, Lock Cylinder To Door	30.114
Repair Kit, Master Brake Cylinder....	60.15	Retainer, Master Brake Cylinder	
Repair Kit, Prop. Shaft Universal		Piston Stop Plate	15.035
Joint.....	11.030	Retainer, Parking Light Lens	7.563
Repair Kit, Prop. Shaft Universal		Retainer, Rear Axle Shaft Bearing ...	12.080
Joint.....	60.11	Retainer, Rear Door Glass Run Felt ..	30.212
Repair Kit, Water Pump	6.300	Retainer, Rear Floor Mat Riser	30.630
Repair Kit, Water Pump	60.6	Retainer, Rear Quarter Panel	
Reservoir, Hydraulic Pump	30.906	Moulding	30.091
Retainer, Carb. Climatic Control		Retainer, Rear Seat Back Board	30.556
Housing	3.640	Retainer, Rear Window Moulding	30.088
Retainer, Carb. Climatic Control		Retainer, Roof Front Moulding	30.086
Housing	3.660	Retainer, Roof Side Rail	
Retainer, Carb. Connector Rod Spring.	3.660	Weatherstrip	30.102
Retainer, Carb. Pump Spring	3.660	Retainer, Roof Side Rail	
Retainer, Carb. Throttle Connector		Weatherstrip	30.120
Rod Spring	3.640	Retainer, Seat Back Ash Receiver ...	30.806
Retainer, Center Pillar Crease Line		Retainer, Shock Absorber Cushion ...	20.002
Moulding	30.092	Retainer, Shock Absorber Cushion ...	20.004
Retainer, Center Pillar Exterior		Retainer, Steering Gear Jacket Cover.	14.122
Moulding	30.091	Retainer, Storage Battery	7.500
Retainer, Chassis Wiring Harness		Retainer, Tail Light Body Housing ...	7.571
Grommet	7.700	Retainer, Tail Light Lens Gasket ...	7.572
Retainer, Cowl Upper Pillar		Retainer, Tool Compartment Trim	
Weatherstrip	30.102	Panel	30.611
Retainer, Directional Signal		Retainer, Trans. Drive Pinion Bearing	9.115
Indicator Jewel	40.142	Retainer, Trans. Gear Shift Lever	
Retainer, Door Belt Moulding	30.090	Seal Lower	9.320
Retainer, Exhaust Manifold	5.000	Retainer, Trans. Gear Shift Lower	
Retainer, Folding Top Quarter Panel		Lever	9.330
Fastener	30.632	Retainer, Trans. Main Shaft Bearing..	9.145
Retainer, Front Bow Weatherstrip	30.902	Retainer, Trans. Overdrive Free	
Retainer, Front Door Rear Glass Run .	30.204	Wheeling Cam Bearing	9.230
Retainer, Front Door Upper		Retainer, Trans. Overdrive Governor..	9.265
Weatherseal.....	30.102	Retainer, Valve Spring	1.720
Retainer, Front Sway Eliminator Bar..	13.200	Retainer, Window Lift	30.208
Retainer, Front Door Vent. Frame Nut.	30.206	Retainer, Windshield Division Bar ...	30.094
Retainer, Front Door Vent. Frame		Retaining Ring, Carb. Throttle Shaft.	3.660
Weatherstrip.....	30.206	Retaining Ring, Headlight Sealed Beam	
Retainer, Generator Commutator End		Unit	7.540
Plate Bearing.....	7.412	Retaining Ring, Piston Pin	1.420
Retainer, Generator Drive End Plate		Ring, Glove Compartment Light	
Bearing	7.428	Reflector Retaining	30.710
Retainer, Generator Drive End Plate		Ring, Horn Blowing	7.533
Seal Inner	7.428	Ring, Piston	1.415
Retainer, Glove Box Package	30.404	Ring, Wheel Trim	16.028
Retainer, Hand Brake Operating Lever.	15.008	Ring Gear, Flywheel.....	1.360
Retainer, Hood Lock Bolt Plate		Ring Gear, Trans. Overdrive.....	9.245
Release Spring	18.148	Ring Set, Piston Oil Control	1.417
Retainer, Horn Blowing Ring Cable ...	7.536	Ring Set, Piston Oil Control	60.1
Retainer, Horn Blowing Ring Cable		Ring Set, Wheel Trim	40.122
Seal	7.536	Riser, Roof And Side Quarter Deck	
Retainer, Horn Medallion	7.531	Cover	30.902
Retainer, Hydraulic Pump Fluid	30.906		

ALPHABETICAL INDEX

NAME AND PART DESCRIPTION	GROUP NUMBER	NAME AND PART DESCRIPTION	GROUP NUMBER
Rivet, Front Door Vent. Upper Hinge Tubular	30.206	Screw, Carb. Throttle Lever Adjustment	3.660
Rivet, Hood Hinge Arm	18.200	Screw, Carb. Throttle Shaft Arm	3.640
Rivet, Tubular Rear Door Vent. Pivot.	30.216	Screw, Carb. Throttle Shaft Dog	3.660
Rivet, Wheel Hub Cap Spring Clip	16.026	Screw, Carb. Throttle Valve	3.640
Rivet Plug, Carburetor.....	3.660	Screw, Carb. Throttle Valve	3.660
Rivet Plug, Carburetor.....	3.640	Screw, Center Pillar Window	30.201
Rocker, Top Locking Mechanism	30.902	Screw, Clutch Pedal Floor Plate	8.170
Rod, Accelerator Bell Crank Link	3.410	Screw, Clutch Pressure Plate Lever Adjusting	8.106
Rod, Accelerator Pedal To Bell Crank.	3.080	Screw, Deck Lid Handle Cover	30.068
Rod, Carburetor Extension Shaft.....	3.450	Screw, Distributor Breaker Plate Lead	7.310
Rod, Carb. Throttle Connector.....	3.640	Screw, Distributor Breaker Point Set Clip	7.316
Rod, Connecting	1.400	Screw, Door Lock Striker Plate	30.122
Rod, Front Seat Adjuster Connecting..	30.554	Screw, Generator Brush Set	7.420
Rod, Front Door Lock Locking.....	30.104	Screw, Distributor Condenser	7.318
Rod, Front Door Remote Control	30.106	Screw, Distributor Terminal	7.300
Rod, Hood Lock Latch Support.....	18.147	Screw, Distributor Vacuum Chamber ...	7.334
Rod, Master Brake Cylinder Piston Push	15.035	Screw, Door Lock Striker Plate	30.104
Rod, Master Cylinder Operating	15.100	Screw, Generator Commutator End Plate Bearing Retainer	7.412
Rod, Rear Door Lock Locking	30.122	Screw, Generator Cover Band	7.426
Rod, Rear Door Bell Crank To Lock Locking.....	30.122	Screw, Generator Drive End Plate Seal Retainer	7.428
Rod, Rear Door Remote Control.....	30.124	Screw, Generator Ground Terminal	7.400
Rod, Top Control	30.908	Screw, Glove Box	30.404
Rod, Trans. Gear Shift	9.340	Screw, Headlight Beam Adjusting	7.540
Rod And Plunger Assembly, Carb. Accelerating Pump	3.640	Screw, Headlight Cable Ground	7.546
Roller Package, Prop. Shaft Joint ...	11.037	Screw, Headlight Door	7.540
Roller And Cage, Steering Gear Worm Thrust Bearing	14.114	Screw, Headlight Sealed Beam Unit ...	7.540
Rotor, Distributor Cam	7.332	Screw, Horn Blowing Ring	7.533
Rotor, Hydraulic Pump	30.906	Screw, License Light Door	30.0702
Run, Front Door Glass	30.204	Screw, Parking Light Lens Bezel	7.563
Run, Rear Door Glass	30.212	Screw, Rear Door Locking Rod Bell Crank	30.122
Run, Rear Door Vent. Division Bar ...	30.216	Screw, Rear Door Vent Upper Pivot Plate	30.216
S		Screw, Rear Door Weatherstrip Retainer	30.120
Screen, Carb. Climatic Control Housing	3.640	Screw, Rear Seat Hinge Lower Pivot Thumb	30.556
Screen, Fuel Pump Bowl	3.490	Screw, Robe Rail Cord Escutcheon	30.628
Screen, Instrument Board Radio Grille	30.410	Screw, Starting Motor Brush Set.....	7.236
Screw, Brake Pedal Floor Plate	15.112	Screw, Starting Motor Cover Band	7.238
Screw, Carb. Choke Lever Clamp	3.640	Screw, Steering Gear Shaft And Roller Adjusting	14.116
Screw, Carb. Choke Lever Clamp	3.660	Screw, Valve Tappet	1.740
Screw, Carb. Choke Valve	3.640	Screw, Windshield Division Bar	30.306
Screw, Carb. Choke Valve	3.660	Screw, Windshield Division Bar Retainer	30.094
Screw, Carb. Climatic Control Housing	3.640	Screw And Washer, Carb. Air Horn To Bowl Cover	3.660
Screw, Carb. Climatic Control Housing	3.660	Screw And Washer, Carb. Body Flange To Main Body	3.660
Screw, Carb. Fast Idle Adjustment ...	3.660	Screw And Washer, Carb. Bowl Cover ..	3.660
Screw, Carb. Fast Idle Cam	3.640		
Screw, Carb. Fast Idle Cam	3.660		
Screw, Carb. Idle Adjustment	3.640		
Screw, Carb. Idle Adjustment	3.660		
Screw, Carb. Metering Rod Arm Clamp .	3.660		
Screw, Carb. Pump Retainer	3.660		

ALPHABETICAL INDEX

NAME AND PART DESCRIPTION	GROUP NUMBER	NAME AND PART DESCRIPTION	GROUP NUMBER
Screw And Washer, Carb. Choke Body To Main Body	3.640	Seal, Front Suspension Upper Arm	13.014
Screw And Washer, Carb. Choke Body To Main Body	3.660	Seal, Front Suspension Upper Arm Outer Pivot	13.010
Screw And Washer, Carb. Dust And Bowl Cover	3.640	Seal, Front Wheel Bearing Inner	16.010
Screw And Washer, Carb. Dust Cover ..	3.660	Seal, Generator Drive End Plate	7.428
Screw And Washer, Carb. Main Body To Throttle Body	3.640	Seal, Horn Blowing Ring Cable	7.536
Screw And Washer, Carb. Pump Jet	3.660	Seal, Hydraulic Pump Bottom Plate ...	30.906
Screw And Washer, Prop. Shaft Joint Clamp	11.045	Seal, Hydraulic Pump Mounting Screw .	30.906
Screw With L/W, Cowl Trim Panel	30.602	Seal, Parking Light Baffle	7.561
Screw With L/W, Deck Lid Handle	30.068	Seal, Rear Door Glass	30.210
Screw With L/W, Deck Lid Latch Lower Striker	30.074	Seal, Rear Door Vent. Glass	30.216
Screw With L/W, Directional Signal Switch	40.142	Seal, Rear Stone Deflector	30.048
Screw With L/W, Door Hinge, Front ...	30.108	Seal, Steering Gear Jacket Cover	14.122
Screw With L/W, Door Hinge, Rear ...	30.126	Seal, Steering Gear Shaft And Roller.	14.116
Screw With L/W, Front Door Lock	30.104	Seal, Steering Idler Lever Bushing ..	14.214
Screw With L/W, Front Door Window Glass Run Channel	30.204	Seal, Trans. Gear Shift Lower Lever .	9.320
Screw With L/W, Heater Lever Control Knob	40.008	Seal, Water Pump	6.300
Screw With L/W, Hood Lock Control Bracket	18.158	Sealed Beam Unit, Fog Light.....	40.112
Screw With L/W, Horn Blowing Ring ...	7.533	Sealed Beam Unit, Headlight	7.540
Screw With L/W, Ignition Switch	7.350	Sealed Beam Unit, Spotlight	40.104
Screw With L/W, License Light Cable And Socket	30.0702	Sealzit, Windshield	40.133
Screw With L/W, License Light Door ..	30.0702	Seat, Clutch Pedal Cross Shaft	8.155
Screw With L/W, Parking And Directional Light	7.560	Seat, Front Shock Absorber	20.004
Screw With L/W, Parking Light Cable..	7.568	Seat, Front Suspension Spring Upper..	13.026
Screw With L/W, Parking Light Lens ..	7.563	Seat, Headlight Sealed Beam Unit	7.540
Screw With L/W, Rear Compartment Trim Panel	30.611	Seat, Steering Drag Link End Socket..	14.206
Screw With L/W, Rear Door Lock	30.122	Set Screw, Clutch Release Fork	8.125
Screw With L/W, Rear Floor Mat	30.630	Shackle And Link Kit, Rear Spring ...	12.220
Screw With L/W, Rear Quarter Trim Panel	30.610	Shackle And Link Kit, Rear Spring ...	60.12
Screw With L/W, Rear Window Trim Cover	30.6126	Shaft, Accelerator Cross	3.430
Screw With L/W, Tail Light Cable Socket Plate	7.576	Shaft, Brake And Clutch Pedal	15.104
Screw With L/W, Temperature Control Knob	40.002	Shaft, Carb. Extension	3.450
Screw With L/W, Vent. Control Knob ..	30.034	Shaft, Clutch Pedal	8.145
Screw With L/W, Vent. Control Cable Clip	30.034	Shaft, Clutch Pedal Cross	8.155
Seal, Crankshaft Oil	1.303	Shaft, Clutch Release Fork	8.125
Seal, Folding Top Hinge	30.902	Shaft, Distributor Drive	7.324
Seal, Front Door Glass	30.202	Shaft, Exhaust Manifold Heat Control Valve	5.010
Seal, Front Door Ventilator Window Glass	30.206	Shaft, Front Door Vent. Handle	30.206
Seal, Front Suspension Lower Arm	13.018	Shaft, Oil Pump Drive	2.210
Seal, Front Suspension Lower Arm Outer Pivot	13.012	Shaft, Oil Pump Idler Gear	2.215
		Shaft, Rear Axle	12.080
		Shaft, Rear Axle Differential Side Pinion	12.020
		Shaft, Rear Door Vent. Handle	30.216
		Shaft, Trans. Gear Shift Rod Cross...	9.342
		Shaft, Trans. Gear Shift Shaft	9.310
		Shaft, Trans. Main	9.120
		Shaft, Trans. Overdrive Main	9.235
		Shaft, Trans. Overdrive Shift Control	9.255
		Shaft, Trans. Reverse Idler Gear	9.175
		Shaft, Water Pump Drive	6.300
		Shaft And Bushing Kit, Steering Gear.	14.116
		Shaft And Bushing Kit, Steering Gear.	60.14
		Shaft And Coupling, Distributor Main Drive	7.344
		Shaft And Joint, Prop. Front	11.000
		Shaft And Joints, Prop. Rear	11.014

ALPHABETICAL INDEX

NAME AND PART DESCRIPTION	GROUP NUMBER	NAME AND PART DESCRIPTION	GROUP NUMBER
Shaft And Lever Assy, Carb. Throttle.	3.660	Sleeve, Horn Blowing Ring	7.533
Shaft And Roller, Steering Gear	14.116	Sleeve, Horn Blowing Ring Cable	7.536
Shaft And Yoke, Prop. Front	11.002	Sleeve, Ignition Cable	7.360
Shaft And Yoke, Prop. Rear	11.016	Sleeve, Instrument Lights Wiring Harness	7.643
Shaft Assy, Carb. Throttle Valve	3.640	Sleeve, License Light Cable	30.0702
Shell, Body	30.050	Sleeve, Overdrive Rail Switch To Governor Cable	7.810
Shield, Exhaust Manifold Heat Control	5.010	Sleeve, Overdrive Wiring Harness	7.812
Shield, Front Fender Splash	18.010	Sleeve, Parking Light Cable	7.568
Shield, Prop. Shaft Center Support Bearing	11.006	Sleeve, Relay To Horn Cable	7.525
Shield, Rear Wheel	30.057	Sleeve, Speedometer And Taximeter Drive Pinion	9.290
Shield, Steering Drag Link Stud Cover	14.204	Sleeve, Spotlight Cable Terminal	40.104
Shim, Body Hold Down	30.014	Sleeve, Tail Light Cable	7.576
Shim, Crankshaft Main Bearing Cap ...	1.320	Sleeve, Top Lift Wiring Harness	30.714
Shim, Crankshaft Thrustwasher	1.310	Sleeve, Trans. Gear Shift Lever	9.300
Shim, Deck Lid Latch Striker Plate ..	30.074	Sleeve, Trans. Gear Shift Rod	9.340
Shim, Front Door Lock Striker Plate ..	30.104	Sleeve, Trans. Overdrive Governor ...	9.265
Shim, Front Door Push Button	30.106	Sleeve, Trans. Second And High Synchronizer	9.130
Shim, Front Suspension Upper Arm Inner Pivot	13.016	Sleeve, Trans. Shifting Lever Poppet Ball	9.190
Shim, Rear Axle Differential Bearing	12.035	Sleeve, Window Lift Wiring Harness...	30.714
Shim, Rear Axle Drive Pinion Front Bearing	12.050	Sleeve Nut, Clock	19.155
Shim, Rear Axle Drive Pinion Rear Bearing	12.060	Slinger, Crankshaft Thrustwasher	1.310
Shim, Rear Axle Shaft Bearing	12.080	Slinger, Generator Drive End Plate ..	7.428
Shim, Rear Door Striker Plate	30.122	Slinger, Rear Axle Drive Pinion Rear Bearing	12.060
Shim, Rear Door Push Button	30.124	Slinger, Trans. Drive Pinion Bearing	9.105
Shim, Steering Gear Column And Worm..	14.110	Small Parts Kit, Transmission	9.003
Shim, Steering Knuckle King Pin Thrust Bearing	13.004	Small Parts Kit, Transmission	60.9
Shim, Under Body To Frame	30.014	Snap Ring, Distributor Cam	7.332
Shock Absorber, Front	20.000	Snap Ring, Trans. Drive Pinion Bearing	9.110
Shock Absorber, Rear	20.010	Snap Ring, Trans. Gear Shift Rod Bellcrank	9.345
Shoe Set, Brake	60.15	Snap Ring, Trans. Gear Shift Shaft ..	9.310
Shoe Set, Brake	15.004	Snap Ring, Trans. Overdrive Main Shaft Bearing	9.240
Shoe, Trans. Shifting	9.185	Snap Ring, Trans. Overdrive Stationary Gear	9.210
Shroud, Radiator	6.480	Snap Ring, Trans. Overdrive Stationary Gear Cover Plate	9.215
Sign, Taxi Roof	30.716	Snap Ring, Trans. Overdrive Ring Gear	9.245
Silencer, Steering Gear Jacket Cover.	14.122	Snap Ring, Trans. Second And High Synchronizer	9.125
Sleeve, Air Conditioner Cable	40.002	Snap Ring, Trans. Second And High Synchronizer Sleeve	9.130
Sleeve, Air Duct Outlet	30.034	Snap Ring, Trans. Standard Main Shaft Bearing	9.140
Sleeve, Body Wiring Harness	30.702	Snap Ring, Water Pump	6.300
Sleeve, Carburetor Choke Tube	3.010	Socket, Courtesy Light Seat Back....	7.649
Sleeve, Chassis Wiring Harness	7.700	Socket, Courtesy Light Wiring Harness	7.648
Sleeve, Cigar Lighter Cable	7.657	Socket, Directional Indicator Light Cable	7.637
Sleeve, Courtesy Light Wiring Harness	7.648		
Sleeve, Directional Signal Light Cable Terminal	40.142		
Sleeve, Directional Signal Light Switch	7.620		
Sleeve, Fuel Gauge Tank Unit Cable ..	7.660		
Sleeve, Headlight Cable	7.546		
Sleeve, Headlight Cable Terminal Block Harness	7.552		

ALPHABETICAL INDEX

NAME AND PART DESCRIPTION	GROUP NUMBER	NAME AND PART DESCRIPTION	GROUP NUMBER
Socket, Directional Signal Light Wiring.....	40.142	Spark Plug.....	7.375
Socket, Headlight Beam Indicator Light.....	7.556	Speednut, Ash Receiver.....	30.125
Socket, Instrument Lights Wiring Harness.....	7.643	Speednut, Defroster Control Cable....	40.008
Socket, Steering Drag Link.....	14.206	Speednut, Door Arm Rest.....	30.614
Solenoid, Overdrive.....	7.800	Speednut, Front Door Lock Locking Rod Escutcheon	30.104
Solenoid, Starting Motor	7.265	Speednut, Front Door Push Button Escutcheon	30.106
Solvent Fluid, Windshield Washer.....	40.116	Speednut, Front Door Remote Control Rod	30.106
Spacer, Body Hold Down Bolt.....	30.012	Speednut, Front Door Lock Remote Control Assist Handle	30.106
Spacer, Center Pillar Brace.....	30.012	Speednut, Front Door Garnish Moulding	30.101
Spacer, Chassis Wiring Harness Clip..	7.700	Speednut, Front Fender	18.000
Spacer, Clock Lens.....	19.155	Speednut, Front Fender Name Plate ...	18.104
Spacer, Clutch Pedal Cross Shaft Pivot	8.155	Speednut, Front Fender Splash Shield.	18.010
Spacer, Deck Lid Hinge To Body	30.064	Speednut, Front Stone Deflector Panel	6.492
Spacer, Distributor Cam	7.332	Speednut, Hood Medallion	18.130
Spacer, Exhaust Manifold Heat Control Cover	5.015	Speednut, Instrument Board Name Plate	30.408
Spacer, Exhaust Muffler	5.060	Speednut, Overdrive Kickdown Switch Bracket	7.806
Spacer, Front Bumper Bar	20.200	Speednut, Parking Light Baffle	7.561
Spacer, Front Bumper Guard	20.260	Speednut, Parking Light Housing	7.560
Spacer, Front Door Trim Panel Moulding	30.101	Speednut, Radiator Grille	6.491
Spacer, Front Suspension Spring	13.024	Speednut, Radiator Grille Bar	6.490
Spacer, Fuel Tank Mounting	3.520	Speednut, Rear Door Lock Locking Rod Escutcheon	30.122
Spacer, Generator Drive Pulley	7.434	Speednut, Rear Door Lock Remote Control Assist Handle	30.124
Spacer, Hand Brake Lever	15.200	Speednut, Rear Door Remote Control Rod	30.124
Spacer, Headlight Knob Switch	7.553	Speednut, Rear Door Trim Panel Clip .	30.119
Spacer, Horn Bracket	7.520	Speednut, Rear Door Trim Panel Support	30.124
Spacer, Instrument Board Control Panel.....	30.414	Speednut, Rear License Plate	20.119
Spacer, Instrument Lens.....	19.122	Speednut, Seat Back Ash Receiver Retainer	30.806
Spacer, Instrument Lens.....	19.132	Speednut, Vent Control Cable	30.034
Spacer, Master Brake Cylinder.....	15.035	Speednut, Water Temperature Control Cable	40.002
Spacer, Prop. Shaft Center Bearing Support.....	11.008	Speednut, Window Lift Support	30.208
Spacer, Radiator Shroud.....	6.480	Speedometer Head.....	19.140
Spacer, Radio Grille.....	30.410	Spot Remover.....	40.134
Spacer, Rear Axle Drive Pinion Bearing.....	12.060	Spotlight Package.....	40.104
Spacer, Rear Pillar Brace.....	30.012	Spring, Accelerator Cross Shaft.....	3.430
Spacer, Speedometer Lens.....	19.140	Spring, Accelerator Linkage Tension..	3.400
Spacer, Steering Column Jacket Bearing.....	14.108	Spring, Brake Pedal Return.....	15.108
Spacer, Steering Gear Support Bracket.....	14.120	Spring, Brake Shoe Pull Back.....	15.004
Spacer, Steering Gear Support "U" Bolt.....	14.121	Spring, Carb. Accelerating Pump Piston.....	3.640
Spacer, Tail Light.....	7.570	Spring, Carb. Anti-Percolator Rocker Arm.....	3.640
Spacer, Trans. Counter Shaft Gear Bearing.....	9.160	Spring, Carb. Extension Shaft.....	3.450
Spacer, Underbody to Frame.....	30.012	Spring, Carb. Fast Idle Cam.....	3.660
Spacer, Windshield Wiper Arm Drive Body.....	30.358	Spring, Carb. Idle Adjustment Screw..	3.660
Spacer, Windshield Wiper Control.....	30.356	Spring, Carb. Idle Adjustment Screw..	3.640
Spacer, Windshield Wiper Motor and Driver.....	30.352	Spring, Carb. Metering Rod.....	3.640
		Spring, Carb. Metering Rod.....	3.660

ALPHABETICAL INDEX

NAME AND PART DESCRIPTION	GROUP NUMBER	NAME AND PART DESCRIPTION	GROUP NUMBER
Spring, Carb. Plunger.....	3.660	Spring, Rear	12.200
Spring, Carb. Pump.....	3.660	Spring, Rear Brake Cylinder Piston Return	15.030
Spring, Carb. Throttle Connector Rod.	3.640	Spring, Rear Door Glass Regulator Handle	30.218
Spring, Carb. Vacuum Piston.....	3.660	Spring, Rear Door Remote Control Rod Push Button	30.124
Spring, Carb. Vacuum Piston.....	3.640	Spring, Rear Door Vent.....	30.216
Spring, Clutch Pedal Assist.....	8.160	Spring, Rear Seat Back Center Arm Rest	30.620
Spring, Clutch Pedal Cross Shaft.....	8.155	Spring, Robe Rail Cord	30.628
Spring, Clutch Pedal Return.....	8.140	Spring, Starting Motor Bendix Drive..	7.244
Spring, Clutch Pressure Plate.....	8.106	Spring, Starting Motor Brush Set....	7.236
Spring, Clutch Pressure Plate.....	8.104	Spring, Steering Column Jacket Bearing.....	14.108
Spring, Clutch Release Bearing.....	8.120	Spring, Steering Drag Link End Socket	14.206
Spring, Clutch Release Fork.....	8.125	Spring, Trans. Gear Shift Lever Guide	9.305
Spring, Courtesy Light Cable.....	7.646	Spring, Trans. Gear Shift Rod Cross Shaft	9.342
Spring, Courtesy Light Socket Seat Back.....	7.649	Spring, Trans. Gear Shift Shaft	9.310
Spring, Courtesy Light Wiring Harness Socket.....	7.648	Spring, Trans. Overdrive Free Wheeling Cam Bearing Retainer	9.230
Spring, Deck Lid Handle	30.068	Spring, Trans. Overdrive Shift Control Shaft Retractor	9.255
Spring, Deck Lid Handle Latch Coil ..	30.074	Spring, Trans. Shifting Lever Poppet Ball	9.190
Spring, Deck Lid Hinge	30.064	Spring, Upper Lid Support	30.064
Spring, Directional Indicator Light Cable Socket	7.637	Spring, Valance To Rear Seat Back Support	30.620
Spring, Distributor Drive Shaft Anti/Rattle	7.324	Spring, Valve, Intake And Exhaust ...	1.720
Spring, Distributor Vacuum Chamber ..	7.338	Spring, Window Lift Switch Locking ..	30.208
Spring, Dome Light Connector Cable Bulb Socket	30.704	Springwasher, Cylinder Yoke to Power Link	30.902
Spring, Door Lock Cylinder	30.114	Springwasher, Deck Lid Handle	30.068
Spring, Front Brake Cylinder Piston Return	15.020	Springwasher, Hand Brake Operating Lever	15.008
Spring, Front Door Glass Regulator Handle	30.208	Springwasher, Front Door Vent. Handle Shaft	30.206
Spring, Front Door Remote Control Rod Push Button	30.106	Springwasher, Rear Door Locking Rod Bellcrank	30.122
Spring, Front Door Vent	30.206	Springwasher, Rear Door Vent. Handle Shaft	30.216
Spring, Front Seat Back Center Arm Rest	30.616	Springwasher, Trans. Gear Shift Lower Lever	9.320
Spring, Front Suspension Coil	13.024	Springwasher, Trans. Gear Shift Lower Lever Retainer	9.330
Spring, Fuel Tank Filler Cover	30.040	Springwasher, Trans. Gear Shift Rod .	9.340
Spring, Hand Brake Front Cable	15.218	Springwasher, Upper Deck Lid Support Latch	30.074
Spring, Headlight Beam Indicator Light Socket	7.556	Stand, Foglight Display	40.112
Spring, Headlight Sealed Beam Unit ..	7.540	Stand, Spotlight Display	40.104
Spring, Hood Hinge	18.200	Starting Motor	7.222
Spring, Hood Lock Release	18.148	Stop, Front Door Check Arm	30.112
Spring, Hood Lock Latch	18.150	Stop, Front Door Vent Lower Pivot ...	30.206
Spring, Hood Lock Safety Catch	18.152	Stop, Rear Door Check Arm	30.132
Spring, Horn Blowing Ring	7.533	Stop, Rear Door Vent Lower Pivot	30.216
Spring, Hydraulic Pump	30.906	Stop, Rear Seat Back Board	30.556
Spring, Instrument Lights Wiring Harness Socket	7.643	Stop, Side Rail Rear Male Hinge	30.902
Spring, Intake And Exhaust Valve	1.720		
Spring, License Light Cable Socket ..	30.0702		
Spring, Master Brake Cylinder	15.035		
Spring, Oil Pressure Relief Valve ...	2.410		
Spring, Prop. Shaft Joint Centering .	11.038		
Spring, Prop. Shaft Joint Compensating	11.040		

ALPHABETICAL INDEX

NAME AND PART DESCRIPTION	GROUP NUMBER	NAME AND PART DESCRIPTION	GROUP NUMBER
Stop And Bracket, Front Door Check Arm	30.112	Support, Hood Medallion	18.130
Stop And Bracket, Rear Door Check Arm	30.132	Support, Instrument Board Gauge	30.412
Stop Pin, Exhaust Valve Heat Control Cover	5.015	Support, Oil Depth Gauge	2.415
Strainer, Carb. Accelerating Pump	3.640	Support, Prop. Shaft Center Bearing ..	11.008
Strainer, Carb. Bowl	3.660	Support, Radiator Grille Bar	6.490
Strainer, Carb. Bowl	3.640	Support, Radio Speaker (Eight Tube) ..	30.410
Strainer, Carb. Pump	3.660	Support, Radio Speaker (Six Tube)	30.412
Strap, Engine Ground	1.030	Support, Rear Bumper	20.252
Strap, Hydraulic Pump	30.906	Support, Rear License Plate Bracket ..	20.115
Strap, Oil Filter	2.300	Support, Rear Seat Front	30.556
Strap, Seat Back Hold	30.556	Support, Rear Seat Rear	30.560
Striker, Deck Lid Latch Lower	30.074	Support, Rear Window Lift	30.218
Strip, Trim Tacking	30.612	Support, Shock Absorber Cushion	20.004
Strut, Clutch Pressure Plate Lever ..	8.104	Support, Steering Gear Support Bracket	14.121
Stud, Air Conditioner Switch Knob ...	40.002	Support, Steering Knuckle	13.008
Stud, Carb. Extension Shaft Bellcrank ..	3.450	Support, Storage Battery	7.500
Stud, Carb. Mounting	3.640	Support, Top Control Rod	30.908
Stud, Carb. Mounting	3.660	Support, Top Operating Cylinder	30.904
Stud, Courtesy Light Dummy Knob Mounting	7.644	Support, Upper Deck Lid	30.064
Stud, Cylinder Head Water Outlet Elbow	6.425	Support, Ventilator And Heater Control	30.410
Stud, Defroster Control	40.008	Support, Window Lift Vacuum Pump	30.912
Stud, Distributor Mounting Adapter ..	7.342	Switch, Air Conditioner	40.002
Stud, Exhaust Manifold	5.000	Switch, Back-Up Light	40.108
Stud, Exhaust Pipe	5.040	Switch, Courtesy Light	7.644
Stud, Folding Top Frame to Rear Female Hinge	30.902	Switch, Directional Signal Light	7.620
Stud, Folding Top Quarter Panel Fastener	30.632	Switch, Directional Signal Light	40.142
Stud, Front Door Vent Frame	30.206	Switch, Dome Light	30.706
Stud, Front Seat Frame	30.616	Switch, Fog Light	40.112
Stud, Front Wheel Brake Drum	16.006	Switch, Glove Compartment Light	30.710
Stud, Fuel Pump	3.470	Switch, Headlight	7.553
Stud, Grille Guard	20.262	Switch, Headlight Dimmer	7.554
Stud, Hydraulic Pump Motor Terminal Ground	30.906	Switch, Hydraulic Pump Solenoid	30.902
Stud, Instrument Board Moulding	30.412	Switch, Ignition	7.350
Stud, Intake Manifold	3.000	Switch, Instrument Board	7.640
Stud, License Light Mounting	30.0702	Switch, Overdrive Kickdown	7.806
Stud, Oil Filter Mounting	2.300	Switch, Overdrive Rail	7.802
Stud, Oil Pump	2.200	Switch, Starting	7.270
Stud, Oil Return Tube	2.405	Switch, Stop Light	7.650
Stud, Rear Axle Brake Tube	15.078	Switch, Taxi Roof Sign	30.702
Stud, Rear Wheel Brake Drum	16.022	Switch, Window Lift	30.208
Stud, Tail Light	7.570	Swivel, Carb. Extension Shaft	3.450
Stud, Timing Chain Cover	1.610	Swivel, Front Door Vent. Upper Hinge ..	30.206
Stud, Valve Tappet Cover	1.750	Swivel, Trans. Overdrive Control Shaft Lever	9.261
Stud, Vent Control	30.034	Synchronizer Unit, Trans. Second and High	9.125
Stud, Water Temperature Control	40.002		T
Support, Air Scoop	17.000	Tank, Fuel	3.520
Support, Deck Lid	30.064	Tank, Windshield Washer	40.116
Support, Folding Top Female Hinge ...	30.902	Tappet, Valve	1.740
Support, Front Bumper	20.208	Tapping Plate, Front Suspension Lower Arm Bumper	13.022
Support, Front Shock Absorber	17.020	Tee, Intake Manifold to Vacuum Pump Tube	30.914
Support, Front Window Lift	30.208	Tee, Master Brake Cylinder Frame	15.062

ALPHABETICAL INDEX

NAME AND PART DESCRIPTION	GROUP NUMBER	NAME AND PART DESCRIPTION	GROUP NUMBER
Tee, Rear Axle Brake Tube	15.076	Thrustwasher, Trans. Gear Shift Rod Cross Shaft	9.342
Tee, Vacuum Antenna	40.102	Tie Rod, Steering	14.216
Tee, Window Lift Tube	30.910	Tie Rod Kit, Steering	14.216
Terminal, Air Conditioner Blower Feed Cable	40.002	Tie Rod Kit, Steering	60.14
Terminal, Body Wiring Harness	30.702	Tool Kit	20.300
Terminal, Chassis Wiring Harness	7.700	Top, Folding	30.632
Terminal, Cigar Lighter Cable	7.657	Transmission	9.000
Terminal, Courtesy Light Cable	7.646	Trim, Instrument Cluster Center	19.132
Terminal, Courtesy Light Socket, Seat Back	7.649	Trim, Instrument Cluster Center	19.122
Terminal, Courtesy Light Wiring Harness	7.648	Trip Lever, Carburetor Cam	3.660
Terminal, Directional Indicator Light Cable	7.637	Trough, Rear Compt. Drain	30.040
Terminal, Directional Signal Light Flasher Connector	7.635	Tube, Air Conditioner Blower	40.002
Terminal, Directional Signal Light Switch	7.620	Tube, Carburetor Choke	3.010
Terminal, Dome Light Cable	30.704	Tube, Dash To Top Control Valve	30.910
Terminal, Fuel Gauge Tank Unit Cable.	7.660	Tube, Distributor Vacuum Chamber	7.340
Terminal, Glove Compartment Light Cable	30.710	Tube, Door Hinge	30.914
Terminal, Headlight Beam Indicator Light Cable	7.556	Tube, Door Hinge Pillar	30.910
Terminal, Headlight Cable Connector..	7.546	Tube, Door Window Lift Hydraulic	30.910
Terminal, Horn Blowing Ring Cable ...	7.536	Tube, Door Window Lift Vacuum	30.914
Terminal, Instrument Lights Wiring Harness	7.643	Tube, Exhaust Manifold Heat Riser ...	5.000
Terminal, Window Lift Wiring Harness.	30.714	Tube, Fitting To Fuel Pump	3.550
Thermostat, Engine	6.410	Tube, Frame Tee To Front Brake Hose .	15.064
Thermostat, Exhaust Manifold Heat Control	5.010	Tube, Frame Tee To Rear Brake Hose ..	15.070
Throttle Valve, Carburetor	3.660	Tube, Fuel Pump To Carburetor	3.560
Thru Bolt, Generator Commutator End Plate	7.412	Tube, Fuel Pump To Windshield Wiper Tube	3.560
Thru Bolt, Starting Motor Commutator End Plate	7.234	Tube, Fuel Tank Filler	3.530
Thrustblock, Rear Axle Shaft	12.080	Tube, Fuel Tank To Fuel Pump Line ...	3.550
Thrustblock, Rear Axle Shaft	12.020	Tube, Intake Manifold To Vacuum Pump.	30.914
Thrustplate, Camshaft	1.500	Tube, Master Brake Cylinder To Frame Tee	15.060
Thrustplate, Camshaft	1.310	Tube, Master Cylinder To Front Brake Hose	15.064
Thrustwasher, Brake Pedal	15.102	Tube, Oil Filler	2.412
Thrustwasher, Clutch Pedal	8.140	Tube, Oil Filter Inlet	2.315
Thrustwasher, Crankshaft	1.310	Tube, Oil Filter Outlet	2.316
Thrustwasher, Distributor Drive Shaft	7.324	Tube, Oil Pressure Gauge Engine Unit.	2.440
Thrustwasher, Hydraulic Pump Motor Armature	30.906	Tube, Oil Pressure Gauge	2.425
Thrustwasher, Prop. Shaft Joint	11.037	Tube, Oil Return	2.405
Thrustwasher, Rear Axle Differential.	12.020	Tube, Radiator Outlet	6.420
Thrustwasher, Starting Motor Armature	7.224	Tube, Rear Axle Brake	15.078
Thrustwasher, Steering Gear Shaft and Roller	14.116	Tube, Robe Rail Cord	30.628
Thrustwasher, Trans. Countershaft Gear Cluster	9.155	Tube, Trans. Gear Shift	9.310
Thrustwasher, Trans. Gear Shift Rod Bellcrank	9.345	Tube, Vacuum Pump To Manifold	3.560
		Tube, Vacuum Pump To Windshield Wiper	3.560
		Tube, Water Temperature Control To Engine	40.002
		Tube, Windshield Wiper	30.364
		U	
		"U" Bolt, Rear Spring	12.215
		"U" Bolt, Steering Gear Support	14.121
		Upright, Radiator Grille And Rear Deck Guard	40.143
		Upright, Radiator Grille And Rear Deck Guard	40.142
		Utility Light Demonstrator	40.110

ALPHABETICAL INDEX

NAME AND PART DESCRIPTION	GROUP NUMBER	NAME AND PART DESCRIPTION	GROUP NUMBER
V			
Valance, Front Seat	30.616	Weatherseal, Front Door Lock Facing Upper Corner	30.102
Valance, Rear Seat	30.620	Weatherseal, Front Door Upper Corner.	30.102
Valve, Carburetor Choke	3.640	Weatherseal, Rear Door To Quarter Panel	30.120
Valve, Carburetor Choke	3.660	Weatherseal, Rear Wheel Shield	30.057
Valve, Carburetor Throttle	3.640	Weatherseal, Wheel Housing Baffle ...	30.040
Valve, Exhaust	1.720	Weatherseal, Windshield Division Bar.	30.094
Valve, Exhaust Manifold Heat Control.	5.010	Weatherstrip, Center Pillar Glass ...	30.201
Valve, Hydraulic Pump	30.906	Weatherstrip, Cowl Upper Pillar Drain Trough	30.102
Valve, Intake	1.720	Weatherstrip, Deck Lid	30.062
Valve, Master Brake Cylinder Check...	15.035	Weatherstrip, Front Bow	30.902
Valve, Oil Pressure Relief	2.410	Weatherstrip, Front Door	30.102
Valve, Top Control	30.908	Weatherstrip, Front Door Glass	30.204
Valve, Vacuum Antenna	40.102	Weatherstrip, Front Door Roof Side Rail	30.102
Valve, Water Temperature Control Heater	40.002	Weatherstrip, Front Door Vent	30.206
Valve, Windshield Washer Control	40.116	Weatherstrip, Rear Door	30.120
Ventilator, Front Door	30.206	Weatherstrip, Rear Door Glass	30.212
Ventilator, Rear Door	30.216	Weatherstrip, Rear Door Roof Side Rail	30.120
W		Weatherstrip, Rear Door Vent	30.216
Washer, Brake Pedal	15.102	Weatherstrip, Rear Floor Pan Extension	30.058
Washer, Carb. Choke Shaft	3.660	Weatherstrip, Rear Window	30.088
Washer, Carb. Throttle Shaft Dog	3.660	Weatherstrip, Rear Window Glass	30.502
Washer, Clutch Pedal Cross Shaft	8.155	Weatherstrip, Windshield	30.302
Washer, Distributor Vacuum Chamber ...	7.338	Weatherstrip, Windshield Division Bar	30.094
Washer, Folding Top Back Curtain	30.632	Weatherstrip Set, Front Door	30.102
Washer, Front Door Vent Handle Shaft Spring	30.206	Weatherstrip Set, Front Door	60.30
Washer, Hood Lock Control	18.154	Weatherstrip Set, Rear Door	30.120
Washer, Horn Blowing Ring Insulating.	7.534	Weatherstrip Set, Rear Door	60.30
Washer, Horn Blowing Ring Insulating.	7.533	Wedge, Front Door Bumper	30.132
Washer, Hydraulic Pump Valve	30.906	Wedge, Rear Door Bumper	30.112
Washer, Hydraulic Switch Terminal Stud Outer Insulator	30.208	Well, Folding Top	30.632
Washer, License Light Mounting Support	30.070	Welt, Front Seat Frame	30.616
Washer, Oil Depth Gauge	2.415	Welt, Instrument Board	30.402
Washer, Oil Pressure Relief Valve ...	2.410	Wheel	16.000
Washer, Rear Door Vent Handle Shaft Spring	30.216	Wheel, Steering	14.126
Washer, Roof Sign Mounting Screw	30.716	White Sidewall Tire Cleaner	40.134
Washer, Spare Tire Cover Clamp Bolt .	30.607	Wick, Distributor	7.302
Washer, Steering Idler Lever Bushing.	14.214	Windbreak, Rear Compartment	30.611
Washer, Trans. Countershaft Gear Bearing	9.160	Wing Bolt, Rear Seat Back Hinge	30.560
Washer, Water Pump	6.300	Wing Nut, Air Cleaner	4.000
Washer, Package, Windshield	40.116	Wing Nut, Spare Wheel Mounting	16.030
Weathercord, Front Door Opening	30.604	Wing Stud, Air Cleaner	4.000
Weathercord, Rear Deck Opening	30.6085	Wings, Air Vent	40.135
Weathercord, Rear Door Opening	30.608	Wiring Package, Back-Up Light	40.108
Weatherseal, Center Pillar Glass	30.201	Wrench, Wheel Bolt	20.300
		Y	
		Yoke, Folding Top Operating Cylinder.	30.904
		Yoke, Hand Brake Front Cable	15.220

NOTES

BUILD



OWNER

CONFIDENCE...

WITH

*Factory Approved
and Inspected
Parts and Accessories*

