



**1951**

**FRAZER**

**PRELIMINARY**

*Combined* CHASSIS and BODY

**PARTS  
LIST**

*Models*

**F515**

**F516**

ISSUED MARCH, 1950

**KAISER-FRAZER SALES CORPORATION**

**KAISER-FRAZER CORPORATION**

**WILLOW RUN, MICHIGAN, U.S.A.**



1951



*FRAZER*

PRELIMINARY

*Combined*  
CHASSIS and BODY

**PARTS  
LIST**

*Models*

**F515**

**F516**

ISSUED MARCH, 1950

**KAISER-FRAZER SALES CORPORATION**

KAISER-FRAZER CORPORATION  
WILLOW RUN, MICHIGAN, U.S.A.

#25  
#35  
C1930  
**QUICK REFERENCE INDEX**  
BEND BACK PAGES TO FIND GROUP INDEX

PAGE NO.	GROUP and NAME
II	GENERAL INFORMATION
1	1 ENGINE
7	2 ENGINE LUBRICATION
10	3 FUEL
16	4 AIR INTAKE
17	5 EXHAUST
19	6 COOLING
22	7 ELECTRICAL
37	8 CLUTCH and CONTROLS
39	9 TRANSMISSION and CONTROLS
47	11 DRIVE SHAFT
49	12 REAR AXLE and SUSPENSION
52	13 FRONT SUSPENSION
55	14 STEERING
59	15 BRAKES
66	16 WHEELS
67	17 FRAME
68	18 SHEET METAL
72	19 INSTRUMENTS
74	20 CHASSIS MISC.
77	30 BODY
132	40 ACCESSORIES
139	NUMERICAL INDEX

## GENERAL INFORMATION

This Preliminary Parts List is issued for your convenience in locating, identifying, specifying and ordering replacement parts for Frazer Models F515 and F516. Body types are identified by the numerals 1, 2 and 5, and when combined with Model numbers, represent not only the 1951 Model but the body type as well. These numerals, designating body types, will be found on the Body Number Plate secured to the dash underneath the hood. For example, when the numeral "1" is shown following the model number, it indicates that the body type is a 4-door sedan. Therefore, a 1951 Frazer 4-door sedan would be identified as F5151. Body type numerals used on 1951 Frazer Models are as follows:

1 - 4-Door Sedan      2 - Convertible      5 - 4-Door Utility

A numerical index indicating the part number and group in which they appear and containing all replacement parts found in this Parts List will be found in the back of this book.

### LOCATION OF CAR SERIAL, BODY AND ENGINE NUMBERS

Car Serial Number:      Left front door hinge pillar post.

Engine Number:      Left side of engine stamped in block at upper front; also on plate attached to left side center of crankcase.

Body Number:      On left side of cowl or on the front of dash (right side) under the hood.

### ENGINE SUFFIX LETTERS

Letters used as suffixes in connection with engine numbers denote the following:

"A"      Designates .010 undersize main and rod bearings.

"N"      Designates .020 oversize pistons.

"AN"      Designates .010 undersize main and rod bearings and .020 oversize pistons.

Engines manufactured at the Detroit plant carry the numeral "4" following the engine model designation. Engines manufactured at the Muskegon plant carry the numeral "8" following the engine model designation.

For complete information regarding the ordering of parts refer to the 1949 Illustrated Combined Chassis and Body Parts List dated May, 1949.

### IMPORTANT NOTICE

---

GROUP NUMBERS SHOULD NEVER BE USED FOR ORDERING PARTS.  
ORDER BY PART NUMBER ONLY.

---