



FIGURE 16-1 — TYPICAL FRONT WHEEL AND BEARINGS - EXPLODED VIEW

KEY	PART NAME	GROUP	KEY	PART NAME	GROUP
1	Cap, Grease	16.010	6	Cup, Outer	16.010
2	Cotter Pin	16.002	7	Cup, Inner	16.010
3	Nut	16.002	8	Cone, Inner	16.010
4	Flatwasher	16.002	9	Seal, Inner	16.010
5	Cone, Outer	16.010	10	Knuckle, Steering	13.000




FIGURE 16-2 — TYPICAL WHEEL WITH HUB, DRUM AND HUB CAPS - EXPLODED VIEW

KEY	PART NAME	GROUP	KEY	PART NAME	GROUP
1	Hub and Drum Assembly	16.002	5	Cover and Disc (One Piece)	16.028
2	Wheel	16.000	6	Rivet	16.026
3	Bolt, Wheel	16.000	7	Clip, Spring	16.026
4	Cap, Hub	16.026			

FIGURE NUMBER	GROUP, PART NAME and DESCRIPTION	PART NUMBER	USED PER CAR MODEL	
			511	512
	16.000 - WHEELS			
16-2-2	Wheel (15")	203258	5	5
	Wheel (16") (Export)	203308	5	5
16-2-3	Bolt, R.H. Thd.	203121	20	20
	16.002 - FRONT WHEEL HUB AND DRUM			
16-2-1	Hub and Drum (with Tapped Holes for Wheel Mounting Bolts)	204633	2	2
16-1-4	Flatwasher	201166	2	2
16-1-3	Nut, 3/4"-16 Hx. Sl.	436	2	2
16-1-2	Cotter Pin, 1/8"	496	2	2
	16.010 - FRONT WHEEL BEARINGS			
16-1-8	Bearing Cone, Inner	204634	2	2
16-1-7	Bearing Cup, Inner	204635	2	2
16-1-5	Bearing Cone, Outer	204636	2	2
16-1-6	Bearing Cup, Outer	204637	2	2
16-1-9	Seal, Inner	204638	2	2
16-1-1	Cap, Grease	201151	2	2
	16.020 - REAR WHEEL HUB AND DRUM			
	Hub and Drum (with Tapped Holes for Wheel Mounting Bolts)	207340	2	2
	Key, 2 3/8" Long x 7/32" x 7/32"	207238	2	2
	Flatwasher, 29/32" I.D. x 1 9/16" O.D.	207239	2	2
	Nut, 7/8"-14 Hx. (1 5/16" Across Flats)	207240	2	2
	Cotter Pin, 1/8"	496	2	2
	16.026 - WHEEL HUB CAP OR COVER			
	Cap "K", up to Serial 511-2399	204658	4	
16-2-4	Cap "K", after Serial 511-2399	208525	4	4
16-2-7	Clip, Spring	203262	25	25
16-2-6	Rivet	203263	25	25
	16.028 - WHEEL TRIM RING (FOR SETS SEE GROUP 40.122)			
	"Donut" Disc	205728	*	*
16-2-5	Cover and Disc (One Piece)	208601	*	*
	16.030 - SPARE TIRE HOLD DOWN CLAMP			
	Clamp	204656	1	1
	Bolt	208602	1	1

* As Required