

ALPHABETICAL INDEX

NAME AND PART DESCRIPTION	GROUP NUMBER	NAME AND PART DESCRIPTION	GROUP NUMBER
A			
Access Cover, Front Fender Splash Shield	18.010	Armature, Generator	7.402
Adapter, Distributor Mounting	7.342	Armature, Starting Motor	7.224
Adapter, Heater Temperature Control Valve Tube	40.002	Ash Receiver, Front Seat Back	30.806
Adapter, Overdrive Housing	9.145	Ash Receiver, Instrument Board	30.406
Adapter, Master Brake Cylinder Outlet Fitting	15.035	Ash Receiver, Rear Quarter	30.807
Adapter, Water Temperature Gauge to Cylinder Block	6.444	Auto Cleaner and Wax	40.134
Adapter Ring, Engine Thermostat	6.410	Auto Polish and Cleaner	40.134
Adjuster, Front Seat Track	30.554	Axle, Rear	12.000
Adjusting Link, Steering Drag Link	14.202	B	
Air Conditioner Package	40.002	Back-Up Light Package	40.108
Air Duct, Heater	40.002	Baffle, Transmission Main Shaft Bearing	9.140
Air Horn and Climatic Control Assembly, Carburetor	3.680	Baffle, Valve Chamber Oil	1.750
Air Horn and Piston Housing Assembly, Carburetor	3.680	Baffle Plate, Carburetor	3.680
Alcohol, Anti-Freeze	40.146	Ball, Transmission Shifting Lever Poppet	9.190
Ammeter	19.110	Ball Stud, Rear Seat Back	30.560
Anchor, Hydra-Matic Reverse Shifter	9.695	Band, Generator Cover	7.420
Antenna, Radio	40.102	Band, Starting Motor Cover	7.238
Antenna Conversion Kit, Radio	40.102	Band and Lining, Hydra-Matic Front Clutch Servo	9.580
Anti-Freeze, Permanent	40.146	Band and Lining, Hydra-Matic Rear Clutch Servo	9.625
Anti-Squeak, Front Door Hinge	30.108	Bar, Front Bumper	20.200
Anti-Squeak, Fuel Tank	3.520	Bar, Front Door Ventilator Division	30.206
Anti-Squeak, Hand Brake Lever Cover Panel	30.412	Bar, Front Sway Eliminator	13.200
Anti-Squeak, Hood	18.100	Bar, Quarter Panel Window Glass Division	30.216
Anti-Squeak, Hood Lock Bolt Plate	18.148	Bar, Radiator Grille	6.490
Anti-Squeak, Hood Lock Latch	18.150	Bar, Rear Bumper	20.250
Anti-Squeak, Instrument Board	30.402	Bar, Rear Door Ventilator Division	30.216
Anti-Squeak, Instrument Board Heater Control Panel	30.412	Bar, Windshield Division, Inner	30.306
Anti-Squeak, Rear Door Hinge	30.126	Bar, Windshield Division, Outer	30.094
Anti-Squeak, Steering Gear Support Rod	14.120	Base, Distributor	7.302
Anti-Squeak, Tire Well Cover	30.058	Base, Hood Ornament	18.110
Arm, Carburetor Throttle Shaft	3.680	Base, Jack	20.300
Arm, Distributor Advance	7.308	Base and Clamp, Cigar Lighter	7.652
Arm, Front Door Check	30.112	Base Strip, Moulding Clip	30.099
Arm, Front Suspension Lower	13.018	Bearing, Camshaft	1.510
Arm, Front Suspension Upper	13.014	Bearing, Clutch Release	8.120
Arm, Generator Brush	7.420	Bearing, Connecting Rod	1.405
Arm, Rear Door Check	30.132	Bearing, Crankshaft Main	1.315
Arm, Rear Window Wiper	40.162	Bearing, Crankshaft Pilot	1.300
Arm, Steering Gear Lever Pitman	14.200	Bearing, Front Door Handle	30.114
Arm, Steering Knuckle	13.006	Bearing, Generator Drive End Plate	7.428
Arm, Windshield Wiper	30.360	Bearing, Hydra-Matic Rear Clutch Servo Band Actuating Lever	9.625
Arm and Bracket, Sun Visor Panel	30.626	Bearing, Hydra-Matic Reverse Unit Shaft	9.685
Arm and Screw, Carburetor Metering Rod	3.680	Bearing, Overdrive Free Wheeling Cam Roller	9.230
Arm and Screw, Carburetor Pump	3.680	Bearing, Overdrive Main Shaft	9.240
Arm and Shaft, Brake Pedal	15.102	Bearing, Rear Door Handle	30.134
Arm Rest, Door	30.614	Bearing, Starting Motor Drive Housing	7.242
Arm Rest, Rear Quarter	30.6101	Bearing, Steering Column Jacket	14.108
		Bearing, Steering Drag Link End Socket	14.206
		Bearing, Steering Idler Lever	14.212

ALPHABETICAL INDEX

NAME AND PART DESCRIPTION	GROUP NUMBER	NAME AND PART DESCRIPTION	GROUP NUMBER
Bearing, Steering Knuckle King Pin Thrust	13.004	Body, Headlight	7.540
Bearing, Transmission Countershaft Gear Roller	9.160	Body, Hood Ornament	18.110
Bearing, Transmission Drive Pinion	9.105	Body, Hydra-Matic Front Servo	9.585
Bearing, Transmission Main Shaft	9.140	Body, Hydra-Matic Front Servo Exhaust	9.710
Bearing, Transmission Main Shaft Roller	9.120	Body, Hydra-Matic Rear Servo	9.630
Bearing Cone, Front Wheel	16.010	Body, Hydra-Matic Rear Servo Accumulator Check Valve	9.640
Bearing Cone, Rear Axle Differential	12.035	Body, Oil Pump	2.205
Bearing Cone, Rear Axle Pinion, Front	12.050	Body, Rear Brake Cylinder	15.018
Bearing Cone, Rear Axle Pinion - Rear	12.060	Body, Tail Light	7.571
Bearing Cone, Rear Axle Shaft	12.080	Body, Water Pump	6.300
Bearing Cup, Front Wheel	16.010	Body Flange, Carburetor	3.680
Bearing Cup, Rear Axle Differential	12.035	Bolt, Battery Cable	7.510
Bearing Cup, Rear Axle Pinion, Front	12.050	Bolt, Body Hold Down	30.012
Bearing Cup, Rear Axle Pinion, Rear	12.060	Bolt, Clutch Pressure Plate	8.104
Bearing Cup, Rear Axle Shaft	12.080	Bolt, Connecting Rod	1.400
Bearing and Sleeve, Clutch Release	8.120	Bolt, Crankshaft Bearing Front Filler Block	1.325
Bellcrank, Hydra-Matic Throttle Control Lower	9.805	Bolt, Crankshaft Main Bearing Cap	1.320
Bellcrank, Hydra-Matic Throttle Control Upper	9.795	Bolt, Cylinder Block Front End Plate	1.105
Bellcrank, Rear Door Locking Rod	30.122	Bolt, Deck Lid Prop	30.064
Belt, Fan	6.000	Bolt, Deck Lid Support Link	30.064
Bendix Drive, Starting Motor	7.244	Bolt, Flywheel to Crankshaft	1.360
Bezel, Back-Up Light Lens	40.108	Bolt, Front Brake Cylinder	15.010
Bezel, Hand Brake Lever Cover Panel	30.412	Bolt, Front Brake Support Plate	15.000
Bezel, Headlight Switch	7.553	Bolt, Front Bumper Bar	20.200
Bezel, Heater Blower Switch	40.002	Bolt, Front Bumper Bar Wing	20.260
Bezel, Horn Blowing	7.527	Bolt, Front Door Handle Anchor Bracket "J"	30.114
Bezel, Ignition Switch	7.350	Bolt, Front Seat Back Ash Receiver	30.806
Bezel, Instruments	19.100	Bolt, Front Seat Back Cushion Frame	30.616
Bezel, Instrument Cluster	30.412	Bolt, Front Seat Back Stop Adjusting	30.616
Bezel, Parking Light	7.563	Bolt, Front Suspension Lower Arm Inner Pivot	13.020
Bezel, Spotlight	40.104	Bolt, Hood Lock Bolt Plate	18.148
Bezel, Windshield Wiper Control	30.354	Bolt, Hydra-Matic Parking Brake Pawl	9.695
Binding, Headlining Wire-On	30.612	Bolt, Hydra-Matic Reverse Shifter Anchor	9.695
Binding, Rear Deck Wire-On	30.6125	Bolt, Hydra-Matic Torus Cover	9.505
Black Rubber Finish	40.134	Bolt, License Light Hinge	30.0702
Blade, Clutch Release Bearing	8.120	Bolt, Master Brake Cylinder	15.035
Blade, Rear Window Wiper	40.162	Bolt, Overdrive Control to Lever	9.270
Blade, Windshield Wiper	30.360	Bolt, Overdrive Housing	9.200
Bleeder Valve, Front Brake Cylinder	15.016	Bolt, Overdrive Main Shaft Slip Joint Housing	9.247
Bleeder Valve, Rear Brake Cylinder	15.018	Bolt, Radiator Mounting	6.400
Block, Crankshaft Bearing Front Filler	1.325	Bolt, Rear Axle Differential Case	12.015
Block, Crankshaft Bearing Rear Filler	1.326	Bolt, Rear Axle Drive Gear and Pinion	12.045
Block, Cylinder	1.100	Bolt, Rear Axle Housing Cover	12.005
Block, Headlight Cable Terminal	7.550	Bolt, Rear Axle Shaft Oil Seal	12.080
Block, Instrument Panel Wiring Junction	7.642	Bolt, Rear Brake Cylinder	15.012
Blocking Ring, Overdrive Stationary Gear	9.205	Bolt, Rear Brake Support Plate	15.002
Blocking Ring, Transmission Second and High Synchronizer Sleeve	9.130	Bolt, Rear Bumper Bar	20.250
Blower, Heater	40.002	Bolt, Rear Door Handle Anchor Bracket "J"	30.134
Board, Instrument	30.402	Bolt, Rear Seat Back Outer Hinge Pivot	30.560
Body, Front Brake Cylinder	15.016	Bolt, Rear Seat Cushion Panel Hinge	30.556
Body, Front Seat Back Ash Receiver	30.806		

ALPHABETICAL INDEX

NAME AND PART DESCRIPTION	GROUP NUMBER	NAME AND PART DESCRIPTION	GROUP NUMBER
Bolt, Spare Tire Hold Down Clamp	16.030	Bracket, Ignition Switch	7.350
Bolt, Steering Drag Link	14.202	Bracket, Instrument Cluster Mounting	19.100
Bolt, Steering Drag Link Clamp	14.206	Bracket, Oil Filter	2.300
Bolt, Steering Gear Housing End Cover	14.104	Bracket, Overdrive Control to Transmission	9.270
Bolt, Steering Gear Shaft Cover	14.118	Bracket, Package Compartment Lower Panel	30.562
Bolt, Steering Knuckle Arm	13.006	Bracket, Quarter Panel Window Glass Division Bar	30.216
Bolt, Steering Tie Rod Clamp	14.216	Bracket, Radiator Cradle to Fender	6.455
Bolt, Wheel	16.000	Bracket, Radiator Grille to Stone Deflector	6.490
Bolt with L/W, Distributor	7.300	Bracket, Radiator Mounting	17.025
Bolt with L/W, Hood Lock Bolt Plate	18.148	Bracket, Rear Door Check Arm Pivot	30.132
Bolt with L/W, Hood Lock Latch Plate	18.150	Bracket, Rear Door Handle Anchor	30.134
Bolt with L/W, Hydra-Matic Case Side Cover	9.510	Bracket, Rear License Plate	20.115
Bolt with L/W, Gear Shift Lever Housing Cover	9.320	Bracket, Rear Seat Back Filler Panel Spring	30.560
Bolt with L/W, Gear Shift Upper Bracket	9.310	Bracket, Spotlight	40.104
Bolt with L/W, Oil Pan	2.400	Bracket, Steering Gear Jacket Cover	14.122
Bolt with L/W, Oil Return Tube	2.405	Bracket, Tail Light Mounting, Lower	30.040
Bolt with L/W, Steering Gear Support	14.120	Bracket, Windshield Washer	40.116
Bolt with L/W, Windshield Wiper Arm Pivot Clamp	30.358	Bracket, Windshield Wiper Motor	30.352
Boot, Accelerator Pedal	3.070	Bracket and Crank, Hydra-Matic Reverse Shifter	9.695
Boot, Front Brake Cylinder	15.020	Bracket, Crank and Lever, Hydra-Matic Parking Brake	9.695
Boot, Master Brake Cylinder	15.035	Breaking Tool, Moulding Clip	30.099
Boot, Overdrive Governor	9.265	Breather, Oil Filler Tube	2.412
Boot, Rear Brake Cylinder	15.030	Brush, Generator	7.420
Bow, Headlining	30.612	Brush, Starting Motor	7.236
Bowl, Fuel Filter	3.555	Bulb, Back-Up Light	40.108
Box, Instrument Board Glove	30.404	Bulb, Clock Lighting	40.136
Brace, Hood Lock Latch Support Plate	18.147	Bulb, Directional Indicator Light	7.637
Brace, Instrument Board Heater Control Panel	30.412	Bulb, Glove Compartment Light	30.710
Brace, Radiator Cradle Tie	6.455	Bulb, Headlight Beam Indicator Light	7.556
Bracket, Accelerator Extension Shaft	3.450	Bulb, Hydra-Matic Gear Shift Lever Indicator	9.745
Bracket, Accelerator Pedal to Floor	3.070	Bulb, Instrument Lights	7.643
Bracket, Air Cleaner Support	4.060	Bulb, License Light	30.0702
Bracket, Back-Up Light Switch	40.108	Bulb, Parking Light	7.564
Bracket, Deck Lid Support Cable	30.074	Bulb, Pillar Light	30.707
Bracket, Deck Lid Support Locking	30.064	Bulb, Rear Compartment Light	40.152
Bracket, Directional Signal Light Flasher	7.635	Bulb, Tail Light	7.574
Bracket, Front Door Check Arm Pivot	30.112	Bumper, Brake Pedal Arm and Shaft	15.102
Bracket, Front Door Handle Anchor	30.114	Bumper, Clutch Pedal	8.140
Bracket, Front Door Ventilator Upper Pivot	30.206	Bumper, Deck Lid Side	30.062
Bracket, Front License Plate	20.100	Bumper, Floor Pan Differential Housing	30.058
Bracket, Fuel Tank	3.520	Bumper, Front Suspension Lower Arm	13.022
Bracket, Fuel Tank Filler Pipe Housing	30.040	Bumper, Fuel Tank	3.520
Bracket, Gear Shift Upper Shaft	9.310	Bumper, Fuel Tank Filler Cover	30.040
Bracket, Generator Mounting	7.465	Bumper, Hood	18.100
Bracket, Generator Voltage Regulator	7.470	Bumper, Instrument Board Glove Box	30.404
Bracket, Hand Brake Front Cable	15.218	Bumper, License Light Brace	30.0702
Bracket, Horn	7.520	Bumper, Package Compartment Panel to Floor	30.562
Bracket, Hydra-Matic Gear Shift Lower	9.760	Bumper, Rear Seat Back Ball Stud	30.560
Bracket, Hydra-Matic Gear Shift Upper	9.755		
Bracket, Hydra-Matic Throttle Control Lower Bellcrank	9.805		
Bracket, Ignition Coil Mounting	7.346		

ALPHABETICAL INDEX

NAME AND PART DESCRIPTION	GROUP NUMBER	NAME AND PART DESCRIPTION	GROUP NUMBER
Bumper, Rear Spring (or Axle)	12.230	Cable, Spark Plug	7.360
Bumper, Steering Drag Link End Socket . . .	14.206	Cable, Starting Motor Solenoid	7.265
Bushing, Clutch Pedal Shaft	8.145	Cable, Ventilator Control	30.034
Bushing, Connecting Rod	1.400	Cable, Windshield Wiper Switch Feed	30.366
Bushing, Crankshaft Pilot	1.300	Cable and Housing, Hydra-Matic Speedometer	9.730
Bushing, Directional Indicator Light Socket.	7.637	Cable and Housing, Speedometer	9.282
Bushing, Distributor Base	7.302	Cable and Socket, Glove Compartment Light	30.710
Bushing, Distributor Terminal	7.300	Cable and Socket, License Light	30.0702
Bushing, Exhaust Manifold Heat Control . . .	5.010	Cage, Overdrive Stationary Gear Pinion . . .	9.220
Bushing, Front Suspension Lower Arm	13.018	Cam, Brake Shoe Adjusting	15.000
Bushing, Front Suspension Lower Arm Outer Pivot	13.012	Cam, Carburetor Fast Idle	3.680
Bushing, Front Suspension Upper Arm	13.014	Cam, Deck Lid Lock	30.074
Bushing, Front Suspension Upper Arm Outer Pivot	13.010	Cam, Overdrive Free Wheeling	9.225
Bushing, Headlight Beam Indicator Light Socket	7.556	Cam and Shaft, Distributor	7.332
Bushing, Hydra-Matic Gear Shift Lower Lever	9.770	Camshaft	1.500
Bushing, Instrument Lights Socket	7.643	Cap, Distributor	7.302
Bushing, Oil Pump	2.200	Cap, Front Wheel Grease	16.010
Bushing, Oil Pump Body	2.205	Cap, Fuel Tank	3.520
Bushing, Oil Pump Shaft	2.200	Cap, Oil Filler Tube	2.412
Bushing, Rear Shock Absorber	20.010	Cap, Radiator Filler	6.400
Bushing, Rear Spring Front	12.200	Cap, Rear Belt Moulding	30.086
Bushing, Rear Spring Shackle	12.220	Cap, Wheel Hub	16.026
Bushing, Starting Motor Drive Housing . . .	7.242	Carburetor	3.680
Bushing, Steering Gear Housing	14.102	Carpet, Floor	30.630
Bushing, Steering Knuckle King Pin	13.002	Carrier, Hydra-Matic Front Planet	9.560
Bushing, Transmission Drive Pinion	9.100	Case, Hydra-Matic	9.510
Bushing, Transmission Main Shaft Bearing Retainer	9.145	Case, Rear Axle Differential	12.015
Bushing, Transmission Reverse Idler Gear.	9.170	Case, Transmission	9.005
Button, Front Door Ventilator Handle	30.206	Catch, Hood Lock Safety	18.152
Button, Rear Door Ventilator Handle	30.216	Catch, Rear Seat Back Ball Stud	30.560
Button Plug, Overdrive Kickdown Switch . .	7.806	Catch, Rear Wheel Opening Cover	30.0911
C		Chain, Timing	1.605
"C" Washer, Overdrive Shift Fork	9.250	Chamber, Distributor Vacuum	7.334
Cable, Battery Ground	7.510	Channel, Front Door Glass	30.202
Cable, Battery to Starter Solenoid	7.510	Channel, Instrument Board Radio Control Cover Retaining	30.410
Cable, Cigar Lighter Feed	7.657	Channel, Quarter Panel Glass	30.210
Cable, Deck Lid Support	30.074	Channel, Rear Door Glass	30.210
Cable, Fuel Gauge Tank Unit	7.660	Check Ball, Carburetor Pump Intake	3.680
Cable, Hand Brake Front	15.218	Check Valve, Hydra-Matic Torus	9.505
Cable, Hand Brake Rear	15.236	Check Valve and Rivet, Hydra-Matic Rear Servo Accumulator	9.640
Cable, Headlight	7.546	Chrome Coating	40.134
Cable, Heater Blower Switch Feed	40.002	Chrome Polish	40.134
Cable, Heater Defroster Control	40.008	Circuit Breaker, Headlight Switch	7.553
Cable, Heater Water Temperature Control . .	40.002	Clamp, Air Cleaner	4.000
Cable, Horn Blowing Ring	7.536	Clamp, Air Duct	30.034
Cable, Hydra-Matic Gear Shift Lever Indicator	9.745	Clamp, Distributor Breaker Upper Plate . .	7.310
Cable, Ignition	7.360	Clamp, Exhaust Pipe Hanger	5.050
Cable, Overdrive Rail Switch to Governor . .	7.810	Clamp, Exhaust Pipe to Muffler	5.055
Cable, Parking Light	7.568	Clamp, Fuel Tank Filler Hose	3.530
		Clamp, Gear Shift Lever Housing	9.320
		Clamp, Gear Shift Upper to Lower Shaft . . .	9.310
		Clamp, Generator Voltage Regulator Terminal Screw	7.470

ALPHABETICAL INDEX

NAME AND PART DESCRIPTION	GROUP NUMBER	NAME AND PART DESCRIPTION	GROUP NUMBER
Clamp, Heater Blower Seal	40.002	Clip, Master Brake Cylinder to Rear Brake Hose Tube	15.070
Clamp, Heater Hose	40.002	Clip, Master Brake Cylinder Tube to Frame Tee	15.060
Clamp, Ignition Coil Terminal	7.346	Clip, Oil Return Tube	2.405
Clamp, Radiator Hose	6.420	Clip, Overdrive Free Wheeling Cam	9.225
Clamp, Spare Tire Hold Down	16.030	Clip, Overdrive Wiring Harness	7.812
Clamp, Steering Drag Link	14.202	Clip, Parking Light Cable	7.568
Clamp, Steering Gear Jacket	14.122	Clip, Pump to Wiper Hose Tube	30.364
Clamp, Steering Gear Support	14.120	Clip, Quarter Panel Extension Moulding	30.0911
Clamp, Steering Tie Rod	14.216	Clip, Quarter Panel Rub Rail Moulding	40.154
Clamp, Tail Pipe to Muffler	5.070	Clip, Rear Axle Brake Tube	15.078
Clamp, Tail Pipe to Support	5.075	Clip, Rear Brake Hose Spring	15.074
Clamp, Windshield Wiper Arm Pivot	30.358	Clip, Rear Door Garnish Moulding Weatherstrip	30.119
Clamp and Strap, Tail Pipe Rear Support	5.080	Clip, Rear Door Glass Run	30.212
Cleaner, Air	4.000	Clip, Rear Door Regulator to Channel	30.218
Cleaner, Fabric	40.134	Clip, Rear Wheel Opening Cover Catch	30.0911
Cleaner, Glass	40.134	Clip, Rear Window Garnish Moulding	30.503
Cleaner, White Side Wall	40.134	Clip, Rear Window Reveal Moulding Joint	30.0915
Clevis, Hand Brake Front Cable	15.222	Clip, Rub Rail Moulding	30.0911
Clevis Pin, Clutch Pedal Cross Shaft Coupling	8.155	Clip, Speedometer Cable	9.282
Clevis Pin, Clutch Pedal Shaft Adjusting Link	8.145	Clip, Switch Wiring Harness	30.702
Clevis Pin, Deck Lid Lock Lever	30.074	Clip, Tire Well Cover Hold Down	30.058
Clevis Pin, Deck Lid Support Cable	30.074	Clip, Vacuum Pump Tube to Manifold Stud	3.560
Clip, Accelerator Adjusting Rod	3.435	Clip, Wheel Hub Cap Spring	16.026
Clip, Accelerator Pedal Pivot Pin	3.070	Clip, Window Reveal Moulding	30.0915
Clip, Accelerator Pedal Rod	3.085	Clip, Windshield Reveal Moulding Joint	30.0915
Clip, Air Duct Cable Support	30.034	Clip, Windshield Wiper Arm Pivot Link	30.358
Clip, Battery Retainer	7.500	Clock Package	40.136
Clip, Body Wiring Harness	30.702	Coil, Ignition	7.346
Clip, Brake Shoe Hold Down	15.004	Collar, Air Duct	30.034
Clip, Chassis Wiring Harness	7.700	Collar, Generator Drive End Plate Bearing	7.428
Clip, Clutch Pressure Plate Lever	8.106	Collar, Overdrive Stationary Gear	9.210
Clip, Directional Signal Light Switch Wiring Cover	7.623	Collar, Steering Gear Jacket Cover	14.122
Clip, Distributor Point Set	7.316	Collar and Deflector, Air Duct	30.034
Clip, Door Reveal Moulding Joint	30.0915	Column and Worm, Steering Gear	14.110
Clip, Front Brake Hose Spring	15.068	Condenser, Distributor	7.318
Clip, Front Brake Tube	15.064	Cone, Hydra-Matic Reverse Unit Stationary	9.685
Clip, Front Door Garnish Moulding Weatherstrip	30.101	Connecting Rod, Carburetor Choke	3.680
Clip, Front Door Glass Run	30.204	Connector, Air Duct	30.034
Clip, Front Door Regulator to Channel	30.208	Connector, Directional Signal Light Flasher	7.635
Clip, Fuel Gauge Tank Unit Cable	7.660	Connector, Distributor Vacuum Chamber Tube	7.340
Clip, Fuel Tank to Fuel Pump Tube	3.550	Connector, Fuel Filter	3.555
Clip, Gear Shift Rod to Lever	9.340	Connector, Headlight Cable	7.546
Clip, Generator Adjusting	7.460	Connector, License Light Cable "Y"	30.0702
Clip, Glove Box Lock Attaching	30.404	Connector, Oil Filter Outlet Tube	2.316
Clip, Hand Brake Front Cable	15.218	Connector, Overdrive Wiring Harness	7.812
Clip, Headlight Cable	7.546	Connector, Pump to Wiper Tube	30.364
Clip, Heater Temperature Control Valve	40.002	Connector, Vacuum Pump to Windshield Wiper Tube	3.560
Clip, Hood Anti-Squeak	18.100	Connector, Windshield Washer "Y"	40.116
Clip, Hood Lock Control	18.154	Connector Rod, Carburetor Throttle	3.680
Clip, Instrument Board Moulding	30.412	Control, Hood Lock	18.154
Clip, License Light Cable	30.0702		

ALPHABETICAL INDEX

NAME AND PART DESCRIPTION	GROUP NUMBER	NAME AND PART DESCRIPTION	GROUP NUMBER
Control, Windshield Wiper	30.354	Cover and Disc, Wheel Trim	16.028
Control and Bracket, Overdrive	9.270	Cover and Lens, Hydra-Matic Gear Shift Lever Indicator	9.750
Control Valve, Hydra-Matic Oil	9.710	Cowl Complete	30.054
Core, Heater	40.002	Cradle, Radiator	6.455
Core, Hydra-Matic Speedometer Cable	9.730	Crankshaft	1.300
Core, Speedometer Cable	9.284	Crossmember, Frame	17.010
Countershaft, Transmission	9.165	Cup, Front Brake Cylinder	15.020
Counterweight, Heat Control Valve	5.020	Cup, Horn Blowing Ground	7.527
Coupling, Clutch Pedal Cross Shaft	8.155	Cup, Master Brake Cylinder Piston	15.035
Coupling, Distributor Drive Shaft	7.330	Cup, Overdrive Shift Fork	9.250
Coupling, Distributor Vacuum Chamber	7.338	Cup, Rear Brake Cylinder	15.030
Cover, Clutch Pressure Plate	8.104	Cup, Steering Gear Worm Thrust Bearing	14.112
Cover, Deck Lid Cable	30.6105	Cupwasher, License Light Mounting	30.0702
Cover, Deck Lid Handle Lock Cylinder	30.068	Cushion, Air Ride	40.137
Cover, Directional Signal Light Switch Wiring	7.623	Cushion, Front Seat	30.616
Cover, Distributor Breaker Plate Terminal Slot	7.310	Cushion, Front Sway Eliminator Bar	13.200
Cover, Front Seat Back Ash Receiver	30.806	Cushion, Rear Seat	30.620
Cover, Front Seat Cushion	30.616	Cushion, Shock Absorber	20.002
Cover, Fuel Pump Bowl	3.490	Cylinder, Front Brake	15.010
Cover, Fuel Tank Filler	30.040	Cylinder, Hydra-Matic Front Servo	9.590
Cover, Gear Shift Lever Housing	9.320	Cylinder, Master Brake	15.035
Cover, Heater Defroster Valve Housing	40.008	Cylinder, Rear Brake	15.012
Cover, Hydra-Matic Case Side	9.510	D	
Cover, Hydra-Matic Gear Shift Lever	9.735	Damper, Engine Vibration	1.330
Cover, Hydra-Matic Rear Oil Pump	9.700	Deflector, Exhaust	5.080
Cover, Hydra-Matic Torus	9.505	Deflector, Exhaust	40.126
Cover, Instrument Board Clock Opening	30.412	Deflector, Rear Stone	30.048
Cover, Instrument Board Radio Control	30.410	Dial, Instruments	19.100
Cover, Instrument Board Trim	30.615	Diaphragm Kit, Fuel Pump	3.500
Cover, Master Brake Cylinder Access	15.036	Disc, Clutch	8.100
Cover, Oil Filter	2.300	Distributor	7.300
Cover, Oil Pump	2.230	Donut Disc, Wheel Trim Ring	16.028
Cover, Package Compartment Panel	30.622	Donut Disc, Wheel Trim Ring	40.122
Cover, Package Tray	40.163	Door, Front	30.102
Cover, Rear Axle Housing	12.005	Door, Headlight	7.540
Cover, Rear Quarter Ash Receiver	30.807	Door, License Light	30.0702
Cover, Rear Seat Cushion	30.620	Door, Rear	30.120
Cover, Rear Shelf Trim Panel	30.624	Dowel, Crankshaft Main Bearing Cap	1.320
Cover, Rear Wheel Opening	30.0911	Dowel Pin, Clutch Housing	8.130
Cover, Roof	30.634	Dowel Pin, Crankshaft	1.300
Cover, Spare Tire Well	30.058	Dowel Pin, Crankshaft Main Bearing Cap	1.320
Cover, Steering Drag Link Stud	14.204	Dowel Pin, Generator Commutator End Plate	7.412
Cover, Steering Gear Housing	14.104	Dowel Pin, Generator Drive End Plate	7.428
Cover, Steering Gear Jacket	14.122	Dowel Pin, Starting Motor Commutator End Plate	7.234
Cover, Steering Gear Shaft	14.118	Dowel Pin, Starting Motor Drive Housing	7.242
Cover, Steering Tie Rod End Dust	14.216	Dowel Ring, Crankshaft Main Bearing Cap	1.320
Cover, Timing Chain	1.610	Dowel Screw, Clutch Housing	8.130
Cover, Transmission Adjusting Hole	9.004	Drag Link End, Steering	14.206
Cover, Transmission Case	9.007	Draincock, Cylinder Block Water Jacket	1.100
Cover, Transmission Oil Filler Access Hole	9.004	Draincock, Radiator	6.400
Cover, Valve Tappet	1.750	Drive Nail, Roof Cover	30.634
Cover, Water Pump	6.300	Drive Screw, Hood Ornament Nose	18.110
Cover, Windshield Pillar	30.612		

ALPHABETICAL INDEX

NAME AND PART DESCRIPTION	GROUP NUMBER	NAME AND PART DESCRIPTION	GROUP NUMBER
Drum, Hydra-Matic Front Brake	9.565	Fastener, Steering Column Jacket	14.106
Drum, Hydra-Matic Front Clutch	9.565	Felt, Distributor Cam and Shaft	7.332
Drum, Hydra-Matic Rear Brake	9.610	Fender, Front	18.000
Drum, Hydra-Matic Rear Clutch	9.610	Filler, Deck Drain Trough Upper Corner . .	30.040
Dust Cover, Carburetor	3.680	Filler, Front Door Ventilator Glass	30.206
Dust Seal, Gear Shift Lower Lever	9.320	Filler, Rear Door Ventilator Glass	30.216
E		Filler, Steering Gear Jacket Cover	14.122
Elbow, Cylinder Head Water Outlet	6.425	Filler, Windshield Garnish Moulding	30.304
Elbow, Distributor Vacuum Chamber Tube .	7.340	Filter, Fuel	3.555
Elbow, Fuel Filter	3.555	Filter, Oil	2.300
Elbow, Fuel Line Fitting to Fuel Pump Tube	3.550	Filter Package, Oil	40.145
Elbow, Fuel Pump to Carburetor Tube	3.560	Fitting, Fuel Tank to Fuel Pump Tube	3.550
Elbow, Fuel Pump to Carburetor Vacuum	3.560	Fitting, Master Brake Cylinder Outlet	15.035
Tube	3.560	Flange, Propeller Shaft Companion, Rear . .	11.020
Elbow, Heater to Engine Hose	40.002	Flange and Pin Package, Hydra-Matic	
Elbow, Oil Filter Inlet	2.315	Governor	9.705
Element, Air Cleaner	4.000	Flasher, Directional Signal Light	7.635
Element, Cigar Lighter	7.652	Flatwasher, Body Hold Down Bolt, Lower . .	30.012
Element, Fuel Filter	3.555	Flatwasher, Clutch Pressure Plate Lever . .	8.106
Element, Oil Filter	2.300	Flatwasher, Crankshaft Main Bearing Cap . .	1.320
Element, Oil Filter	40.145	Flatwasher, Deck Lid Handle	30.068
Engine	1.000	Flatwasher, Deck Lid Hinge	30.064
Equalizer, Seat Track Adjuster	30.554	Flatwasher, Deck Lid Support Bracket	30.064
Escutcheon, Deck Lid Handle	30.068	Flatwasher, Distributor Point Set Clip	7.316
Escutcheon, Front Door Handle	30.114	Flatwasher, Engine Vibration Damper	1.330
Escutcheon, Front Door Remote Control		Flatwasher, Exhaust Manifold to Block . . .	5.000
Handle	30.106	Flatwasher, Front Bumper Bar	20.200
Escutcheon, Front Door Window Regulator		Flatwasher, Front Bumper Guard	20.260
Handle	30.208	Flatwasher, Front Door Ventilator Pivot . .	30.206
Escutcheon, Rear Door Handle	30.134	Flatwasher, Front Wheel Hub and Drum . . .	16.002
Escutcheon, Rear Door Remote Control		Flatwasher, Fuel Gauge Tank Unit	3.580
Handle	30.124	Flatwasher, Hydra-Matic Gear Shift	
Escutcheon, Rear Door Window Regulator		Neutralizer Switch to Lever Rod	9.765
Handle	30.218	Flatwasher, Hydra-Matic Rear Bearing	
Expander and Seal Package, Hydra-Matic		Retainer	9.525
Front Clutch Control Piston	9.570	Flatwasher, Hydra-Matic Reverse Unit	
Expander and Seal Package, Hydra-Matic		Internal Gear Support	9.685
Rear Clutch Control Piston	9.315	Flatwasher, Hydra-Matic Throttle Control	
Extension, Quarter Panel Lower	30.040	Lower Bellcrank to Transmission Rod . .	9.810
Extension, Rear Floor Pan	30.058	Flatwasher, Overdrive Control Shaft Lever .	9.260
Extension, Roof Drain Trough Moulding . . .	30.087	Flatwasher, Propeller Shaft Companion	
Eyebolt and Nut, Clutch Pressure Plate		Flange	11.004
Lever	8.104	Flatwasher, Rear Axle Shaft	12.080
F		Flatwasher, Rear Bumper Bar	20.250
Facing Set, Clutch Disc	8.100	Flatwasher, Rear Door Ventilator Pivot . .	30.216
Fan, Engine	6.000	Flatwasher, Rear Wheel Hub and Drum . . .	16.020
Fan, Generator Drive Pulley	7.434	Flatwasher, Rear Shock Absorber	20.010
Fan, Heater Blower	40.002	Flatwasher, Steering Gear Mounting	14.000
Fastener, Center Pillar Trim Panel	30.606	Flatwasher, Tire Well Cover Hold Down	
Fastener, Dash Insulating Pad	30.630	Latch	30.058
Fastener, Front Door Trim Panel	30.604	Flatwasher, Transmission Outer Shifting	
Fastener, Rear Belt Moulding	30.086	Lever	9.195
Fastener, Rear Compartment Windbreak . .	30.611	Flatwasher, Vacuum Antenna Valve	40.102
Fastener, Rear Door Trim Panel	30.608	Float and Lever, Carburetor	3.680
		Floato, Oil Pump	2.235
		Flywheel	1.360

ALPHABETICAL INDEX

NAME AND PART DESCRIPTION	GROUP NUMBER	NAME AND PART DESCRIPTION	GROUP NUMBER
Foglight Package	40.112	Gasket, Hydra-Matic Torus Cover to Flywheel	9.505
Fork, Clutch Release	8.125	Gasket, Intake to Exhaust Manifold	3.000
Fork, Overdrive Shift	9.250	Gasket, License Light Lens	30.0702
Fork, Transmission Shifting	9.185	Gasket, Manifold to Block	3.000
Frame	17.000	Gasket, Master Brake Cylinder	15.035
Frame, License Plate	40.128	Gasket, Master Brake Cylinder Access Cover	15.036
Frame and Glass, Front Door Ventilator . .	30.206	Gasket, Master Brake Cylinder Filler Plug.	15.035
Frame and Glass, Rear Door Ventilator . .	30.216	Gasket, Master Brake Cylinder Fitting . . .	15.035
Funnel, Air Duct Inlet	30.034	Gasket, Oil Filter Cover	2.300
Fuse, Cigar Lighter Cable	7.657	Gasket, Oil Pan Drain Plug	2.400
Fuse, Foglight	40.112	Gasket, Oil Pan	2.400
Fuse, Heater Blower Switch Feed Cable . .	40.002	Gasket, Oil Pressure Relief Valve Plug . . .	2.410
Fuse, Overdrive Solenoid Relay	7.804	Gasket, Oil Pump Cover	2.230
G		Gasket, Overdrive Adapter to Transmission Case	9.145
Gasket, Air Cleaner Element	4.000	Gasket, Overdrive Housing to Adapter	9.200
Gasket, Back-Up Light Lens	40.108	Gasket, Overdrive Main Shaft Slip Joint Housing	9.247
Gasket, Carburetor Air Horn	3.680	Gasket, Overdrive Rail Switch	7.802
Gasket, Carburetor Body Flange	3.680	Gasket, Parking Light Lens	7.563
Gasket, Carburetor Bowl Strainer	3.680	Gasket, Rear Axle Housing Cover	12.005
Gasket, Carburetor Coil Housing	3.680	Gasket, Rear Axle Pinion Bearing	12.050
Gasket, Carburetor Dust Cover	3.680	Gasket, Rear Axle Shaft Bearing Retainer . .	12.080
Gasket, Carburetor Needle Seat	3.680	Gasket, Rear Axle Shaft Oil Seal Outer . . .	12.080
Gasket, Carburetor Piston Housing	3.680	Gasket, Rear Brake Hose	15.074
Gasket, Carburetor Pump Jet	3.680	Gasket, Spark Plug	7.375
Gasket, Cylinder Block Front End Plate . .	1.105	Gasket, Speedometer Cable	9.282
Gasket, Cylinder Head	1.200	Gasket, Steering Gear Shaft Cover	14.118
Gasket, Deck Lid Handle Escutcheon	30.068	Gasket, Tail Light Lens	7.572
Gasket, Deck Lid Hinge	30.064	Gasket, Timing Chain Cover	1.610
Gasket, Distributor Vacuum Chamber	7.338	Gasket, Transmission Adjustment Hole Cover	9.004
Gasket, Exhaust Manifold	5.000	Gasket, Transmission Case Cover	9.007
Gasket, Exhaust Pipe	5.040	Gasket, Transmission Drive Pinion Bearing Retainer	9.117
Gasket, Front Brake Hose	15.068	Gasket, Transmission Main Shaft Bearing Retainer	9.145
Gasket, Fuel Filter	3.555	Gasket, Transmission Oil Filler Access Hole Cover	9.004
Gasket, Fuel Gauge Tank Unit	3.580	Gasket, Valve Tappet Cover	1.750
Gasket, Fuel Pump Bowl Cover	3.490	Gasket, Valve Tappet Cover Stud	1.750
Gasket, Fuel Pump Bowl Cover Bolt	3.490	Gasket, Water Outlet Elbow	6.425
Gasket, Fuel Pump Cover Plate	3.470	Gasket, Water Pump Cover	6.300
Gasket, Fuel Pump Oil Seal	3.505	Gasket, Water Pump to Block	6.300
Gasket, Fuel Pump to Block	3.470	Gasket, Windshield Wiper Arm Pivot	30.358
Gasket, Generator Drive End Plate Bearing Retainer	7.428	Gasket Assortment, Carburetor	3.680
Gasket, Headlight	7.540	Gasket Paste, Perfect Seal	40.133
Gasket, Heater Water Temperature Control Valve	40.002	Gasket Set, Engine Overhaul	1.000
Gasket, Hydra-Matic Case Oil Pan	9.515	Gasket Set, Hydra-Matic Overhaul	9.500
Gasket, Hydra-Matic Case Oil Pan Plug . . .	9.515	Gasket Set, Manifold	5.000
Gasket, Hydra-Matic Case Side Cover	9.510	Gasket Set, Oil Pan	2.400
Gasket, Hydra-Matic Front Oil Pump Cover	9.535	Gasket Set, Valve Grind	1.720
Gasket, Hydra-Matic Front Oil Pump Inlet Pipe Flange	9.545	Gauge, Fuel	19.110
Gasket, Hydra-Matic Oil Pressure Regulator Valve Plug	9.555	Gauge, Fuel, Tank Unit	3.580
Gasket, Hydra-Matic Rear Bearing Retainer	9.525		

ALPHABETICAL INDEX

NAME AND PART DESCRIPTION	GROUP NUMBER	NAME AND PART DESCRIPTION	GROUP NUMBER
Gauge, Moulding Clip	30.099	Grommet, Vacuum Antenna	40.102
Gauge, Oil Depth	2.415	Grommet, Ventilator Control Cable	30.034
Gauge, Oil Pressure	19.110	Grommet, Windshield Wiper Arm Pivot	30.358
Gauge, Oil Pressure, Engine Unit	2.430	Grommet, Windshield Wiper Motor to Bracket	30.352
Gauge, Water Temperature	19.110	Guard, Crankshaft Bearing Rear Filler Block	1.326
Gauge, Water Temperature, Engine Unit	6.444	Guard, Front Bumper	20.260
Gear, Camshaft Timing	1.600	Guard, Rear Bumper	20.265
Gear, Crankshaft Timing	1.600	Guide, Front Door Check Arm	30.112
Gear, Hydra-Matic Front Unit Drive	9.560	Guide, Gear Shift Upper Shaft	9.310
Gear, Hydra-Matic Rear Drum Internal	9.610	Guide, Hand Brake Rear Cable	15.236
Gear, Hydra-Matic Reverse Unit Center	9.675	Guide, Overdrive Shift Fork	9.250
Gear, Hydra-Matic Reverse Unit Internal	9.685	Guide, Rear Door Check Arm	30.132
Gear, Hydra-Matic Reverse Unit Oil Pump and Governor Drive	9.670	Guide, Valve	1.720
Gear, Hydra-Matic Speedometer Drive	9.690		
Gear, Oil Pump	2.210	H	
Gear, Oil Pump Idler	2.215	Handle, Deck Lid	30.068
Gear, Overdrive Governor	9.265	Handle, Front Door	30.114
Gear, Overdrive Stationary	9.210	Handle, Front Door Regulator	30.208
Gear, Speedometer Drive	9.286	Handle, Front Door Remote Control	30.106
Gear, Steering	14.000	Handle, Front Door Ventilator	30.206
Gear, Transmission Low and Reverse	9.135	Handle, Hand Brake	15.200
Gear, Transmission Reverse Idler	9.170	Handle, Rear Door	30.134
Gear, Transmission Second Speed Idler	9.135	Handle, Rear Door Regulator	30.218
Gear Cluster, Transmission Countershaft	9.155	Handle, Rear Door Remote Control	30.124
Gear and Blocking Ring, Overdrive Stationary	9.205	Handle, Rear Door Ventilator	30.216
Gear and Pin Package, Hydra-Matic Rear Oil Pump Driven	9.700	Hanger, Exhaust Pipe	5.050
Gear and Pinion, Rear Axle Drive	12.045	Hanger, Rear Spring	12.200
Gear and Pinion Kit, Rear Axle Differential	12.020	Harness, Body Wiring	30.702
Generator	7.400	Harness, Chassis Wiring	7.700
Glareshield, Inside Visor Package	40.115	Harness, Clock Wiring	40.136
Glass, Front Door	30.201	Harness, Front Door Switch Wiring	30.702
Glass, Front Door Ventilator	30.201	Harness, Generator to Voltage Regulator	7.470
Glass, Quarter Panel Window	30.201	Harness, Instrument Voltage Regulator	19.110
Glass, Rear Door	30.201	Harness, Overdrive Wiring	7.812
Glass, Rear Door Ventilator	30.201	Harness, Relay to Horn	7.525
Glass, Rear Window	30.501	Head, Cylinder	1.200
Glass, Windshield	30.301	Headlight	7.540
Governor, Hydra-Matic	9.705	Headlining	30.612
Governor, Overdrive	9.265	Hinge, Deck Lid	30.064
Governor Weight, Distributor Drive Shaft	7.324	Hinge, Front Door	30.108
Grille, Instrument Board Radio	30.410	Hinge, Hood	18.200
Grommet, Body Wiring Harness	30.702	Hinge, Rear Door	30.126
Grommet, Chassis Wiring Harness	7.700	Hinge, Rear Seat Back Filler	30.560
Grommet, Cigar Lighter Feed Cable	7.657	Hinge, Rear Seat Cushion Panel	30.556
Grommet, Deck Lid Hinge	30.064	Holder, Starting Motor Brush	7.236
Grommet, Fuel Gauge Tank Unit Cable	7.660	Hood	18.100
Grommet, Hand Brake Handle	15.200	Horn	7.520
Grommet, Headlight Dimmer Switch	7.554	Hose, Front Brake	15.068
Grommet, Headlining Bow	30.612	Hose, Fuel Tank Filler	3.520
Grommet, Hood Lock Control	18.154	Hose, Heater	40.002
Grommet, Overdrive Control	9.270	Hose, Heater Defroster	40.008
Grommet, Parking Light Cable	7.568	Hose, Radiator	6.420
Grommet, Speedometer Cable	9.282	Hose, Rear Brake Tube to Axle Tee	15.074
		Hose, Water Temperature Control Valve	40.002

ALPHABETICAL INDEX

NAME AND PART DESCRIPTION	GROUP NUMBER	NAME AND PART DESCRIPTION	GROUP NUMBER
Housing, Clutch	8.130	Key, Hydra-Matic Reverse Unit Stationary Cone	9.685
Housing, Gear Shift Lever	9.320	Key, Ignition Switch Lock	7.352
Housing, Heater Defroster Valve	40.008	Key, Oil Pump Drive Gear	2.210
Housing, Instrument Cluster	30.412	Key, Overdrive Governor Gear	9.265
Housing, Instruments Mounting	19.100	Key, Rear Axle Shaft	12.080
Housing, Overdrive	9.200	Key, Rear Door Ventilator Handle	30.216
Housing, Overdrive Main Shaft Slip Joint . .	9.247	Key, Rear Wheel Hub and Drum	16.020
Housing, Rear Axle	12.005	Key, Speedometer Drive Gear	9.286
Housing, Starting Motor Drive	7.242	King Pin, Steering Knuckle	13.002
Housing, Steering Gear	14.102	Knob, Front Door Lock Push Rod	30.104
Housing and Coil Assembly, Carburetor Thermostatic	3.680	Knob, Front Seat Back Ash Receiver	30.806
Hub, Hydra-Matic Rear Clutch	9.620	Knob, Gear Shift Upper Lever	9.300
Hub, Transmission Second and High Synchronizer	9.125	Knob, Headlight Switch	7.553
Hub, Water Pump Pulley	6.000	Knob, Heater Blower Switch	40.002
Hub and Drum, Front Wheel	16.002	Knob, Hydra-Matic Gear Shift Lever	9.735
Hub and Drum, Rear Wheel	16.020	Knob, Instrument Board Ash Receiver	30.406
Hydraulic Brake Fluid	15.040	Knob, Rear Door Lock Push Rod	30.122
		Knob, Rear Quarter Ash Receiver	30.807
		Knob, Seat Track Adjuster Operating Handle	30.554
I		Knob, Vacuum Antenna Valve	40.102
Impeller, Water Pump	6.300	Knob, Windshield Wiper Control	30.354
Indicator, Hydra-Matic Oil Level	9.520	Knob and Element, Cigar Lighter	7.652
Indicator and Light, Hydra-Matic Gear Shift Lever	9.745	Knuckle, Steering	13.000
Insulator, Engine Support Front	1.010	L	
Insulator, Engine Support Rear	1.020	Latch, Glove Box Door	30.404
Insulator, Front Bumper Bar Support	20.208	Latch, Tire Well Cover Hold Down	30.058
Insulator, Front Suspension Spring Upper . .	13.024	Latch and Link, Deck Lid Lock	30.074
Insulator, Fuel Tank Filler Tube	3.530	Lead, Distributor Breaker Plate	7.310
Insulator, Gear Shift Lower Lever to Rod . .	9.320	Lead, Starting Motor Brush	7.236
Insulator, Radiator Cradle to Frame	6.455	Lens, Back-Up Light	40.108
Insulator, Rear Spring	12.215	Lens, License Light	30.0702
Insulator, Transmission Outer Shifting Lever	9.195	Lens, Hydra-Matic Gear Shift Lever Indicator	9.750
J		Lens, Parking Light	7.563
Jack	20.300	Lens, Tail Light	7.572
Jacket, Steering Column	14.106	Lens and Retainer, Directional Signal Lamp Indicator	19.100
Jet, Carburetor Low Speed	3.680	Lens and Retainer, Headlight Beam Indicator	19.100
Jet, Carburetor Metering Rod	3.680	Lever, Clutch Pressure Plate	8.104
Jet, Windshield Washer	40.116	Lever, Clutch Pedal Shaft	8.145
Jet and Housing, Carburetor Pump	3.680	Lever, Deck Lid Lock	30.074
K		Lever, Directional Signal Light Switch	7.626
Key, Deck Lid Handle Lock Cylinder	30.068	Lever, Hand Brake Equalizing	15.230
Key, Front Door Lock Cylinder	30.114	Lever, Hand Brake Operating	15.008
Key, Front Door Ventilator Handle	30.206	Lever, Hydra-Matic Gear Shift Upper	9.735
Key, Fuel Tank Cover Lock	40.124	Lever, Hydra-Matic Gear Shift Lower	9.770
Key, Generator Drive Pulley	7.434	Lever, Hydra-Matic Manual Oil Control Valve Detent	9.715
Key, Glove Box Lock	30.404	Lever, Hydra-Matic Outer Shift	9.725
Key, Heat Control Valve Counterweight . . .	5.020	Lever, Hydra-Matic Rear Clutch Servo Band Actuating	9.625
Key, Hydra-Matic Front Oil Pump Drive Gear	9.530		
Key, Hydra-Matic Gear Shift Lower Lever . .	9.770		

ALPHABETICAL INDEX

NAME AND PART DESCRIPTION	GROUP NUMBER	NAME AND PART DESCRIPTION	GROUP NUMBER
Lever, Hydra-Matic Throttle Outer Control	9.720	Lock and Key Package, Fuel Tank Cover . .	40.124
Lever, Gear Shift Lower	9.320	Lock Ring, Starting Motor Spring Anchor Plate	7.244
Lever, Gear Shift Upper	9.300	Lock Spring, Carburetor Idle Adjusting Screw	3.680
Lever, Overdrive Control Shaft	9.260	Locking Washer, Hydra-Matic Driven Torus	9.505
Lever, Steering Idler	14.212	Locking Washer, Hydra-Matic Gear Shift Lower Lever	9.770
Lever, Transmission Outer Shifting	9.195	Locknut, Body Hold Down Bolt	30.012
Lever and Countershaft, Carburetor Pump Operating	3.680	Locknut, Brake Pedal	15.102
Lever, Link and Shaft, Carburetor Choke Piston	3.680	Locknut, Clutch Pedal	8.140
Lever and Pin, Carburetor Choke Trip	3.680	Locknut, Clutch Pedal Shaft Lever	8.145
Lever and Shaft, Hydra-Matic Throttle Control Inner	9.720	Locknut, Clutch Pressure Plate Lever	8.106
Lever and Shaft, Transmission Shifting, Inner	9.180	Locknut, Front Bumper Bar	20.200
Lid, Rear Deck	30.062	Locknut, Front Bumper Guard	20.260
Light, License	30.070?	Locknut, Front Suspension Lower Arm Inner Pivot	13.020
Light, Parking and Directional	7.560	Locknut, Fuel Tank Bracket	3.520
Light, Pillar	30.707	Locknut, Propeller Shaft Companion Flange	11.020
Light, Tail, Stop and Directional	7.570	Locknut, Rear Bumper Bar	20.250
Light Package, Rear Compartment	40.152	Locknut, Rear Bumper Guard	20.265
Light and Shield, Hydra-Matic Gear Shift Lever Indicator	9.745	Locknut, Rear Spring Shackles	12.220
Lighter, Cigar	7.652	Locknut, Shock Absorber	20.000
Link, Carburetor Fast Idle	3.680	Locknut, Steering Gear Mounting	14.000
Link, Carburetor Pump Arm	3.680	Locknut, Steering Gear Shaft and Roller . .	14.116
Link, Carburetor Vacuumer	3.680	Lockpin, King Pin	13.002
Link, Clutch Pedal Shaft Adjusting	8.145	Lockpin, Rear Axle Differential Side Pinion	12.020
Link, Generator Adjusting	7.460	Lockplate, Hydra-Matic Brake Drum Oil Delivery Cap Bolt	9.575
Link, Hand Brake Operating Lever	15.008	Lockplate, Hydra-Matic Front Oil Pump Inlet Pipe	9.545
Link, Rear Door Lock Push Rod	30.122	Lockplate, Rear Axle Drive Gear and Pinion Bolt	12.045
Link, Steering Drag	14.202	Lockplate, Steering Gear Shaft and Roller .	14.116
Link, Windshield Wiper Arm Pivot	30.358	Lockplate, Transmission Reverse Idler Gear Shaft	9.175
Link Block, Hydra-Matic Gear Shift Lever Indicator	9.745	Lockwasher, Distributor Breaker Plate Lead	7.310
Lining Set, Brake Shoe	15.006	Lockwasher, Distributor Condenser	7.318
Lock, Camshaft Timing Gear	1.600	Lockwasher, Distributor Drive Shaft Plate Spacer	7.324
Lock, Deck Lid	30.074	Lockwasher, Front Door Lock Striker Plate	30.104
Lock, Front Door	30.104	Lockwasher, Front Suspension Lower Arm Outer Pivot	13.012
Lock, Glove Box Door	30.404	Lockwasher, Generator Armature Terminal	7.402
Lock, Hydra-Matic Reverse Shifter Anchor.	9.695	Lockwasher, Generator Brush	7.420
Lock, Intake and Exhaust Valve Spring Retainer	1.720	Lockwasher, Generator Drive End Plate Bearing Retainer	7.428
Lock, Rear Door	30.122	Lockwasher, Generator Drive Pulley	7.434
Lock, Safety Car Door Kiddie	40.151	Lockwasher, Overdrive Kickdown Switch Terminal Screw	7.806
Lock, Steering Idler Lever Bearing	14.212	Lockwasher, Rear Door Lock Striker Plate.	30.122
Lock Clip, Distributor Terminal	7.300	Lockwasher, Starting Switch Terminal	7.270
Lock Cylinder and Key, Deck Lid Handle . .	30.068	Lockwasher, Steering Gear Lever Arm . . .	14.200
Lock Cylinder and Key, Front Door	30.114	Lubriplate	40.1345
Lock Cylinder and Key, Ignition Switch . . .	7.352	Lustur Seal	40.134
Lock Cylinder and Key Kit, Deck Lid Handle	30.068		
Lock Cylinder and Key Kit, Front Door . . .	30.114		
Lock Cylinder and Key Kit, Glove Box and Deck Lid	30.404		

ALPHABETICAL INDEX

NAME AND PART DESCRIPTION	GROUP NUMBER	NAME AND PART DESCRIPTION	GROUP NUMBER
Lustur Seal Applicator	40.134	Nut, Back-Up Light Switch	40.108
Lustur Seal Buffer Pad	40.134	Nut, Battery Cable	7.510
Lustur Seal Haze Cream	40.134	Nut, Brake Shoe Adjusting Cam	15.000
Lustur Seal Literature Kit	40.134	Nut, Camshaft Timing Gear	1.600
M		Nut, Carburetor Choke Tube	3.010
Manifold, Exhaust	5.000	Nut, Connecting Rod	1.400
Manifold, Intake	3.000	Nut, Deck Lid Handle	30.068
Mat, Floor	30.630	Nut, Directional Signal Light Switch	7.620
Mat, Rear Compartment Floor	30.611	Nut, Distributor Advance Arm	7.308
Mat, Rear Compartment Tire Well Cover	30.611	Nut, Distributor Point Set	7.316
Medallion, Hood	18.130	Nut, Distributor Vacuum Chamber Tube	7.340
Medallion, Horn	7.527	Nut, Exhaust Manifold	5.000
Medallion, Instrument Board Glove Box Panel	30.404	Nut, Exhaust Pipe	5.040
Metering Rod, Carburetor	3.680	Nut, Flywheel to Crankshaft	1.360
Mirror, Outside Rear View	40.118	Nut, Front Brake Tube	15.064
Mirror, Vanity	40.120	Nut, Front Door Arm Rest	30.614
Mirror and Bracket, Rear View	30.802	Nut, Front Door Ventilator Pivot	30.206
Motor, Heater Blower	40.002	Nut, Front Fender to Radiator Cradle and Bracket	18.000
Motor, Windshield Wiper	30.352	Nut, Front Seat Back Cushion Frame	30.616
Motor and Bracket, Windshield Wiper	30.352	Nut, Front Seat Track Adjuster to Cushion	30.554
Moulding, Front Door Belt	30.0901	Nut, Front Suspension Lower Arm Outer Pivot	13.012
Moulding, Front Door Garnish	30.101	Nut, Fuel Pump to Carburetor Tube	3.560
Moulding, Front Door Reveal	30.0915	Nut, Fuel Pump to Carburetor Vacuum Tube	3.560
Moulding, Front Door Rub Rail	30.0911	Nut, Fuel Tank to Fuel Pump Tube	3.550
Moulding, Front Door Trim Panel	30.604	Nut, Generator Drive Pulley	7.434
Moulding, Front Fender Rub Rail	30.0911	Nut, Headlight Sealed Beam Adjusting Screw	7.540
Moulding, Instrument Board	30.412	Nut, Headlight Switch	7.553
Moulding, Quarter Panel Extension	30.0911	Nut, Heater Blower Switch	40.002
Moulding, Quarter Panel Rub Rail	30.0911	Nut, Heater Defroster Control Cable	40.008
Moulding, Quarter Panel Window Belt	30.0901	Nut, Heater Water Temperature Control Cable	40.002
Moulding, Quarter Panel Window Garnish	30.119	Nut, Heater Water Temperature Control Valve Tube	40.002
Moulding, Quarter Panel Window Reveal	30.0915	Nut, Hydra-Matic Driven Torus	9.505
Moulding, Rear Belt	30.086	Nut, Instrument Board Glove Box Support to Cowl	30.404
Moulding, Rear Door Belt	30.0901	Nut, Instrument Voltage Regulator	19.110
Moulding, Rear Door Garnish	30.119	Nut, Intake to Exhaust Manifold	3.000
Moulding, Rear Door Reveal	30.0915	Nut, Master Brake Cylinder to Rear Brake Hose Tube	15.070
Moulding, Rear Door Rub Rail	30.0911	Nut, Master Brake Cylinder Tube to Frame Tee	15.060
Moulding, Rear Door Trim Panel	30.608	Nut, Oil Filter Inlet Tube	2.315
Moulding, Rear Window Garnish	30.503	Nut, Oil Filter Outlet	2.316
Moulding, Rear Window Reveal	30.0915	Nut, Overdrive Kickdown Switch	7.806
Moulding, Roof Drain Trough	30.087	Nut, Rear Axle Brake Tube	15.078
Moulding, Roof Drip	30.052	Nut, Rear Axle Shaft	12.080
Moulding, Windshield Garnish	30.304	Nut, Rear Door Ventilator Pivot	30.216
Moulding, Windshield Reveal	30.0915	Nut, Rear Wheel Hub and Drum	16.020
Moulding Package, Rub Rail	40.154	Nut, Starting Motor Cover Band	7.238
Muffler, Exhaust	5.055	Nut, Starting Motor Terminal	7.222
N		Nut, Starting Switch	7.270
Needle, Carburetor Pump Check	3.680	Nut, Steering Gear Lever Arm Pitman	14.200
Needle and Seat, Carburetor Float	3.680	Nut, Steering Wheel	14.126
Nipple, Ignition Cable	7.360		
Nipple, Spark Plug Cable	7.360		
Nose, Hood Ornament	18.110		
Nut, Air Duct Clamp	30.034		

ALPHABETICAL INDEX

NAME AND PART DESCRIPTION	GROUP NUMBER	NAME AND PART DESCRIPTION	GROUP NUMBER
Nut, Vacuum Antenna Valve	40.102	Pad, Horn Blowing Ring	40.155
Nut, Vacuum Pump to Windshield Wiper Tube	3.560	Pad, License Light Mounting	30.0702
Nut, Valve Tappet Cover	1.750	Pad, Lustur Seal Buffer	40.134
Nut, Windshield Wiper Control	30.354	Pad, Parking and Directional Light Mounting	7.560
Nut, Windshield Wiper Motor	30.352	Pad, Rear Seat Cushion (Rubber)	30.620
Nut and Gasket, Carburetor Strainer	3.680	Pad, Tail, Stop and Directional Light Mounting	7.570
Nut and Retainer, License Light Mounting	30.0702	Pad, Windshield Wiper Arm Pivot	30.358
O		Pan, Clutch Housing	8.135
Oil, General Use	40.134	Pan, Oil	2.400
Oil Pan, Hydra-Matic Case	9.515	Pan, Rear Floor	30.058
Oil Pump, Hydra-Matic Rear	9.700	Panel, Body Rocker	30.056
Oil Seal, Crankshaft Bearing Rear Filler Block	1.326	Panel, Center Pillar Trim	30.606
Oil Seal, Fuel Pump	3.505	Panel, Cowl Trim	30.602
Oil Seal, Hydra-Matic Front Oil Pump Cover	9.540	Panel, Deck Lower	30.058
Oil Seal, Hydra-Matic Rear Bearing Retainer	9.525	Panel, Deck Opening Side	30.040
Oil Seal, Overdrive Main Shaft	9.235	Panel, Deck Opening Upper Strainer	30.040
Oil Seal, Overdrive Shift Control Shaft	9.255	Panel, Door Lock Pillar Trim	30.605
Oil Seal, Overdrive Solenoid	7.800	Panel, Front Door Trim	30.604
Oil Seal, Rear Axle Pinion Bearing, Front	12.050	Panel, Front Stone Deflector	6.492
Oil Seal, Rear Axle Shaft	12.080	Panel, Fuel Tank Filler Housing	30.040
Oil Seal, Transmission Inner Shifting Lever	9.180	Panel, Fuel Tank Stone Deflector	3.520
Oil Seal, Transmission Main Shaft Bearing Retainer	9.145	Panel, Hand Brake Lever Cover	30.412
Oil Seal, Universal Joint	11.030	Panel, Instrument Board Glove Box	30.404
Oiler, Clutch Housing	8.130	Panel, Instrument Board Heater Control	30.412
Oiler, Distributor	7.302	Panel, Package Compartment	30.562
Oiler, Front Suspension Lower Arm Outer Pivot	13.012	Panel, Package Compartment Rear	30.564
Oiler, Front Suspension Upper Arm	13.014	Panel, Radiator Splash	6.465
Oiler, Front Suspension Upper Arm Outer Pivot	13.010	Panel, Rear Door Trim	30.608
Oiler, Generator Commutator End Plate	7.412	Panel, Rear Quarter	30.040
Oiler, Generator Drive End Plate	7.428	Panel, Rear Quarter Trim	30.610
Oiler, Master Brake Cylinder	15.035	Panel, Rear Seat Back	30.560
Oiler, Steering Drag Link	14.202	Panel, Rear Seat Cushion	30.556
Oiler, Steering Drag Link End Socket	14.206	Panel, Rear Seat Shelf	30.505
Oiler, Steering Idler Lever	14.212	Panel, Rear Wheelhousing, Outer	30.040
Oiler, Steering Knuckle	13.000	Panel, Roof	30.052
Oiler, Steering Tie Rod	14.216	Panel, Seat Protector	40.129
Oiler, Universal Joint	11.030	Panel, Sun Visor	30.626
Outlet, Air Duct, Rear	30.034	Pawl, Deck Lid Handle	30.068
P		Pawl, Hydra-Matic Parking Brake	9.695
Pad, Back-Up Light	40.108	Pawl, Overdrive Stationary Gear	9.210
Pad, Brake Pedal	15.102	Pedal, Accelerator	3.070
Pad, Clutch Pedal	8.140	Pedal, Brake	15.102
Pad, Dash Insulating	30.630	Pedal, Clutch	8.140
Pad, Front Floor Carpet	30.630	Pillar, Body Center	30.038
Pad, Front Seat Cushion (Rubber)	30.616	Pillar, Body Front	30.038
Pad, Horn Blowing Contact	7.527	Pillar, Body Rear Quarter Lock	30.038
		Pin, Accelerator Pedal Pivot	3.070
		Pin, Carburetor Choke Piston	3.680
		Pin, Carburetor Float Lever	3.680
		Pin, Carburetor Intake Needle	3.680
		Pin, Clutch Pressure Plate Lever	8.104
		Pin, Deck Lid Hinge	30.064
		Pin, Deck Lid Lock	30.074

ALPHABETICAL INDEX

NAME AND PART DESCRIPTION	GROUP NUMBER	NAME AND PART DESCRIPTION	GROUP NUMBER
Pin, Directional Signal Light Switch Cut-Off	7.630	Piston, Hydra-Matic Rear Clutch Control Annular	9.615
Pin, Distributor Drive Shaft Coupling	7.330	Piston, Hydra-Matic Rear Servo Accumulator	9.645
Pin, Front Door Check Arm	30.112	Piston, Hydra-Matic Rear Servo Booster	9.635
Pin, Front Door Handle	30.114	Piston, Hydra-Matic Rear Servo Compensator	9.650
Pin, Front Door Hinge	30.108	Piston, Hydra-Matic Reverse Shifter Bracket Blocker	9.695
Pin, Front Door Regulator Handle	30.208	Piston, Hydra-Matic Reverse Unit	9.685
Pin, Front Door Remote Control Handle	30.106	Piston, Master Brake Cylinder	15.035
Pin, Front Door Ventilator Handle	30.206	Piston, Rear Brake Cylinder	15.030
Pin, Hand Brake Handle Stop	15.200	Piston and Pin, Carburetor Vacuum	3.680
Pin, Hood Lock Safety Catch Pivot	18.152	Pivot, Clutch Pedal Cross Shaft	8.155
Pin, Hydra-Matic Compensator Auxiliary Plug Stop	9.710	Pivot, Deck Lid Support Spring	30.064
Pin, Hydra-Matic Rear Clutch Plate Release Spring Guide	9.615	Pivot, Front Door Ventilator	30.206
Pin, Hydra-Matic Rear Clutch Servo Band Actuating Lever	9.625	Pivot, Front Suspension Lower Arm Inner	13.020
Pin, Oil Pump Gear	2.210	Pivot, Front Suspension Lower Arm Outer	13.012
Pin, Overdrive Shift Control Shaft	9.255	Pivot, Front Suspension Upper Arm Inner	13.016
Pin, Piston	1.420	Pivot, Front Suspension Upper Arm Outer	13.010
Pin, Rear Door Check Arm	30.132	Pivot, Gear Shift Rod to Lever	9.340
Pin, Rear Door Handle	30.134	Pivot, Rear Door Ventilator	30.216
Pin, Rear Door Hinge	30.126	Pivot, Rear Seat Back Outer Hinge	30.560
Pin, Rear Door Regulator Handle	30.218	Pivot, Windshield Wiper Arm	30.358
Pin, Rear Door Remote Control Handle	30.124	Pivot Pin, Gear Shift Upper Lever	9.300
Pin, Rear Door Ventilator	30.216	Planet Carrier, Hydra-Matic Reverse Unit	9.680
Pin, Rear Shock Absorber Lower Anchor	12.215	Plastigage	1.315
Pin, Transmission Inner Shifting Lever	9.180	Plate, Brake Support, Front	15.000
Pin, Transmission Shifting Lever Poppet Ball	9.190	Plate, Brake Support, Rear	15.002
Pin, Seal and Washer Package, Hydra-Matic Throttle Inner Control Lever	9.720	Plate, Clutch Pressure	8.104
Pin Spring, Carburetor	3.680	Plate, Cylinder Block Front End	1.105
Pinion, Overdrive Governor	9.265	Plate, Deck Lid Lock Cover	30.074
Pinion, Speedometer Driven	9.286	Plate, Deck Lid Name	30.076
Pinion, Transmission Drive	9.100	Plate, Distributor Breaker	7.310
Pinion and Sleeve, Hydra-Matic Speedometer Drive	9.690	Plate, Distributor Drive Shaft Governor Weight Hold Down	7.324
Pipe, Exhaust	5.040	Plate, Door Scuff	30.808
Pipe, Hydra-Matic Front Oil Pump	9.545	Plate, Flywheel to Crankshaft Bolt	1.360
Pipe, Hydra-Matic Oil Control Valve to Governor Oil Delivery	9.710	Plate, Front Door Lock Striker	30.104
Pipe, Hydra-Matic Pressure Regulator Reverse Oil	9.710	Plate, Front Fender Name	18.004
Pipe, Hydra-Matic Rear Oil Pump Front Servo Discharge	9.655	Plate, Front Seat Back Stop	30.616
Pipe, Hydra-Matic Reverse Clutch	9.710	Plate, Generator Commutator End	7.412
Pipe, Tail	5.070	Plate, Generator Drive End	7.428
Piston	1.410	Plate, Generator Drive End Plate Bearing Retainer	7.428
Piston, Carburetor Choke	3.680	Plate, Glove Box Lock Striker	30.404
Piston, Front Brake Cylinder	15.020	Plate, Hood Lock Latch	18.150
Piston, Hydra-Matic Front Clutch Control Annular	9.570	Plate, Hood Lock Latch Support	18.147
Piston, Hydra-Matic Front Servo Band	9.595	Plate, Horn Blowing Contact	7.527
Piston, Hydra-Matic Parking Blocker	9.695	Plate, Horn Blowing Ground Spring	7.527
		Plate, Horn Blowing Ring Cable Terminal	7.536
		Plate, Hydra-Matic Front Clutch Drive	9.570
		Plate, Hydra-Matic Gear Shift Upper Bracket	9.755
		Plate, Hydra-Matic Name	9.505
		Plate, Hydra-Matic Rear Clutch	9.615

ALPHABETICAL INDEX

NAME AND PART DESCRIPTION	GROUP NUMBER	NAME AND PART DESCRIPTION	GROUP NUMBER
Plate, Master Brake Cylinder Piston Stop . . .	15.035	Pointer, Engine Timing	1.370
Plate, Overdrive Stationary Gear Cover . . .	9.215	Presstite Cord	40.133
Plate, Package Compartment Lower Panel Support	30.562	Prop, Deck Lid	30.064
Plate, Rear Door Lock Striker	30.122	Pulley, Generator Drive	7.434
Plate, Rear Seat Back Hinge Pivot	30.560	Pulley, Water Pump	6.000
Plate, Rear Seat Back Outer Panel Hinge Pivot	30.560	Pump, Fuel	3.470
Plate, Rear Spring Mounting	12.215	Pump, Hydra-Matic Front Oil	9.530
Plate, Starting Motor Bendix Drive Spring Anchor	7.244	Pump, Oil	2.200
Plate, Starting Motor Center	7.240	Pump, Water	6.300
Plate, Starting Motor Commutator End . . .	7.234	R	
Plate, Tail Pipe Rear Support	5.080	Radiator	6.400
Plate, Transmission Second and High Synchronizer Sleeve Shifting	9.130	Radiator Flush	40.134
Plate and Nut, Hood Lock Bolt	18.148	Radiator Rust Resistor	40.134
Plug, Blower Switch Button	30.412	Radiator Stop Leak	40.134
Plug, Clutch Pedal Hole	8.140	Radio Package	40.100
Plug, Cylinder Block Oil Header Pipe	1.100	Rail, Overdrive Shift	9.250
Plug, Cylinder Block Water Jacket	1.100	Rail, Roof Side	30.052
Plug, Defroster Control Button	30.412	Regulator, Front Door	30.208
Plug, Distributor Cap	7.302	Regulator, Generator Voltage	7.470
Plug, Distributor Vacuum Chamber	7.338	Regulator, Instrument Voltage	19.110
Plug, Floor Pan Button	30.058	Regulator, Quarter Panel Window	30.218
Plug, Gear Shift Lever Housing Cover	9.320	Regulator, Rear Door	30.218
Plug, Heater Mounting Hole Button	30.054	Reinforcement, Deck Lid Handle	30.068
Plug, Hydra-Matic Case	9.510	Reinforcement, Deck Panel Lower	30.058
Plug, Hydra-Matic Front Servo Body	9.585	Reinforcement, Front Suspension Lower Arm Inner Pivot	13.020
Plug, Hydra-Matic Governor Oil Delivery Sleeve	9.705	Reinforcement, Hood Lock Latch Support Plate	18.147
Plug, Hydra-Matic Oil Pressure Regulator Valve	9.555	Reinforcement, Overdrive Control	9.270
Plug, Hydra-Matic Torus Cover	9.505	Reinforcement, Roof Side Rail	30.052
Plug, Master Brake Cylinder Filler Hole . .	15.035	Reinforcement, Tail Pipe Support	5.075
Plug, Oil Pan Drain	2.400	Relay, Horn	7.525
Plug, Oil Pressure Relief Valve	2.410	Relay, Overdrive Solenoid	7.804
Plug, Pillar Light Switch Hole	30.707	Remote Control and Link, Front Door	30.106
Plug, Rear Quarter Pillar Facing Button . .	30.038	Remote Control and Link, Rear Door	30.124
Plug, Rocker Panel Drain Hole	30.056	Repair Kit, Carburetor	3.680
Plug, Steering Drag Link End Socket	14.206	Repair Kit, Front Brake Cylinder	15.014
Plug, Steering Gear Shaft Cover Oiler . . .	14.118	Repair Kit, Front Suspension Lower Arm Inner Pivot	13.020
Plug, Transmission Case Filler and Drain .	9.005	Repair Kit, Front Suspension Lower Arm Outer Pivot	13.012
Plug, Water Pump Body	6.300	Repair Kit, Front Suspension Upper Arm Inner Pivot	13.014
Plug and Gasket, Hydra-Matic Oil Pan . . .	9.515	Repair Kit, Front Suspension Upper Arm Outer Pivot	13.010
Plug Package, Hydra-Matic Oil Pressure Regulator and Reverse Booster	9.555	Repair Kit, Fuel Pump	3.480
Plunger, Hydra-Matic Manual Oil Control Valve Detent	9.715	Repair Kit, Master Brake Cylinder	15.040
Plunger, Hydra-Matic Rear Servo Accumulator Check Valve	9.640	Repair Kit, Rear Brake Cylinder	15.014
Plunger and Bushing, Hydra-Matic Governor	9.705	Repair Kit, Steering Knuckle King Pin	13.002
Plunger, Rod, Spring and Retainer, Carburetor	3.680	Repair Kit, Steering Tie Rod	14.216
Point Set, Distributor	7.316	Repair Kit, Universal Joint	11.030
		Repair Kit, Water Pump	6.300
		Repair Package, Flywheel	1.360
		Retainer, Battery	7.500
		Retainer, Body Wiring Harness	30.702

ALPHABETICAL INDEX

NAME AND PART DESCRIPTION	GROUP NUMBER	NAME AND PART DESCRIPTION	GROUP NUMBER
Retainer, Brake Pedal Arm and Shaft	15.102	Retainer, Rear Door Ventilator Division	
Retainer, Carburetor Choke Shaft	3.680	Bar and Weatherstrip	30.216
Retainer, Carburetor Coil Housing	3.680	Retainer, Rear Door Ventilator Pivot	30.216
Retainer, Carburetor Pump Spring	3.680	Retainer, Rear Seat Back Ball Stud Bumper	30.560
Retainer, Carburetor Throttle and Choke		Retainer, Rear Wheel Opening Cover Catch	30.0911
Connector Rod	3.680	Retainer, Shock Absorber	20.002
Retainer, Carburetor Throttle Connector		Retainer, Shock Absorber	20.004
Rod	3.680	Retainer, Speedometer Cable Grommet . . .	9.282
Retainer, Deck Lid Handle	30.068	Retainer, Steering Column Jacket Bearing .	14.108
Retainer, Deck Lid Side Bumper	30.062	Retainer, Transmission Drive Pinion	
Retainer, Distributor Breaker Plate	7.310	Bearing	9.115
Retainer, Exhaust Manifold	5.000	Retainer, Transmission Main Shaft Bearing	9.145
Retainer, Front Door Lock Cylinder	30.114	Retainer, Universal Joint Oil Seal	11.030
Retainer, Front Door Lock Cylinder to		Retainer, Windshield Division Bar	30.306
Stem	30.114	Retainer, Windshield Wiper Arm Pivot . . .	30.358
Retainer, Front Door Ventilator Division		Retainer, Windshield Wiper Link	30.358
Bar and Weatherstrip	30.206	Retainer Ring, Water Pump Bearing	6.300
Retainer, Front Sway Eliminator Bar		Retainer Spring, Directional Signal Light	
Cushion	13.200	Switch Wiring Cover	7.623
Retainer, Gear Shift Upper Lever	9.300	Retainer Washer, Carburetor Choke Shaft. .	3.680
Retainer, Generator Drive End Plate Seal .	7.428	Retaining Ring, Carburetor Pump Check	
Retainer, Hand Brake Operating Lever. . . .	15.008	Ball	3.680
Retainer, Hand Brake Rear Cable	15.236	Retaining Ring, Carburetor Throttle Shaft. .	3.680
Retainer, Hood Lock Bolt Plate	18.148	Retaining Ring, Headlight Sealed Beam . . .	7.540
Retainer, Hydra-Matic Front Servo		Retaining Ring, Piston Pin	1.420
Downshift 4th to 3rd Valve	9.600	Ring, Hood Ornament	18.110
Retainer, Hydra-Matic Front Servo		Ring, Horn Blowing	7.527
Retracting Spring	9.595	Ring, Horn Blowing Contact	7.527
Retainer, Hydra-Matic Gear Shift Lever		Ring, Hydra-Matic Brake Drum Oil Seal . .	9.575
Anti-Rattle Washer	9.735	Ring, Hydra-Matic Driven Torus Retaining.	9.505
Retainer, Hydra-Matic Gear Shift Lever		Ring, Hydra-Matic Front Oil Pump Cover	
Indicator Lens	9.750	Oil Seal	9.540
Retainer, Hydra-Matic Gear Shift Lever		Ring, Hydra-Matic Front Servo Band Piston	9.595
Spring	9.735	Ring, Hydra-Matic Governor Oil Seal. . . .	9.705
Retainer, Hydra-Matic Manual Oil Control		Ring, Hydra-Matic Rear Servo Booster	
Valve Detent Ball	9.715	Piston	9.635
Retainer, Hydra-Matic Oil Control Valve		Ring, Hydra-Matic Rear Servo Accumulator	
Reverse Detent Plunger	9.710	Piston	9.645
Retainer, Hydra-Matic Rear Bearing.	9.525	Ring, Hydra-Matic Rear Servo Compensator	
Retainer, Hydra-Matic Rear Servo		Piston	9.650
Compensator Piston Spring	9.650	Ring, Piston	1.415
Retainer, Hydra-Matic Reverse Clutch		Ring, Slotted Oil Control Piston	1.417
Release Spring	9.685	Ring, 2nd Steel Section Compression Piston	1.417
Retainer, Hydra-Matic Reverse Unit Piston		Ring, Steel Section Oil Control Piston	1.417
Release Spring	9.685	Ring, Steering Wheel Trim	7.527
Retainer, Hydra-Matic Torus Check Valve .	9.505	Ring, Tire Well Cover	30.058
Retainer, Intake and Exhaust Valve Spring .	1.720	Ring, Top Compression Piston	1.417
Retainer, Intake Manifold	3.000	Ring Gear, Flywheel.	1.360
Retainer, License Light Lens	30.0702	Ring Gear, Overdrive	9.245
Retainer, Master Brake Cylinder Piston		Ring Package, Horn Blowing	40.155
Stop Plate	15.035	Ring Set, Piston	1.417
Retainer, Overdrive Free Wheeling Cam		Ring Set, Wheel Trim	40.122
Bearing	9.230	Rivet, Deck Lid Handle Lock Cylinder	
Retainer, Overdrive Governor Sleeve	9.265	Cover	30.068
Retainer, Radiator Grille Bar	6.490	Rivet, Front Door Ventilator Division Bar .	30.206
Retainer, Rear Axle Shaft Bearing	12.080	Rivet, Front Door Ventilator Pivot	30.206

ALPHABETICAL INDEX

NAME AND PART DESCRIPTION	GROUP NUMBER	NAME AND PART DESCRIPTION	GROUP NUMBER
Rivet, Front Door Ventilator Upper Pivot Bracket	30.206	Screw, Carburetor Pump Jet Housing Attaching	3.680
Rivet, Instrument Board Glove Box Panel . .	30.404	Screw, Carburetor Throttle Lever Adjustment	3.680
Rivet, Rear Door Ventilator Division Bar . .	30.216	Screw, Carburetor Throttle Shaft Arm Attaching	3.680
Rivet, Rear Door Ventilator Handle Striker .	30.216	Screw, Carburetor Throttle Valve Attaching	3.680
Rivet, Rear Door Ventilator Pivot	30.216	Screw, Clutch Pressure Plate Lever Adjusting	8.106
Rivet, Tire Well Cover Hold Down Clip . . .	30.058	Screw, Cowl Trim Panel	30.602
Rivet, Wheel Hub Cap Spring Clip	16.026	Screw, Deck Lid Handle Lock Cylinder Cover	30.068
Rivet Plug, Carburetor	3.680	Screw, Distributor Breaker Plate Lead . . .	7.310
Rivet Plug, Carburetor Idle Port	3.680	Screw, Distributor Condenser	7.318
Rivet Plug, Carburetor Nozzle	3.680	Screw, Distributor Contact Plate	7.316
Rod, Accelerator Adjusting	3.435	Screw, Distributor Point Set	7.316
Rod, Accelerator Pedal	3.085	Screw, Distributor Terminal	7.300
Rod, Connecting	1.400	Screw, Distributor Vacuum Chamber	7.334
Rod, Front Door Lock Push	30.104	Screw, Door Arm Rest	30.614
Rod, Gear Shift	9.340	Screw, Front Door Lock Striker Plate	30.104
Rod, Hand Brake Equalizing Lever	15.230	Screw, Front Door Ventilator Division Bar .	30.206
Rod, Hood Lock Latch Support	18.147	Screw, Front Fender Radiator Shroud	18.000
Rod, Hydra-Matic Gear Shift Lower Lever to Transmission	9.775	Screw, Front Fender Splash Shield	18.010
Rod, Hydra-Matic Gear Shift Neutralizer Switch to Lever	9.760	Screw, Front Stone Deflector Panel	6.492
Rod, Hydra-Matic Throttle Control Lever Bellcrank to Transmission	9.810	Screw, Generator Drive End Plate Bearing Retainer	7.428
Rod, Hydra-Matic Throttle Control Upper to Lower Bellcrank	9.800	Screw, Generator Voltage Regulator	7.470
Rod, Master Brake Cylinder Piston Push . .	15.035	Screw, Headlight Cable Clip	7.546
Rod, Rear Door Lock Push	30.122	Screw, Headlight Cable Ground	7.546
Rod, Seat Track Adjuster Connecting	30.554	Screw, Headlight Door	7.540
Rod, Steering Gear Support	14.120	Screw, Headlight Sealed Beam	7.540
Roller, Hydra-Matic Reverse Shifter Crank	9.695	Screw, Horn Relay	7.525
Roller and Cage, Steering Gear Worm Thrust Bearing	14:114	Screw, Hydra-Matic Front Clutch Servo Band Adjusting	9.580
Rotor, Distributor Cam	7.332	Screw, Hydra-Matic Rear Clutch Servo Band Adjusting	9.625
Run, Front Door Glass	30.204	Screw, Ignition Coil Mounting Strap Clamp .	7.346
Run, Front Door Ventilator Division Bar . .	30.206	Screw, Instrument Board Glove Box Support	30.404
Run, Quarter Panel Window Glass	30.212	Screw, License Light Door	30.0702
Run, Rear Door Glass	30.212	Screw, Package Compartment Rear Panel . .	30.564
Run, Rear Door Ventilator Division Bar Glass	30.216	Screw, Parking Light Cable Clip	7.568
S		Screw, Parking Light Door	7.563
Screen, Clutch Housing	8.130	Screw, Quarter Panel Window Glass Division Bar	30.216
Screen, Fuel Pump Bowl	3.490	Screw, Radiator Grille	6.490
Screen, Hydra-Matic Front Oil Pump Intake	9.545	Screw, Radiator Shroud	6.480
Screen, Hydra-Matic Gear Shift Lever Indicator Lens	9.750	Screw, Radiator Splash Panel	6.465
Screw, Air Duct Valve and Collar	30.034	Screw, Rear Door Lock Striker Plate	30.122
Screw, Back-Up Light Lens Bezel	40.108	Screw, Rear Quarter Arm Rest	30.6101
Screw, Carburetor Choke Valve Attaching . .	3.680	Screw, Rear Seat Back Ball Stud to Support.	30.560
Screw, Carburetor Coil Housing Attaching . .	3.680	Screw, Rear Seat Back Outer Panel Hinge Pivot Plate	30.560
Screw, Carburetor Idle Adjustment	3.680	Screw, Rear Seat Shelf Panel	30.505
Screw, Carburetor Metering Rod Arm Clamp	3.680	Screw, Rear Stone Deflector	30.048
Screw, Carburetor Piston Housing Attaching	3.680	Screw, Starting Motor Brush Set	7.236
		Screw, Starting Motor Cover Band	7.238

ALPHABETICAL INDEX

NAME AND PART DESCRIPTION	GROUP NUMBER	NAME AND PART DESCRIPTION	GROUP NUMBER
Screw, Starting Motor Solenoid	7.265	Seal, Generator Drive End Plate	7.428
Screw, Steering Gear Jacket	14.122	Seal, Heater Blower	40.002
Screw, Steering Gear Shaft and Roller Adjusting	14.116	Seal, Hydra-Matic Gear Shift Lower Bracket	9.760
Screw, Valve Tappet Adjusting	1.740	Seal, Radiator Splash Panel to Fender	6.465
Screw, Windshield Wiper Motor to Bracket	30.352	Seal, Rear Seat Shelf Panel	30.505
Screw with L/W, Cowl Trim Panel	30.602	Seal, Rear Stone Deflector	30.048
Screw with L/W, Deck Lid Hinge	30.064	Seal, Steering Gear Shaft and Roller	14.116
Screw with L/W, Deck Lid Lock Striker	30.074	Seal, Tire Well Cover	30.058
Screw with L/W, Directional Signal Light Switch	7.620	Seal, Water Pump	6.300
Screw with L/W, Front Door Glass Run Channel	30.202	Seal Package, Hydra-Matic Reverse Unit Reverse Piston	9.685
Screw with L/W, Front Door Hinge	30.108	Seal and Washer Package, Hydra-Matic Throttle Inner Control Lever	9.720
Screw with L/W, Front Door Lock	30.104	Sealed Beam Unit, Foglight	40.112
Screw with L/W, Horn Blowing Bezel	7.527	Sealed Beam Unit, Headlight	7.540
Screw with L/W, Hydra-Matic Gear Shift Lever Indicator	9.745	Sealed Beam Unit, Spotlight	40.104
Screw with L/W, Hydra-Matic Gear Shift Lever Indicator Cover and Lens	9.750	Sealer, Flywheel to Crankshaft	1.360
Screw with L/W, Hydra-Matic Gear Shift Upper Bracket Plate	9.755	Sealzit, Windshield	40.133
Screw with L/W, Instrument Board Heater Control Panel Brace	30.412	Seat, Headlight Sealed Beam	7.540
Screw with L/W, Instrument Board Glove Box	30.404	Seat, Hydra-Matic Rear Pump Discharge Check Valve	9.605
Screw with L/W, License Light Cable and Socket	30.0702	Seat, Shock Absorber Lower	20.004
Screw with L/W, License Light Lens Retainer	30.0702	Seat, Steering Drag Link End Socket	14.206
Screw with L/W, Rear Compartment Windbreak	30.611	Seat Cover Set	40.132
Screw with L/W, Rear Door Hinge	30.126	Set Screw, Clutch Release Fork	8.125
Screw with L/W, Rear Door Lock	30.122	Set Screw, Front Door Lock Cylinder Retainer	30.114
Screw and Washer, Carburetor Air-Horn Attaching	3.680	Shackle and Link Kit, Rear Spring	12.220
Screw and Washer, Carburetor Body Flange Attaching	3.680	Shaft, Accelerator Cross	3.430
Screw and Washer, Carburetor Dust Cover Attaching	3.680	Shaft, Accelerator Extension	3.450
Screw and Washer Package, Hydra-Matic Front Oil Pump	9.535	Shaft, Clutch Pedal Cross	8.155
Seal, Brake Pedal Dust	15.102	Shaft, Clutch Release	8.125
Seal, Clutch Pedal	8.140	Shaft, Distributor Drive	7.324
Seal, Clutch Pedal Cross Shaft	8.155	Shaft, Exhaust Manifold Heat Control Valve	5.010
Seal, Crankshaft Oil	1.303	Shaft, Gear Shift	9.310
Seal, Front Fender Splash Shield	18.010	Shaft, Hydra-Matic Gear Shift	9.740
Seal, Front Fender Splash Shield Access Cover	18.010	Shaft, Oil Pump Drive	2.210
Seal, Front Suspension Lower Arm	13.018	Shaft, Oil Pump Idler Gear	2.215
Seal, Front Suspension Lower Arm Outer Pivot	13.012	Shaft, Overdrive Main	9.235
Seal, Front Suspension Upper Arm	13.014	Shaft, Overdrive Shift Control	9.255
Seal, Front Suspension Upper Arm Outer Pivot	13.010	Shaft, Rear Axle	12.080
Seal, Front Wheel Inner Bearing	16.010	Shaft, Rear Axle Differential Side Pinion	12.020
		Shaft, Rear Door Ventilator Handle	30.216
		Shaft, Transmission Main	9.120
		Shaft, Transmission Reverse Idler Gear	9.175
		Shaft, Water Pump Drive	6.300
		Shaft and Arm, Clutch Pedal	8.145
		Shaft and Coupling, Distributor Main Drive	7.344
		Shaft and Gear, Hydra-Matic Main	9.660
		Shaft and Joints, Propeller	11.000
		Shaft and Lever, Carburetor Throttle	3.680
		Shaft and Planet Gears, Hydra-Matic Reverse Output	9.665
		Shaft and Plate, Distributor Drive	7.324
		Shaft and Roller, Steering Gear	14.116

ALPHABETICAL INDEX

NAME AND PART DESCRIPTION	GROUP NUMBER	NAME AND PART DESCRIPTION	GROUP NUMBER
Shaft and Yoke, Propeller	11.002	Snap Ring, Distributor Cam and Shaft	7.332
Shaver, Electric.	40.149	Snap Ring, Hydra-Matic Driving Torus.	9.505
Shell, Body	30.050	Snap Ring, Hydra-Matic Front Clutch Control Annular Piston	9.570
Shield, Front Fender Splash.	18.010	Snap Ring, Hydra-Matic Front Drum	9.565
Shield, Steering Drag Link Stud.	14.204	Snap Ring, Hydra-Matic Front Unit Drive Gear	9.560
Shim, Body Hold Down Bolt	30.014	Snap Ring, Hydra-Matic Rear Clutch Control Annular Piston	9.615
Shim, Distributor Breaker Plate.	7.310	Snap Ring, Hydra-Matic Rear Clutch Hub	9.620
Shim, Distributor Drive Shaft Coupling.	7.330	Snap Ring, Hydra-Matic Reverse Unit Internal Gear	9.685
Shim, Front Door Hinge.	30.108	Snap Ring, Hydra-Matic Reverse Unit Oil Pump and Governor Drive Gear	9.670
Shim, Front Door Lock Striker Plate.	30.104	Snap Ring, Hydra-Matic Reverse Unit Piston Release Spring.	9.685
Shim, Front Fender to Cowl.	18.000	Snap Ring, Hydra-Matic Reverse Unit Planet Carrier.	9.680
Shim, Front Suspension Upper Arm Inner Pivot	13.016	Snap Ring, Hydra-Matic Reverse Unit Shaft Bearing	9.685
Shim, Hydra-Matic Reverse Shifter to Case	9.695	Snap Ring, Overdrive Main Shaft.	9.240
Shim, Rear Axle Differential Bearing.	12.035	Snap Ring, Overdrive Main Shaft Bearing	9.240
Shim, Rear Axle Pinion Bearing, Front	12.050	Snap Ring, Overdrive Ring Gear	9.245
Shim, Rear Axle Pinion Bearing, Rear	12.060	Snap Ring, Overdrive Stationary Gear	9.210
Shim, Rear Axle Shaft Bearing	12.080	Snap Ring, Overdrive Stationary Gear Cover Plate	9.215
Shim, Rear Door Hinge	30.126	Snap Ring, Speedometer Drive Gear.	9.286
Shim, Rear Door Lock Striker Plate	30.122	Snap Ring, Transmission Drive Pinion Bearing	9.110
Shim, Steering Gear Column and Worm	14.110	Snap Ring, Transmission Main Shaft Bearing	9.140
Shim, Steering Gear Support.	14.120	Snap Ring, Transmission Second and High Synchronizer Hub	9.125
Shim, Steering Knuckle King Pin Thrust Bearing	13.004	Snap Ring, Transmission Second and High Synchronizer Shifting Plate	9.130
Shock Absorber, Front	20.000	Snap Ring, Universal Joint.	11.030
Shock Absorber, Rear	20.010	Snap Ring, Water Pump Drive Shaft	6.300
Shoe, Transmission Shifting.	9.185	Socket, Directional Indicator Light	7.637
Shoe Set, Brake	15.004	Socket, Headlight Beam Indicator Light	7.556
Shroud, Radiator	6.480	Socket, Instrument Lights	7.643
Silencer, Hood.	18.100	Socket, Pillar Light	30.707
Sleeve, Body Wiring Harness Terminal	30.702	Socket, Steering Drag Link End	14.206
Sleeve, Carburetor Choke Tube.	3.010	Socket, Tail and Stop Light.	30.702
Sleeve, Chassis Wiring Harness Terminal	7.700	Solenoid, Overdrive	7.800
Sleeve, Cigar Lighter Feed Cable Terminal	7.657	Solenoid, Starting Motor	7.265
Sleeve, Front Shock Absorber.	20.002	Solvent Fluid, Windshield Washer	40.116
Sleeve, Fuel Gauge Tank Unit Cable Terminal	7.660	Spacer, Back-Up Light Switch.	40.108
Sleeve, Gear Shift Rod to Lever	9.340	Spacer, Deck Lid Handle	30.068
Sleeve, Headlight Cable Terminal	7.546	Spacer, Deck Lid Hinge Bolt	30.064
Sleeve, Hydra-Matic Brake Drum Oil Delivery.	9.575	Spacer, Distributor Cam and Shaft	7.332
Sleeve, Hydra-Matic Governor Oil Delivery	9.705	Spacer, Distributor Drive Shaft Coupling	7.330
Sleeve, Hydra-Matic Oil Level Indication	9.520	Spacer, Distributor Drive Shaft Plate to Base	7.324
Sleeve, Overdrive Control to Lever.	9.270	Spacer, Front Bumper Bar.	20.200
Sleeve, Overdrive Governor.	9.265	Spacer, Front Bumper Wing.	20.260
Sleeve, Overdrive Rail Switch to Governor Cable Terminal	7.810	Spacer, Front Suspension Spring.	13.024
Sleeve, Overdrive Wiring Harness Terminal	7.812	Spacer, Generator Brush Arm	7.420
Sleeve, Transmission Second and High Synchronizer.	9.130		
Sleeve, Transmission Shifting Lever Poppet Ball.	9.190		
Slinger, Crankshaft Oil	1.300		
Slinger, Rear Axle Pinion Bearing, Front.	12.050		
Slinger, Transmission Drive Pinion Bearing	9.105		
Slip Yoke and Plug, Propeller.	11.004		

ALPHABETICAL INDEX

NAME AND PART DESCRIPTION	GROUP NUMBER	NAME AND PART DESCRIPTION	GROUP NUMBER
Spacer, Generator Drive End Plate Bearing	7.428	Spring, Carburetor Vacuum Piston	3.680
Spacer, Generator Mounting	7.400	Spring, Clutch Pedal Cross Shaft Coupling	
Spacer, Glove Box Door Lock	30.404	Take-Up	8.155
Spacer, Headlight Switch	7.553	Spring, Clutch Pedal Return	8.140
Spacer, Heater Blower Switch	40.002	Spring, Clutch Pressure Plate	8.104
Spacer, Horn Blowing Contact Ring	7.527	Spring, Clutch Pressure Plate Lever	8.104
Spacer, Hydra-Matic Driven Torus	9.505	Spring, Clutch Release Bearing	8.120
Spacer, License Light Hinge Bolt	30.0702	Spring, Deck Lid Handle Lock Cylinder	
Spacer, Rear Axle Pinion Bearing, Front	12.050	Cover	30.068
Spacer, Rear Bumper Bar	20.250	Spring, Deck Lid Handle Pawl	30.068
Spacer, Rear Bumper Guard	20.265	Spring, Deck Lid Lock	30.074
Spacer, Rear License Plate Bracket	20.115	Spring, Deck Lid Lock Latch Link	30.074
Spacer, Steering Column Jacket Bearing	14.108	Spring, Deck Lid Support	30.064
Spacer, Transmission Countershaft Gear		Spring, Directional Indicator Light Socket	7.637
Bearings	9.160	Spring, Distributor Cap	7.302
Spacer, Windshield Garnish Moulding	30.304	Spring, Distributor Drive Shaft	7.324
Spacer, Windshield Wiper Control	30.354	Spring, Distributor Vacuum Chamber	7.338
Spark Plug	7.375	Spring, Front Brake Cylinder Return	15.020
Speaker Package, Rear Seat Radio	40.100	Spring, Front Door Handle	30.114
Speednut, Body Hold Down Bolt	30.012	Spring, Front Door Regulator Handle	30.208
Speednut, Deck Lid Handle Lock Cylinder		Spring, Front Door Remote Control Handle	
Cover	30.068	Escutcheon	30.106
Speednut, Deck Lid Name Plate	30.076	Spring, Front Door Ventilator Handle	30.206
Speednut, Front Fender Name Plate	18.004	Spring, Front Door Ventilator Pivot	30.206
Speednut, Front Fender Splash Shield	18.010	Spring, Front Suspension	13.024
Speednut, Front Fender to Radiator Cradle		Spring, Fuel Tank Filler Cover	30.040
and Bracket	18.000	Spring, Gear Shift Lower Lever to Cam	9.320
Speednut, Front Stone Deflector Panel	6.492	Spring, Gear Shift Shaft End to Lever	9.310
Speednut, Headlight Cable Terminal Block	7.550	Spring, Gear Shift Upper Lever Pivot Pin	9.300
Speednut, Hood Medallion	18.130	Spring, Generator Brush	7.420
Speednut, Instrument Board Glove Box	30.404	Spring, Hand Brake Equalizing Lever	15.230
Speednut, Instrument Board Mounting	30.402	Spring, Headlight Beam Indicator Light	
Speednut, Instrument Board Radio Control		Socket	7.556
Cover	30.410	Spring, Headlight Sealed Beam Seat	7.540
Speednut, Radiator Grille	6.490	Spring, Hood Hinge	18.200
Speednut, Radiator Mounting	6.400	Spring, Hood Lock Bolt Plate Release	18.148
Speednut, Radiator Shroud	6.480	Spring, Hood Lock Latch	18.150
Speednut, Radiator Splash Panel	6.465	Spring, Hood Lock Safety Catch	18.152
Speednut, Rear Door Arm Rest	30.614	Spring, Hood Ornament	18.110
Speednut, Rear License Plate	20.115	Spring, Horn Blowing Ground	7.527
Speednut, Rear Quarter Arm Rest	30.6101	Spring, Hydra-Matic Front Clutch Drive	
Speednut, Rear Seat Back Outer Panel Hinge		Plate Release	9.570
Pivot Plate	30.560	Spring, Hydra-Matic Front Pump Relief	
Speednut, Rear Stone Deflector	30.048	Valve	9.550
Speedometer Head	19.110	Spring, Hydra-Matic Front Servo Booster	9.595
Spot Remover	40.134	Spring, Hydra-Matic Front Servo Retracting	9.595
Spotlight Package	40.104	Spring, Hydra-Matic Gear Shift Lever	9.735
Spring, Accelerator Linkage Tension	3.400	Spring, Hydra-Matic Gear Shift Lower	
Spring, Brake Pedal Arm and Shaft Return	15.102	Bracket	9.760
Spring, Brake Shoe Pull Back	15.004	Spring, Hydra-Matic Manual Oil Control	
Spring, Carburetor Fast Idle Cam	3.680	Valve Detent Ball	9.715
Spring, Carburetor Intake Needle	3.680	Spring, Hydra-Matic Manual Oil Control	
Spring, Carburetor Metering Rod	3.680	Valve Detent Plunger	9.715
Spring, Carburetor Plunger	3.680	Spring, Hydra-Matic Oil Pressure Regulator	
Spring, Carburetor Pump Lower	3.680	Valve	9.555
Spring, Carburetor Pump Upper	3.680	Spring, Hydra-Matic Parking Blocker Piston	9.695

ALPHABETICAL INDEX

NAME AND PART DESCRIPTION	GROUP NUMBER	NAME AND PART DESCRIPTION	GROUP NUMBER
Spring, Hydra-Matic Parking Brake Return	9.695	Springwasher, Deck Lid Lock Latch Pin Support	30.074
Spring, Hydra-Matic Rear Clutch Plate Release	9.615	Springwasher, Deck Lid Prop.	30.064
Spring, Hydra-Matic Rear Pump Discharge Check Valve	9.605	Springwasher, Deck Lid Support	30.064
Spring, Hydra-Matic Rear Servo Accumulator Piston	9.645	Springwasher, Distributor Breaker Plate . .	7.310
Spring, Hydra-Matic Rear Servo Booster Piston	9.635	Springwasher, Front Door Ventilator Handle	30.206
Spring, Hydra-Matic Rear Servo Compensator Piston	9.650	Springwasher, Gear Shift Rod to Lever. . . .	9.340
Spring, Hydra-Matic Reverse Anchor Retracting	9.695	Springwasher, Hand Brake Operating Lever	15.008
Spring, Hydra-Matic Reverse Clutch Release	9.685	Springwasher, Hydra-Matic Gear Shift Lower Lever to Transmission Rod	9.775
Spring, Hydra-Matic Reverse Shifter Blocker Piston.	9.695	Springwasher, Hydra-Matic Throttle Control Lower Bellcrank to Transmission Rod	9.810
Spring, Hydra-Matic Reverse Unit Piston Release	9.685	Springwasher, Rear Door Ventilator Handle	30.216
Spring, Hydra-Matic Throttle Control Lower Bellcrank Pull Back	9.805	Springwasher, Tire Well Cover Hold Down Latch.	30.058
Spring, Hydra-Matic Torus Check Valve. . .	9.505	Stand, Foglight Display	40.112
Spring, Ignition Switch Cylinder Lock. . . .	7.350	Stand, Spotlight Display.	40.104
Spring, Instrument Board Radio Control Cover.	30.410	Starting Motor.	7.222
Spring, Instrument Lights Socket	7.643	Stop, Deck Lid Support Link.	30.064
Spring, Intake and Exhaust Valve.	1.720	Stop, Front Door Ventilator Pivot	30.206
Spring, Master Brake Cylinder	15.035	Stop, Hydra-Matic Governor Plunger	9.705
Spring, Moulding Clip Backing	30.099	Stop, Hydra-Matic Parking Blocker Piston Release	9.695
Spring, Oil Pressure Relief Valve.	2.410	Stop, Rear Door Ventilator.	30.216
Spring, Overdrive Free Wheeling Cam Bearing	9.230	Stop, Rear Wheel Opening Cover	30.0911
Spring, Overdrive Shift Control Shaft. . . .	9.255	Stop Pin, Hydra-Matic Reverse Shifter Blocker Piston.	9.695
Spring, Pillar Light Socket.	30.707	Strainer, Carburetor Bowl Cover	3.680
Spring, Rear	12.200	Strainer, Carburetor Pump	3.680
Spring, Rear Brake Cylinder Piston Return	15.030	Strap, Ignition Coil Mounting	7.346
Spring, Rear Door Handle	30.134	Strap, Oil Filter.	2.300
Spring, Rear Door Regulator Handle	30.218	Striker, Deck Lid Lock	30.074
Spring, Rear Door Regulator Pinion Lock. .	30.218	Striker, Front Door Ventilator Handle	30.206
Spring, Rear Door Remote Control Handle Escutcheon	30.124	Striker, Rear Door Ventilator Handle. . . .	30.216
Spring, Rear Door Ventilator Handle	30.216	Strip, Rear Compartment Skid	30.075
Spring, Rear Door Ventilator Pivot	30.216	Strut, Clutch Pressure Plate Lever	8.104
Spring, Rear Seat Back Filler Panel	30.560	Stud, Distributor Mounting Adapter	7.342
Spring, Seat Track Adjuster Latch	30.554	Stud, Distributor Terminal	7.300
Spring, Starting Motor Bendix Drive	7.244	Stud, Exhaust Manifold	5.000
Spring, Starting Motor Brush	7.236	Stud, Exhaust Pipe	5.040
Spring, Steering Column Jacket Bearing. . .	14.108	Stud, Fuel Pump to Block.	3.470
Spring, Steering Drag Link End Socket. . . .	14.206	Stud, Hood Hinge	18.200
Spring, Tail and Stop Light Socket.	30.702	Stud, Hood Ornament	18.110
Spring, Transmission Shifting Lever Poppet Ball.	9.190	Stud, License Light Mounting	30.0702
Spring Clip, Moulding	30.099	Stud, Intake to Exhaust Manifold	3.000
Spring Set, Distributor Drive Shaft Governor Weight	7.324	Stud, Manifold to Block	3.000
Springwasher, Deck Lid Handle.	30.068	Stud, Oil Pump.	2.200
		Stud, Rear Axle Brake Tube	15.078
		Stud, Tail Light Body	7.571
		Stud, Tire Well Cover Hold Down	30.058
		Stud, Valve Tappet Cover.	1.750
		Stud, Water Outlet Elbow.	6.425
		Support, Air Duct Valve Cable	30.034
		Support, Air Scoop	17.005
		Support, Clutch Pedal Cross Shaft.	8.155

ALPHABETICAL INDEX

NAME AND PART DESCRIPTION	GROUP NUMBER	NAME AND PART DESCRIPTION	GROUP NUMBER
Support, Deck Lid	30.064	Terminal, Instrument Lights	7.643
Support, Deck Lid Lock Latch Pin	30.074	Thermostat, Engine	6.410
Support, Distributor Cap Spring	7.302	Thermostat, Exhaust Manifold Heat Control	5.010
Support, Front Bumper Bar	20.208	Throttle Valve, Carburetor	3.680
Support, Front Shock Absorber	17.020	Thru Bolt, Generator Commutator End Plate	7.412
Support, Hydra-Matic Reverse Unit Internal Gear	9.685	Thru Bolt, Starting Motor Commutator End Plate	7.234
Support, Instrument Board Glove Box	30.404	Thrustblock, Rear Axle Shaft	12.020
Support, Instrument Board to Dash Radio	30.402	Thrustblock, Rear Axle Shaft	12.080
Support, Package Compartment Lower Panel	30.562	Thrustwasher, Distributor Drive Shaft	7.324
Support, Rear Bumper Bar	20.252	Thrustwasher, Hydra-Matic Front Drum	9.565
Support, Rear License Plate Adjusting	20.115	Thrustwasher, Hydra-Matic Front Unit Drive Gear	9.560
Support, Rear Seat Back	30.560	Thrustwasher, Hydra-Matic Main Shaft	9.660
Support, Shock Absorber Lower	20.004	Thrustwasher, Hydra-Matic Rear Clutch Hub	9.620
Support, Steering Gear	14.120	Thrustwasher, Hydra-Matic Reverse Unit Center Gear	9.675
Support, Steering Gear Jacket Cover	14.122	Thrustwasher, Hydra-Matic Reverse Unit Internal Gear	9.685
Support, Steering Knuckle	13.008	Thrustwasher, Rear Axle Differential Side Gear	12.020
Support, Tail Light Mounting, Upper	30.040	Thrustwasher, Starting Motor Armature	7.224
Support, Tail Pipe (at Frame "X" Member).	5.075	Thrustwasher, Steering Gear Shaft and Roller	14.116
Switch, Back-Up Light	40.108	Thrustwasher, Transmission Gear Cluster	9.155
Switch, Directional Signal Light	7.620	Tie Rod, Steering	14.216
Switch, Foglight	40.112	Tie Rod End, Steering	14.216
Switch, Glove Compartment Light Automatic	30.710	Tool Kit	20.300
Switch, Headlight	7.553	Torus, Hydra-Matic	9.505
Switch, Headlight Dimmer	7.554	Transmission	9.000
Switch, Heater Blower	40.002	Transmission, Hydra-Matic	9.500
Switch, Hydra-Matic Gear Shift Neutralizer	9.765	Trough, Deck Opening Side Drain	30.040
Switch, Ignition	7.350	Trunion, Hydra-Matic Gear Shift Lower Lever to Transmission Rod	9.775
Switch, Overdrive Kickdown	7.806	Trunion, Hydra-Matic Throttle Control Lower Bellcrank to Transmission	9.810
Switch, Overdrive Rail	7.802	Tube, Carburetor Choke	3.010
Switch, Pillar Light Automatic	30.707	Tube, Distributor Vacuum Chamber	7.340
Switch, Starting	7.270	Tube, Front Brake	15.064
Switch, Stop Light	7.650	Tube, Fuel Pump to Carburetor	3.560
Switch, Windshield Wiper	30.354	Tube, Fuel Tank Filler	3.530
Swivel, Hydra-Matic Throttle Control Upper to Lower Bellcrank Rod	9.800	Tube, Fuel Tank to Fuel Pump	3.550
Synchronizer Unit, Transmission Second and High	9.125	Tube, Heater Temperature Control Valve	40.002
T		Tube, Master Brake Cylinder to Frame Tee	15.060
Tacking Strip, Trim	30.636	Tube, Master Brake Cylinder to Rear Brake Hose	15.070
Tank, Fuel	3.520	Tube, Oil Filler	2.412
Tank, Windshield Washer	40.116	Tube, Oil Filter Inlet	2.315
Tappet, Valve	1.740	Tube, Oil Filter Outlet	2.316
Tapping Plate, Front Suspension Lower Arm Bumper	13.022	Tube, Oil Return	2.405
Tee, Master Brake Cylinder Frame	15.062	Tube, Rear Axle Brake	15.078
Tee, Rear Axle Brake Tube	15.076	Tube, Vacuum Pump to Windshield Wiper	3.560
Tee, Vacuum Antenna	40.102	Tube, Windshield Wiper Motor Intake	30.364
Terminal, Body Wiring Harness	30.702		
Terminal, Chassis Wiring Harness	7.700		
Terminal, Cigar Lighter Feed Cable	7.657		
Terminal, Directional Indicator Light	7.637		
Terminal, Fuel Gauge Tank Unit Cable	7.660		
Terminal, Headlight Beam Indicator Light	7.556		
Terminal, Horn Blowing Ring Cable	7.536		

ALPHABETICAL INDEX

NAME AND PART DESCRIPTION	GROUP NUMBER	NAME AND PART DESCRIPTION	GROUP NUMBER
Tube and Fitting, Rear Window Wiper	40.162	Washer, Pillar Light Socket	30.707
Tube and Fitting, Windshield Washer	40.116	Washer, Rear Axle Pinion Bearing, Front. . .	12.050
U			
"U" Bolt, Hydra-Matic Gear Shift Lower Bracket	9.760	Washer, Rear Door Ventilator Pivot	30.216
"U" Bolt, Propeller Shaft	11.000	Washer, Rear License Plate Bracket	20.115
"U" Bolt, Rear Spring Mounting	12.215	Washer, Tail and Stop Light Socket	30.702
Union, Fuel Tank to Fuel Pump Tube	3.550	Washer, Transmission Countershaft Gear Bearings	9.160
V			
Valve, Carburetor Choke	3.680	Washer, Windshield Wiper Arm Pivot Link. .	30.358
Valve, Exhaust	1.720	Washer, Windshield Wiper Motor to Bracket	30.352
Valve, Exhaust Manifold Heat Control	5.010	Weathercord, Door Opening	30.604
Valve, Heater Water Temperature Control . .	40.002	Weathercord, Rear Deck Opening	30.6085
Valve, Hydra-Matic Front Pump Relief	9.550	Weatherseal, Front Door Glass	30.204
Valve, Hydra-Matic Front Servo Downshift 4th to 3rd	9.600	Weatherseal, Front Door Inner Panel	30.102
Valve, Hydra-Matic Manual Oil Control	9.715	Weatherseal, Front Door Opening	30.102
Valve, Hydra-Matic Oil Pressure Regulator . .	9.555	Weatherseal, Quarter Panel Window Glass . .	30.212
Valve, Intake	1.720	Weatherseal, Rear Door Glass	30.212
Valve, Master Brake Cylinder Check	15.035	Weatherseal, Rear Door Inner Panel	30.120
Valve, Oil Pressure Relief	2.410	Weatherseal, Rear Quarter Inner Panel	30.040
Valve, Vacuum Antenna	40.102	Weatherseal, Steering Column Jacket	14.106
Valve, Windshield Washer Control	40.116	Weatherstrip, Deck Lid	30.062
Valve and Collar, Air Duct	30.034	Weatherstrip, Front Door Garnish Moulding	30.101
Ventilator, Front Door	30.206	Weatherstrip, Front Door Glass Lifter Channel	30.202
Ventilator, Rear Door	30.216	Weatherstrip, Front Door Hinge Pillar	30.102
Ventshade	40.150	Weatherstrip, Front Door Ventilator	30.206
W			
Washer, Brake Pedal Arm and Shaft	15.102	Weatherstrip, Fuel Tank Filler Housing	30.040
Washer, Carburetor Throttle Shaft	3.680	Weatherstrip, Quarter Panel Garnish Moulding	30.119
Washer, Distributor Breaker Plate	7.310	Weatherstrip, Quarter Panel Glass Lifter Channel	30.210
Washer, Distributor Breaker Plate Clamp . . .	7.310	Weatherstrip, Quarter Panel Window Glass, Rear	30.216
Washer, Distributor Vacuum Chamber	7.338	Weatherstrip, Rear Door Garnish Moulding.	30.119
Washer, Front Door Ventilator Pivot	30.206	Weatherstrip, Rear Door Glass Lifter Channel	30.210
Washer, Front Seat Back Center Hinge	30.616	Weatherstrip, Rear Door Hinge Pillar	30.120
Washer, Front Seat Back Side Hinge	30.616	Weatherstrip, Rear Door Opening	30.120
Washer, Gear Shift Lower Lever to Cam	9.320	Weatherstrip, Rear Door Ventilator	30.216
Washer, Hand Brake Handle	15.200	Weatherstrip, Rear Window Glass	30.502
Washer, Hood Lock Control	18.154	Weatherstrip, Windshield	30.302
Washer, Horn Blowing Contact Terminal . . .	7.527	Well, Rear Floor Pan Tire	30.058
Washer, Horn Blowing Ring Cable Terminal . .	7.536	Welsh Plug, Carburetor Choke Cylinder . . .	3.680
Washer, Hydra-Matic Front Oil Pump Cover to Body	9.535	Wheel	16.000
Washer, Hydra-Matic Front Oil Pump Locating	9.535	Wheel, Steering	14.126
Washer, Hydra-Matic Gear Shift Lever Anti-Rattle	9.735	Wick, Distributor	7.302
Washer, Hydra-Matic Gear Shift Lower Bracket Seal	9.760	Wick, Distributor Cam and Shaft	7.332
Washer, Hydra-Matic Gear Shift Lower Lever to Transmission Rod	9.775	Windbreak, Rear Compartment Seat Back . .	30.611
Washer, License Light Mounting Stud	30.0702	Windshield Visor Package	40.115
Washer, Oil Pressure Relief Valve	2.410	Windshield Washer Package	40.116
Washer, Overdrive Main Shaft Bearing	9.240	Wing, Front Bumper Guard	20.260
		Wings, Air Vent	40.135
		Wing Nut, Air Cleaner	4.000
		Wing Nut, Deck Lid Support Bracket	30.064
		Wing Nut, License Light Hinge Bolt	30.0702
		Wiper Package, Rear Window	40.162
		Wiring Package, Back-Up Light	40.108
		Wrench, Wheel Bolt	20.300

NOTES

Handwritten scribbles and marks on the right side of the page.



BUILD



OWNER

CONFIDENCE...

WITH

*Factory Approved
and Inspected
Parts and Accessories*