

ALPHABETICAL INDEX

NAME AND PART DESCRIPTION	GROUP NUMBER	NAME AND PART DESCRIPTION	GROUP NUMBER
A			
Access Cover, Front Fender Splash Shield	18.010	Bar, Front Sway Eliminator	13.200
Adapter, Overdrive Housing	9.145	Bar, Radiator Grille	6.490
Adapter, Water Temperature Gauge to Cylinder Block	6.444	Bar, Rear Bumper.	20.250
Adapter Ring, Engine Thermostat.	6.410	Bar, Windshield Division	30.306
Adjuster, Front Seat Track	30.554	Base, Bumper Jack	20.300
Adjusting Link, Steering Tie Rod	14.216	Base, Distributor	7.302
Air Duct Package	40.010	Base and Clamp, Cigar Lighter	7.652
Alcohol, Anti-Freeze	40.146		40.157
Antenna, Radio	40.102	Bearing, Camshaft.	1.510
Anti-Freeze, Permanent.	40.146	Bearing, Clutch Control Bell Crank	8.157
Anti-Squeak, Access Cover.	18.010	Bearing, Clutch Release.	8.120
Anti-Squeak, Door Hinge.	30.108	Bearing, Connecting Rod.	1.405
Anti-Squeak, Fuel Tank	3.520	Bearing, Crankshaft Main.	1.315
Anti-Squeak, Hood.	18.100	Bearing, Overdrive Free Wheeling Cam Roller	9.230
Anti-Squeak, Hood Lock Bolt Plate.	18.148	Bearing, Overdrive Main Shaft.	9.240
Anti-Squeak, Hood Lock Latch Plate.	18.150	Bearing, Steering Column Jacket	14.108
Anti-Squeak, Radiator Cradle to Shroud Supports	6.455	Bearing, Steering Knuckle King Pin Thrust.	13.004
Anti-Squeak, Radiator Shroud	6.480	Bearing, Transmission Countershaft Gear.	9.160
Anti-Squeak, Rear Deck Lid Hinge	30.064	Bearing, Transmission Drive Pinion.	9.105
Anti-Squeak, Steering Gear Support	14.120	Bearing, Transmission Main Shaft	9.140
Anti-Squeak, Stone Deflector Panel to Shroud.	6.492	Bearing, Transmission Main Shaft Roller.	9.120
Anti-Squeak, Tie Brace to Fender	18.000	Bearing Cone, Front Wheel.	16.010
Arm, Distributor Advance.	7.308	Bearing Cone, Rear Axle Differential	12.035
Arm, Door Check	30.112	Bearing Cone, Rear Axle Pinion, Front.	12.050
Arm, Front Suspension Lower.	13.018	Bearing Cone, Rear Axle Pinion, Rear	12.060
Arm, Front Suspension Upper	13.014	Bearing Cone, Rear Axle Shaft.	12.080
Arm, Steering Gear Lever Pitman	14.200	Bearing Cup, Front Wheel.	16.010
Arm, Steering Knuckle.	13.006	Bearing Cup, Rear Axle Differential.	12.035
Arm, Windshield Wiper	30.358	Bearing Cup, Rear Axle Pinion, Front.	12.050
Arm and Bracket, Sun Visor Panel.	30.626	Bearing Cup, Rear Axle Pinion, Rear	12.060
Arm Rest Package, Door	40.159	Bearing Cup, Rear Axle Shaft	12.080
Armature, Generator.	7.402	Bearing and Sleeve, Clutch Release	8.120
Armature, Starting Motor.	7.224	Bell Crank, Accelerator	3.090
Ash Receiver, Instrument Board	30.406	Bell Crank, Clutch Control	8.157
Ash Receiver, Rear Quarter	30.807	Belt, Fan.	6.000
Auto Cleaner and Wax	40.134	Bendix Drive, Starting Motor.	7.244
Auto Polish and Cleaner.	40.134	Bezel, Back-Up Light Lens.	40.108
Axle, Rear.	12.000	Bezel, Horn Blowing Medallion	7.527
B			
Back-Up Light Package	40.108	Bezel, Ignition Switch.	7.350
Baffle, Defroster.	40.008	Bezel, Instrument Cluster.	30.412
Baffle, Headlight Dimmer Switch	7.554	Bezel, Spotlight.	40.104
Baffle, Transmission Main Shaft Bearing.	9.140	Binding, Deck Opening Wire-On.	30.612
Bail, Fuel Pump Bowl	3.490	Binding, Door Opening Wire-On.	30.612
Ball, Transmission Shifting Lever Poppet.	9.190	Black Rubber Finish	40.134
Ball Stud, Rear Seat Back.	30.560	Blade, Windshield Wiper.	30.358
Band, Generator Cover.	7.426	Bleeder Valve, Brake Cylinder	15.016
Band, Starting Motor Cover.	7.238	Block, Cylinder.	1.100
Bar, Door Glass Division	30.202	Block, Headlight Cable Terminal	7.550
Bar, Door Ventilator Division	30.206	Blocking Ring, Overdrive Stationary Gear.	9.205
Bar, Front Bumper	20.200	Blocking Ring, Transmission Second and High Synchronizer Sleeve	9.130
		Board, Instrument.	30.402
		Body, Headlight.	7.540
		Body, Oil Pump.	2.205
		Body, Tail Light	7.571
		Body, Valve Cover Plate Vent	1.760

ALPHABETICAL INDEX

NAME AND PART DESCRIPTION	GROUP NUMBER	NAME AND PART DESCRIPTION	GROUP NUMBER
Body, Water Pump	6.300	Boot, Front Brake Cylinder	15.020
Body Flange, Carburetor	3.690	Boot, Master Brake Cylinder	15.035
Bolt, Air Cleaner	4.000	Boot, Overdrive Governor	9.265
Bolt, Battery Cable	7.510	Boot, Rear Brake Cylinder	15.030
Bolt, Body Hold Down	30.012	Bow, Headlining	30.612
Bolt, Clutch Control Bell Crank Pivot . .	8.157	Bowl, Fuel Pump	3.490
Bolt, Clutch Pressure Plate	8.104	Brace, Fender to Cowl	18.000
	8.106	Brace, Instrument Board to Dash	30.402
Bolt, Connecting Rod	1.400	Brace, Rear Fender	30.041
Bolt, Crankshaft	1.300	Brace, Storage Battery	7.500
Bolt, Crankshaft Main Bearing Cap . . .	1.320	Bracket, Accelerator Bell Crank	3.090
Bolt, Flywheel	1.360	Bracket, Accelerator Pedal to Floor Pan	3.070
Bolt, Front Brake Support Plate	15.000	Bracket, Air Cleaner Support	4.060
Bolt, Front Bumper Bar	20.200	Bracket, Back-Up Light Switch Mounting	40.108
Bolt, Front Seat Back Stop Adjusting . .	30.616	Bracket, Brake Pedal	15.102
Bolt, Front Suspension Lower Arm Pivot Reinforcement	13.020	Bracket, Cowl to Fender	18.000
Bolt, Generator Mounting	7.400	Bracket, Defroster Control Cable Support	40.008
Bolt, Hood Bumper	18.100	Bracket, Directional Signal Light Flasher	40.142
Bolt, Hood Lock Bolt Plate	18.148	Bracket, Directional Signal Switch	40.142
Bolt, Master Brake Cylinder	15.035	Bracket, Door Check Arm Pivot	30.112
Bolt, Oil Filter Fuel Pump to Block . . .	2.300	Bracket, Engine Front Support	17.030
Bolt, Overdrive Control	9.270	Bracket, Exhaust Muffler to Frame . . .	5.060
Bolt, Piston Pin	1.420	Bracket, Fresh Air Intake Tube Mounting	40.010
Bolt, Radiator Cradle to Shroud Supports	6.455	Bracket, Front Bumper Support Cover . .	20.210
Bolt, Rear Axle Differential Case	12.015	Bracket, Front License Plate	20.100
Bolt, Rear Axle Gear and Pinion	12.045	Bracket, Gear Shift Upper Shaft	9.310
Bolt, Rear Axle Housing Cover	12.005	Bracket, Generator	7.465
Bolt, Rear Axle Shaft Oil Seal	12.080	Bracket, Heat Control Counterweight . .	5.020
Bolt, Rear Brake Support Plate	15.002	Bracket, Heater Hose Support	40.002
Bolt, Rear Bumper Bar	20.250	Bracket, Heater Switch Mounting	40.002
Bolt, Rear Deck Lid Prop to Lid	30.064	Bracket, Hood Prop	18.250
Bolt, Spare Tire Hold Down Clamp	16.030	Bracket, Horn	7.520
Bolt, Steering Gear	14.100	Bracket, Ignition Cable Support	7.360
Bolt, Steering Gear Housing End Cover . .	14.104	Bracket, Instrument Cluster Mounting . .	19.100
Bolt, Steering Gear Shaft Cover	14.118	Bracket, Master Brake Cylinder	15.035
Bolt, Steering Knuckle Arm	13.006	Bracket, Oil Filler Tube	2.412
Bolt, Transmission Drive Pinion Bearing Retainer	9.115	Bracket, Overdrive Control	9.275
Bolt, Transmission Main Shaft Bearing Retainer	9.145	Bracket, Quarter Panel Window Ventilator Locking	40.161
Bolt, Transmission Overdrive Housing . .	9.200	Bracket, Rear License Plate	20.115
Bolt, Valve Tappet Cover	1.750	Bracket, Rear Seat Back Adjusting Stop .	30.560
Bolt, Wheel	16.000	Bracket, Spotlight	40.104
Bolt with L/W, Clutch Pedal Cross Shaft Bushing	8.155	Bracket, Steering Gear Upper Support . .	14.120
Bolt with L/W, Front Brake Cylinder . .	15.010	Bracket, Ventilator Upper Pivot	30.206
Bolt with L/W, Gear Shift Lever Housing Cover	9.320	Bracket, Ventilator Window Locking . . .	30.206
Bolt with L/W, Gear Shift Upper Shaft Bracket	9.310	Bracket, Windshield Washer Mounting . .	40.116
Bolt with L/W, Horn Relay	7.525	Brush, Generator	7.420
Bolt with L/W, Oil Pump Cover	2.230	Brush, Starting Motor	7.236
Bolt with L/W, Radiator Grille Bar to Support	6.490	Bulb, Back-Up Light	40.108
Bolt with L/W, Rear Brake Cylinder . . .	15.012	Bulb, Courtesy Light	40.158
Bolt with L/W, Steering Gear Support Bracket	14.120	Bulb, Directional Signal Light	40.142
Boot, Accelerator Pedal	3.070	Bulb, Headlight Beam Indicator Light . .	7.556
		Bulb, Instrument Lights	7.643
		Bulb, Parking Light	7.564
		Bulb, Rear License Light	30.0702
		Bulb, Tail Light	7.574

ALPHABETICAL INDEX

NAME AND PART DESCRIPTION	GROUP NUMBER	NAME AND PART DESCRIPTION	GROUP NUMBER
Bumper, Brake Pedal Floor Plate	15.112	Cap, Front Wheel Grease	16.010
Bumper, Clutch Pedal Floor Plate	8.170	Cap, Fuel Tank	3.520
Bumper, Door Upper	30.112	Cap, Propeller Shaft Slip Yoke	11.005
Bumper, Front Bumper Support Cover . .	20.210	Cap, Radiator Filler	6.400
Bumper, Front Suspension Arm	13.022	Cap, Wheel Hub	16.026
Bumper, Hood	18.100	Carburetor	3.690
Bumper, Rear License Plate Bracket . .	20.115	Case, Rear Axle Differential	12.015
Bumper, Rear Seat Back Ball Stud	30.560	Case, Transmission	9.005
Bumper, Rear Spring (or Axle)	12.230	Catch, Hood Lock Safety	18.152
Bushing, Brake Pedal	15.102	Catch, Rear Seat Back Ball Stud	30.560
Bushing, Clutch Pedal Shaft	8.155	Chamber, Distributor Vacuum	7.334
Bushing, Distributor Base	7.302	Channel, Door Glass	30.202
Bushing, Exhaust Manifold Heat Control	5.010	Channel, Door Glass Lifter	30.202
Bushing, Flywheel Pilot	1.360	Check Valve, Manifold	1.760
Bushing, Front Suspension Lower Arm . .	13.018	Check Valve, Master Brake Cylinder . .	15.035
Bushing, Front Suspension Upper Arm . .	13.014	Chrome Coating	40.134
Bushing, Headlight Beam Indicator		Chrome Polish	40.134
Light Socket	7.556	Clamp, Air Cleaner	4.000
Bushing, Instrument Lights Socket	7.643	Clamp, Exhaust Pipe Hanger	5.050
Bushing, Oil Pump Body	2.205	Clamp, Exhaust Pipe to Muffler	5.055
Bushing, Rear Shock Absorber	20.010	Clamp, Fresh Air Intake Tube	40.010
Bushing, Rear Spring Front	12.200	Clamp, Fuel Tank Filler Hose	3.530
Bushing, Rear Spring Shackle	12.220	Clamp, Gear Shift Lever Housing	9.320
Bushing, Starting Motor Clutch Housing .	8.130	Clamp, Gear Shift Upper to Lower Shaft	9.310
Bushing, Steering Gear Housing	14.102	Clamp, Heater Hose	40.002
Bushing, Steering Knuckle King Pin . . .	13.002	Clamp, Muffler to Tail Pipe	5.060
Bushing, Steering Knuckle Support	13.008	Clamp, Oil Filler Tube to Air Cleaner .	1.760
Bushing, Transmission Reverse Idler		Clamp, Quarter Panel Window	
Gear	9.170	Ventilator Pivot	40.161
Button, Door Locking Handle	30.114	Clamp, Radiator Hose	6.420
Button Plug, Overdrive Kickdown Switch	7.806	Clamp, Spare Tire Hold Down	16.030
C		Clamp, Steering Gear Support	14.120
"C" Washer, Overdrive Shift Fork	9.250	Clamp, Steering Tie Rod	14.216
Cable, Battery Ground	7.510	Clamp and Strap, Tail Pipe Rear	
Cable, Battery to Starter Solenoid	7.510	Support	5.080
Cable, Cigar Lighter Feed	7.652	Cleaner, Air	4.000
	40.157	Clevis Pin, Hand Brake Equalizing	
Cable, Defroster Control	40.008	Lever Rod	15.230
Cable, Directional Signal and		Clip, Accelerator Bell Crank Rod to	
Parking Light	40.142	Carburetor Extension Shaft	3.410
Cable, Fresh Air Damper Control	40.010	Clip, Accelerator Linkage Tension	
Cable, Fresh Air Intake Control	40.010	Spring	3.400
Cable, Fuel Gauge Tank Unit	7.660	Clip, Accelerator Pedal Pivot Pin	3.070
Cable, Hand Brake Front	15.218	Clip, Body Wiring Harness	30.702
Cable, Hand Brake Rear	15.236	Clip, Brake Shoe Hold Down	15.004
Cable, Headlight	7.546	Clip, Chassis Wiring Harness	7.700
Cable, Heater Switch Feed	40.002	Clip, Clutch Pressure Plate Lever	8.106
Cable, Horn	7.520	Clip, Defroster Nozzle	40.008
Cable, Horn Blowing Ring	7.536	Clip, Door Glass Lifter Channel to	
Cable, Ignition	7.360	Regulator	30.202
Cable, Oil Pressure Gauge Engine Unit .	7.662	Clip, Directional Signal Switch Ground .	40.142
Cable, Overdrive Rail Switch to		Clip, Directional Signal Wiring Harness	40.142
Governor	7.810	Clip, Distributor Vacuum Control Arm .	7.338
Cable, Parking Light	7.568	Clip, Front Brake Hose Spring	15.068
Cable, Relay to Horn	7.525	Clip, Fuel Gauge Tank Unit Cable	7.660
Cable, Spark Plug	7.360	Clip, Fuel Pump Tube to Manifold Tube	
Cable and Housing, Speedometer	9.282	Retainer	30.364
Cable and Socket, License Light	30.0702	Clip, Fuel Tank to Fuel Pump Line	
Cable Set, Ignition	7.360	Tube	3.550
Cage, Overdrive Stationary Gear Pinion	9.220	Clip, Hand Brake Front Cable	15.218
Cam, Overdrive Free Wheeling	9.225	Clip, Headlining Bow Retainer	30.612
Cam and Shaft, Distributor	7.332		
Camshaft	1.500		
Cap, Distributor	7.302		
Cap, Battery Filler	40.020		

ALPHABETICAL INDEX

NAME AND PART DESCRIPTION	GROUP NUMBER	NAME AND PART DESCRIPTION	GROUP NUMBER
Clip, Heater Switch Feed Cable Support.	40.002	Cover, Windshield Pillar	30.612
Clip, Hood Prop	18.250	Cowl Complete	30.052
Clip, Horn Cable	7.520	Cradle, Radiator	6.455
Clip, Oil Pressure Gauge Engine Unit		Crankshaft	1.300
Cable	7.662	Cross and Bearing Kit, Propeller	
Clip, Overdrive Control	9.270	Shaft Joint	11.030
Clip, Overdrive Free Wheeling Cam . . .	9.225	Crossmember, Frame	17.010
Clip, Overdrive Wiring Harness	7.812	Cup, Front Brake Cylinder	15.020
Clip, Parking Light Cable	7.568	Cup, Horn Blowing Ground	7.527
Clip, Rear Axle Brake Tube	15.078	Cup, Master Brake Cylinder Piston . . .	15.035
Clip, Rear Brake Hose Spring	15.074	Cup, Overdrive Shift Fork	9.250
Clip, Rear Brake Tube Frame Tee to		Cup, Rear Brake Cylinder	15.030
Rear Hose	15.070	Cup, Steering Gear Worm Thrust	
Clip, Rear Window Finish Moulding . . .	30.088	Bearing	14.112
Clip, Speedometer Cable	9.282	Cushion, Front Seat	30.616
Clip, Wheel Hub Cap Spring	16.026	Cushion, Front Sway Eliminator Bar . . .	13.200
Cluster, Instrument Board	19.100	Cushion, Rear Seat	30.620
Coil, Ignition	7.346	Cushion, Shock Absorber	20.002
Collar, Distributor Drive Shaft	7.330	Cylinder, Front Brake	15.010
Collar, Overdrive Stationary Gear	9.210	Cylinder, Master Brake	15.035
Column and Worm, Steering Gear	14.110	Cylinder, Rear Brake	15.012
Condenser, Distributor	7.318		
Connector, Distributor Vacuum		D	
Chamber Tube	7.340	Damper, Fresh Air	40.010
Connector, Fuel Pump to Carburetor		Deflector, Rear Stone	30.048
Tube	3.560	DGF 123(Dry Graphite Film)	40.134
Connector, Fuel Pump to Wiper Tube . . .	30.364	Diaphragm Kit, Fuel Pump	3.500
Connector, Headlight Cable	7.546	Directional Signal Package	40.142
Connector, Manifold to Wiper Tube	30.364	Disc, Clutch	8.100
Connector, Overdrive Wiring Harness . . .	7.812	Disc, Vibration Damper	1.330
Connector, Starting Motor Solenoid	7.265	Distributor	7.300
Connector, Windshield Washer "Y"	40.116	Door, Front	30.102
Continental Spare Wheel Mount Package	40.123	Door, Headlight	7.540
Control, Carburetor Choke	3.020	Dowel, Crankshaft Main Bearing Cap . . .	1.320
Control, Front Door Lock Remote	30.106	Dowel Bolt, Clutch Housing	8.130
Control, Overdrive	9.270	Dowel Screw, Flywheel	1.360
Control, Windshield Wiper	30.354	Drain Cock, Cylinder Block Water	
Core, Heater	40.002	Jacket	1.100
Core, Speedometer Cable	9.284	Drain Cock, Radiator	6.400
Countershaft, Transmission	9.165	Drive Pulley, Generator	7.434
Counterweight, Heat Control	5.020	Drive Screw, Hood Ornament Nose	18.110
Cover, Air Cleaner	4.000	Dust Seal, Brake Pedal Floor Plate . . .	15.112
Cover, Clutch Housing	8.130	Dust Seal, Clutch Pedal Floor Plate . . .	8.170
Cover, Clutch Pressure Plate	8.104	Dust Seal, Gear Shift Lower Lever	9.320
	8.106	Dust Seal, Steering Tie Rod	14.216
Cover, Continental Spare Tire	40.123		
Cover, Front Bumper Support	20.210	E	
Cover, Front Seat Cushion	30.616	Elbow, Cylinder Head Water Outlet	6.425
Cover, Gear Shift Lever Housing	9.320	Elbow, Fuel Pump to Carburetor Tube . . .	3.560
Cover, Lock Cylinder	30.068	Elbow, Fuel Pump to Intake Manifold	
Cover, Master Brake Cylinder Access . . .	15.035	Tube	3.560
Cover, Oil Pump	2.230	Elbow, Fuel Tank to Fuel Pump Tube . . .	3.550
Cover, Rear Axle Housing	12.005	Elbow, Manifold Check Valve	1.760
Cover, Rear Seat Cushion	30.620	Element, Air Cleaner	4.000
Cover, Steering Gear Housing	14.104	Element, Cigar Lighter	7.652
Cover, Steering Gear Shaft	14.118	Element, Oil Filter	2.300
Cover, Timing Gear	1.610	Engine	1.000
Cover, Timing Hole	1.370	Escutcheon, Door Lock Remote Control	
Cover, Transmission Case	9.007	Handle	30.106
Cover, Valve Tappet	1.750	Escutcheon, Door Window Regulator	
Cover, Wheelhouse Front Trim	30.611	Handle	30.208
		Extension, Spare Tire Valve	40.117

ALPHABETICAL INDEX

NAME AND PART DESCRIPTION	GROUP NUMBER	NAME AND PART DESCRIPTION	GROUP NUMBER
F			
Fabric Cleaner	40.134	Frame and Ventilator Complete, Front Door	30.206
Facing Set, Clutch Disc	8.100	Fuse, Foglight	40.112
Fan, Engine	6.000	Fuse, Headlight Switch	7.553
Fan, Heater	40.002	Fuse, Overdrive Solenoid Relay	7.804
Fastener, Dash Insulating Pad	30.630	G	
Fastener, Door Glass Weatherstrip	30.204	Gasket, Air Cleaner Element	4.000
Fastener, Front Door Trim Panel	30.604	Gasket, Back-Up Light Lens	40.108
Fastener, Luggage Shelf Trim Panel	30.624	Gasket, Carburetor to Manifold	3.690
Fastener, Rear Compartment Windbreak	30.611	Gasket, Cylinder Block Front End Plate	1.105
Fastener, Rear Quarter Trim Panel	30.610	Gasket, Cylinder Head	1.200
Felt, Distributor Cam and Shaft	7.332	Gasket, Distributor Vacuum Chamber	7.338
Fender, Front	18.000	Gasket, Exhaust Manifold	5.000
Fender, Rear	30.041	Gasket, Exhaust Pipe	5.040
Filler, Instrument Cluster Bezel	30.412	Gasket, Fresh Air Damper Mounting	40.010
Filler, Quarter Panel Window Ventilator Glass	40.161	Gasket, Front Brake Hose	15.068
Filter Package, Oil	2.300	Gasket, Fuel and Vacuum Pump Cover Plate	3.470
Fitting, Master Brake Cylinder Outlet	15.035	Gasket, Fuel and Vacuum Pump to Block	3.470
Fitting, Master Brake Cylinder to Frame Tee	15.062	Gasket, Fuel Gauge Tank Unit	3.580
Flange, Fresh Air Intake	40.010	Gasket, Fuel Pump Bowl	3.490
Flange, Propeller Shaft Companion, Front	11.004	Gasket, Fuel Pump Oil Seal	3.505
Flange, Propeller Shaft Companion, Rear	11.020	Gasket, Headlight to Fender	7.540
Flasher, Directional Signal Light	40.142	Gasket, Heater Mounting	40.002
Flatwasher, Body Hold Down Bolt	30.012	Gasket, Instrument Panel Cluster Lens	19.100
Flatwasher, Bumper Guard	20.260	Gasket, Instrument Panel Lens Retainer	19.100
Flatwasher, Clutch Pressure Plate Lever	8.106	Gasket, Intake Manifold to Block	3.000
Flatwasher, Door Glass Lifter Channel to Regulator	30.202	Gasket, Intake to Exhaust Manifold	3.000
Flatwasher, Front Bumper Bar	20.200	Gasket, Master Brake Cylinder Access Cover	15.035
Flatwasher, Front Wheel Hub and Drum	16.002	Gasket, Master Brake Cylinder Access Cover Bolt	15.035
Flatwasher, Fuel Gauge Tank Unit	3.580	Gasket, Master Brake Cylinder Bolt	15.035
Flatwasher, Overdrive Control Shaft Lever	9.260	Gasket, Master Brake Cylinder Filler Plug	15.035
Flatwasher, Propeller Shaft Companion Flange	11.004	Gasket, Master Brake Cylinder Fitting	15.035
Flatwasher, Rear Axle Shaft	12.080	Gasket, Oil Depth Gauge Cap	2.415
Flatwasher, Rear Bumper Bar	20.250	Gasket, Oil Drain Plug	2.400
Flatwasher, Rear Fender to Lock Pillar	30.041	Gasket, Oil Pan	2.400
Flatwasher, Rear Shock Absorber Bushing	20.010	Gasket, Oil Pump Cover	2.230
Flatwasher, Rear Wheel Hub and Drum	16.020	Gasket, Oil Pump Float Support	2.235
Flatwasher, Transmission Outer Shifting Lever	9.195	Gasket, Oil Pump Relief Valve Plug	2.212
Flatwasher, Ventilator Lower Pivot	30.206	Gasket, Oil Pump to Block	2.200
Float, Carburetor	3.690	Gasket, Overdrive Adapter to Transmission Case	9.145
Float, Oil Pump	2.235	Gasket, Overdrive Rail Switch	7.802
Flywheel	1.360	Gasket, Parking Light Lens	7.563
Foglight Package	40.112	Gasket, Rear Axle Housing Cover	12.005
Fork, Overdrive Shift	9.250	Gasket, Rear Axle Pinion Bearing	12.050
Fork, Transmission Shifting	9.185	Gasket, Rear Axle Shaft Oil Seal	12.080
Frame	17.000	Gasket, Rear Brake Hose	15.074
Frame, Door Window	30.202	Gasket, Rear License Light Lens	30.0702
Frame and Glass, Front Door	30.206	Gasket, Spark Plug	7.375
		Gasket, Speedometer Cable	9.282
		Gasket, Steering Gear Shaft Cover	14.118
		Gasket, Tail Light Lens	7.572
		Gasket, Timing Gear Cover	1.610
		Gasket, Transmission Case Cover	9.007

ALPHABETICAL INDEX

NAME AND PART DESCRIPTION	GROUP NUMBER	NAME AND PART DESCRIPTION	GROUP NUMBER
Gasket, Transmission Case Cover Bolt	9.007	Grommet, Parking Light Cable	7.568
Gasket, Transmission Drive Pinion Bearing Retainer.	9.117	Grommet, Speedometer Cable	9.282
Gasket, Transmission Drive Pinion Bearing Retainer Bolt	9.115	Guard, Bumper	20.260
Gasket, Transmission Main Shaft Bearing Retainer.	9.145	Guide, Door Check Arm	30.112
Gasket, Transmission Overdrive Housing to Adapter	9.200	Guide, Gear Shift Upper Shaft	9.310
Gasket, Valve Cover Plate Vent Body	1.760	Guide, Hand Brake Rear Cable.	15.236
Gasket, Valve Tappet Cover	1.750	Guide, Overdrive Shift Fork	9.250
Gasket, Valve Tappet Cover Bolt	1.750	Guide, Valve.	1.720
Gasket, Water Outlet Elbow.	6.425	H	
Gasket, Water Pump to Block	6.300	Handle, Door Lock Remote Control.	30.106
Gasket, Windshield Wiper Arm Pivot	30.358	Handle, Door Locking.	30.114
Gasket Set, Carburetor.	3.690	Handle, Door Window Regulator	30.208
Gasket Set, Engine Overhaul	1.000	Handle, Hand Brake	15.200
Gasket Set, Exhaust Manifold.	5.000	Handle, Quarter Panel Window Ventilator	40.161
Gasket Set, Oil Pan	2.400	Hanger, Exhaust Pipe.	5.050
Gasket Set, Valve Grind	1.720	Hanger, Rear Spring	12.200
Gauge, Fuel	19.110	Harness, Body Wiring	30.702
Gauge, Fuel, Tank Unit.	3.580	Harness, Chassis Wiring	7.700
Gauge, Oil Pressure, Engine Unit.	2.430	Harness, Courtesy Light Wiring.	40.158
Gauge, Water Temperature.	19.110	Harness, Instrument Voltage Regulator	19.110
Gauge, Water Temperature, Engine Unit	6.444	Harness, Overdrive Wiring.	7.812
Gauge and Cap, Oil Depth	2.415	Head, Cylinder	1.200
Gear, Camshaft Timing	1.600	Headlight	7.540
Gear, Crankshaft Timing	1.600	Headlining	30.612
Gear, Oil Pump.	2.210	Heater Package.	40.002
Gear, Overdrive Governor	9.265	Hinge, Deck Lid	30.064
Gear, Overdrive Stationary.	9.210	Hinge, Door	30.108
Gear, Speedometer Drive	9.286	Hinge, Hood	18.200
Gear, Steering	14.100	Hinge, Rear Seat Back	30.560
Gear, Transmission Low and Reverse.	9.135	Hood	18.100
Gear, Transmission Reverse Idler	9.170	Horn	7.520
Gear, Transmission Second Speed Idler.	9.135	Hose, Defroster	40.008
Gear and Blocking Ring, Overdrive Stationary	9.205	Hose, Front Brake.	15.068
Gear and Pinion, Rear Axle Drive	12.045	Hose, Fuel Line to Pump	3.550
Gear and Pinion Kit, Rear Axle Drive.	12.020	Hose, Fuel Tank Filler.	3.530
Gear Cluster, Transmission Countershaft.	9.155	Hose, Heater	40.002
General Use Oil	40.134	Hose, Oil Filler Tube to Air Cleaner	1.760
Generator	7.400	Hose, Radiator	6.420
Glareshield, Inside Visor Package	40.115	Hose, Rear Brake Tube to Axle Tee	15.074
Glass, Rear Window.	30.501	Housing, Clutch.	8.130
Glass Cleaner.	40.134	Housing, Gear Shift Lever.	9.320
Governor, Overdrive	9.265	Housing, Parking Light.	7.560
Governor Weight, Distributor Drive Shaft	7.324	Housing, Rear Axle	12.005
Grommet, Body Wiring Harness.	30.702	Housing, Rear License Light.	30.0702
Grommet, Chassis Wiring Harness.	7.700	Housing, Steering Gear.	14.102
Grommet, Directional Signal Light Cable	40.142	Housing, Transmission Overdrive	9.200
Grommet, Distributor Drive Shaft Oil Seal	7.324	Hub, Transmission Second and High Synchronizer	9.125
Grommet, Fuel Gauge Tank Unit Cable	7.660	Hub, Water Pump Pulley.	6.000
Grommet, Headlight Cable	7.546	Hub and Drum, Front Wheel	16.002
Grommet, Ignition Cable Support Bracket.	7.360	Hub and Drum, Rear Wheel.	16.020
Grommet, Overdrive Control	9.270	Hydraulic Brake Fluid	15.040
		I	
		Impeller, Water Pump	6.300
		Insulator, Clutch Pedal Cross Shaft	8.155
		Insulator, Engine Support Front.	1.010
		Insulator, Engine Support Rear	1.020
		Insulator, Front Bumper Bar Support	20.208

ALPHABETICAL INDEX

NAME AND PART DESCRIPTION	GROUP NUMBER	NAME AND PART DESCRIPTION	GROUP NUMBER
Insulator, Front Suspension Spring Upper	13.024	Lining Set, Brake Shoe	15.006
Insulator, Gear Shift Lower Lever to Rod.	9.320	Link, Generator Adjusting.	7.460
Insulator, Generator Mounting Bolt.	7.400	Link, Hand Brake Operating Lever	15.008
Insulator, Radiator Cradle to Frame.	6.455	Lock, Front Door	30.104
Insulator, Transmission Outer Shifting Lever	9.195	Lock, Intake and Exhaust Valve Guide Spring	1.720
Insulator, Vibration Damper Disc.	1.330	Lock Cylinder and Key, Deck Lid	30.068
J		Lock Cylinder and Key Kit, Ignition Switch and Door	7.352
Jack, Bumper	20.300		30.114
Jacket, Steering Column	14.106	Lock Ring, Clutch Pedal Cross Shaft.	8.155
Jet, Timing Gear Oil	1.600	Lock Ring, Starting Motor Spring	7.244
Jet, Windshield Washer.	40.116	Locknut, Access Cover and Left Splash Shield to Dash.	18.010
K		Locknut, Bumper Guard	20.260
Key, Deck Lid Lock Cylinder.	30.068	Locknut, Clutch Pressure Plate Lever	8.106
Key, Door Handle Lock Cylinder	30.114	Locknut, Connecting Rod.	1.400
Key, Heat Control Valve Counterweight.	5.020	Locknut, Front Bumper Bar Bolt	20.200
Key, Ignition Switch Lock	7.352	Locknut, Front Suspension Lower Arm Pivot Reinforcement	13.020
Key, Rear Axle Shaft	12.080	Locknut, Exhaust Manifold to Pipe	5.040
Key, Rear Wheel Hub and Drum.	16.020	Locknut, Propeller Shaft Companion Flange.	11.020
King Pin, Steering Knuckle	13.002	Locknut, Rear Bumper Bar	20.250
Knob, Defroster Control.	40.008	Locknut, Rear Spring Mounting Plate	12.215
Knob, Gear Shift Lever.	9.300	Locknut, Rear Spring Shackle	12.200
Knob, Headlight Switch.	7.553	Locknut, Shock Absorber	20.000
Knob, Heater Switch Control	40.002	Locknut, Steering Gear Shaft and Roller Adjusting Screw	14.116
Knob, Seat Track Adjuster Operating Handle.	30.554	Lockpin, King Pin	13.002
Knob, Windshield Wiper Control.	30.354	Lockpin, Rear Axle Differential Side Pinion.	12.020
Knob and Element, Cigar Lighter	7.652	Lockplate, Rear Axle Gear and Pinion.	12.045
Knob and Wire, Overdrive Control	9.270	Lockplate, Steering Gear Shaft and Roller Adjusting Screw.	14.116
Knuckle, Steering	13.000	Lockplate, Transmission Reverse Idler Gear Shaft	9.175
L		Lockwasher, Distributor Condenser	7.318
Latch, Deck Lid	30.074	Lockwasher, Door Lock Striker Plate.	30.104
Lead, Distributor Breaker Plate	7.316	Lockwasher, Steering Gear Lever Pitman Arm.	14.200
Lens, Back-Up Light	40.108	Lubriplate	40.1345
Lens, Instrument Panel Cluster	19.100	Lustur Seal	40.134
Lens, Parking Light.	7.563	Lustur Seal Applicator.	40.134
Lens, Rear License Light.	30.0702	Lustur Seal Banner	40.134
Lens, Tail Light	7.572	Lustur Seal Buffer Pad Backing Plate.	40.134
Lever, Clutch Pressure Plate	8.104	Lustur Seal Decal	40.134
Lever, Clutch Release	8.125	Lustur Seal Haze Cream.	40.134
Lever, Directional Signal Switch	40.142	Lustur Seal Literature Kit	40.134
Lever, Fuel Pump Cam	3.472	M	
Lever, Gear Shift Lower.	9.320	Manifold, Exhaust	5.000
Lever, Gear Shift Upper	9.300	Manifold, Intake	3.000
Lever, Hand Brake Equalizing.	15.230	Mat, Floor	30.630
Lever, Hand Brake Operating	15.008	Mat, Rear Compartment Floor.	30.611
Lever, Overdrive Control Shaft	9.260	Medallion, Horn	7.527
Lever, Transmission Outer Shifting	9.195	Metering Rod, Carburetor.	3.690
Lever and Shaft, Transmission Shifting, Inner.	9.180	Miracle Power	40.134
Lid, Rear Deck.	30.062	Mirror, Outside Rear View.	40.118
Light, License	30.0702	Mirror, Vanity	40.120
Light, Parking	7.560	Mirror and Bracket, Rear View.	30.802
Light, Tail and Stop	7.570	Motor, Heater	40.002
Light Package, Courtesy.	40.158		
Lighter Package, Cigar	40.157		

ALPHABETICAL INDEX

NAME AND PART DESCRIPTION	GROUP NUMBER	NAME AND PART NUMBER	GROUP NUMBER
Motor, Windshield Wiper	30.352	Nut, Steering Knuckle Support	13.008
Moulding, Door Trim Panel	30.604	Nut, Steering Wheel	14.126
Moulding, Front Fender	18.002	Nut, Ventilator Lower Pivot	30.206
Moulding, Hood	18.100	Nut, Windshield Wiper Arm Pivot	30.358
Moulding, Rear Window Finish	30.088	Nut, Windshield Wiper Control	30.354
Moulding, Roof Drip	30.052	O	
Moulding, Windshield Division Bar	30.094	Oil Seal, Fuel Pump	3.505
Moulding, Windshield Finish	30.094	Oil Seal, Overdrive Main Shaft	9.235
Muffler, Exhaust	5.055	Oil Seal, Overdrive Shift Control Shaft	9.255
N		Oil Seal, Overdrive Solenoid	7.800
Needle and Seat, Carburetor Float	3.690	Oil Seal, Propeller Shaft Joint	11.030
Nipple, Ignition Cable	7.360	Oil Seal, Rear Axle Pinion, Bearing, Front	12.050
Nipple, Water Pump to Heater Hose	40.002	Oil Seal, Rear Axle Shaft	12.080
Nose, Hood Ornament	18.110	Oil Seal, Transmission Main Shaft Bearing Retainer	9.145
Nozzle, Defroster	40.008	Oiler, Clutch Pedal Cross Shaft	8.155
Nut, Back-Up Light Switch	40.108	Oiler, Distributor	7.302
Nut, Battery Cable	7.510	Oiler, Front Suspension Upper Arm	13.014
Nut, Chassis Wiring Harness Clip	7.700	Oiler, Propeller Shaft Joint	11.030
Nut, Check Valve to Valve Cover Tube	1.760	Oiler, Propeller Shaft Slip Yoke	11.005
Nut, Clutch Control Bell Crank to Release Lever Adjusting Rod	8.157	Oiler, Steering Knuckle	13.000
Nut, Connecting Rod	1.400	Oiler, Steering Knuckle Support	13.008
Nut, Crankshaft Pulley	1.350	Oiler, Steering Tie Rod	14.216
Nut, Cylinder Head Stud	1.200	Ornament, Hood	18.110
Nut, Defroster Baffle	40.008	P	
Nut, Defroster Hole Plug	30.412	Packing, Crankshaft Main Bearing	1.315
Nut, Distributor Vacuum Chamber Tube	7.340	Pad, Brake Pedal	15.102
Nut, Door Arm Rest	30.614	Pad, Brake Pedal Floor Plate	15.112
Nut, Exhaust Manifold	5.000	Pad, Clutch Pedal	8.140
Nut, Front Brake Tube	15.064	Pad, Clutch Pedal Floor Plate	8.170
Nut, Front Bumper Bar Hole Plug	20.200	Pad, Dash Insulating	30.630
Nut, Front Bumper Support Cover Bracket	20.210	Pad, Door Lock Remote Control	30.106
Nut, Front Seat Track Adjuster to Seat Cushion	30.554	Pad, Horn Blowing Contact Plate	7.527
Nut, Fuel Pump to Carburetor Tube	3.560	Pad, Lustur Seal Buffer	40.134
Nut, Fuel Pump to Intake Manifold Tube	3.560	Pad, Rear License Light Mounting	30.0702
Nut, Fuel Tank to Fuel Pump Line Tube	3.550	Pad, Tail and Stop Light	7.570
Nut, Hand Brake Front Cable	15.218	Pan, Oil	2.400
Nut, Headlight Beam Adjusting	7.540	Pan, Rear Floor	30.058
Nut, Headlight Switch	7.553	Panel, Body Rocker	30.056
Nut, Heater Switch Mounting	40.002	Panel, Cowl Trim	30.602
Nut, Instrument Voltage Regulator	19.110	Panel, Deck Lid Trim	30.611
Nut, Intake Manifold Stud	3.000	Panel, Front Door Trim	30.604
Nut, Master Brake Cylinder Tube to Frame Tee	15.060	Panel, Hand Brake Cover	15.200
Nut, Overdrive Control Bracket	9.275	Panel, Hand Brake Handle Cover	30.412
Nut, Overdrive Kickdown Switch	7.806	Panel, Luggage Shelf Trim	30.624
Nut, Parking Light	7.560	Panel, Rear Compartment Trim	30.611
Nut, Propeller Shaft Companion Flange	11.004	Panel, Rear Quarter	30.040
Nut, Rear Axle Brake Tube	15.078	Panel, Rear Quarter Trim	30.610
Nut, Rear Axle Shaft	12.080	Panel, Rear Seat Back	30.560
Nut, Rear Brake Frame Tee to Rear Hose Tube	15.070	Panel, Roof	30.052
Nut, Rear Bumper Bar Hole Plug	20.250	Panel, Stone Deflector, Front	6.492
Nut, Rear Fender to Quarter Panel	30.041	Panel, Sun Visor	30.626
Nut, Rear Wheel Hub and Drum	16.020	Panel, Wheelhouse Rear Trim	30.611
Nut, Spare Wheel Mounting Clamp	16.030	Patch, Rear Quarter Panel	30.040
Nut, Steering Gear	14.100	Pawl, Overdrive Stationary Gear	9.210
Nut, Steering Gear Lever Pitman Arm	14.200	Pedal, Accelerator	3.070
		Pedal, Brake	15.102
		Pedal, Clutch	8.140

ALPHABETICAL INDEX

NAME AND PART DESCRIPTION	GROUP NUMBER	NAME AND PART DESCRIPTION	GROUP NUMBER
Perfect Seal Gasket Paste	40.133	Plate, Distributor Breaker	7.310
Pillar, Rear Quarter Lock	30.038	Plate, Door Handle Button	30.114
Pin, Accelerator Pedal Pivot	3.070	Plate, Door Lock Striker	30.104
Pin, Brake Pedal	15.102	Plate, Front Seat Back Stop	30.616
Pin, Carburetor Float Lever Fulcrum . .	3.690	Plate, Hood Lock Latch	18.150
Pin, Clutch Pedal	8.140	Plate, Hood Lock Latch Support	18.147
Pin, Clutch Pressure Plate Lever	8.106	Plate, Hood Name	18.135
Pin, Clutch Release Lever	8.125	Plate, Horn Blowing Cable Terminal . . .	7.536
Pin, Distributor Drive Shaft Collar . . .	7.330	Plate, Horn Blowing Contact	7.527
Pin, Door Check Arm	30.112	Plate, Instrument Board Name	30.412
Pin, Door Hinge	30.108	Plate, Master Brake Cylinder Piston Stop	15.035
Pin, Door Lock Remote Control Handle .	30.106	Plate, Overdrive Stationary Gear Cover	9.215
Pin, Door Window Regulator Handle . . .	30.208	Plate, Rear License Light Retainer . . .	30.0702
Pin, Fuel Pump Cam Lever	3.472	Plate, Rear Spring Mounting	12.215
Pin, Hand Brake Handle Stop	15.200	Plate, Tail Pipe Rear Support	5.080
Pin, Hood Lock Safety Catch Pivot	18.152	Plate, Transmission Second and High Synchronizer Sleeve Shifting	9.130
Pin, Master Brake Cylinder Operating Rod	15.100	Plate, Vibration Dampner Clamp	1.330
Pin, Oil Pump Gear	2.210	Plate and Nut, Hood Lock Bolt	18.148
Pin, Overdrive Shift Control Shaft	9.255	Plug, Cigar Lighter Button	30.412
Pin, Piston	1.420	Plug, Cylinder Block Oil Header Pipe . .	1.100
Pin, Quarter Panel Window Ventilator Handle	40.161	Plug, Directional Signal Switch Wiring Hole	14.120
Pin, Rear Shock Absorber Lower Anchor	12.215	Plug, Distributor Vacuum Chamber . . .	7.338
Pin, Transmission Inner Shifting Lever .	9.180	Plug, Front Bumper Bar Hole	20.200
Pin, Transmission Shifting Lever Poppet Ball	9.190	Plug, Front Pillar Drain Hole	30.038
Pin, Ventilator Handle	30.206	Plug, Fuel Pump Cam Lever	3.472
Pinion, Overdrive Governor	9.265	Plug, Gear Shift Lever Housing Cover . .	9.320
Pinion, Speedometer Drive	9.286	Plug, Master Brake Cylinder Filler Hole	15.035
Pinion, Transmission Drive	9.100	Plug, Oil Pan Drain	2.400
Pipe, Exhaust	5.040	Plug, Oil Pump Relief Valve	2.212
Pipe, Tail	5.070	Plug, Rear Bumper Bar Hole	20.250
Piston, Engine	1.410	Plug, Steering Gear Shaft Cover Oil . . .	14.118
Piston, Front Brake Cylinder	15.020	Plug, Timing Gear Cover	1.610
Piston, Master Brake Cylinder	15.035	Plug, Tire Well Drain Hole	30.058
Piston, Rear Brake Cylinder	15.030	Plug, Transmission Filler and Drain . .	9.005
Pivot, Clutch Pedal to Bell Crank	8.155	Plug, Ventilator Control Hole	14.120
Pivot, Front Suspension Lower Arm Inner	13.020	Point Set, Distributor Breaker	7.316
Pivot, Front Suspension Upper Arm Pivot Inner	13.016	Pointer, Engine Timing	1.370
Pivot, Gear Shift Rod to Lever	9.340	Presstite Cord	40.133
Pivot, Steering Knuckle Support	13.008	Prop, Hood	18.250
Pivot, Ventilator	30.206	Prop, Rear Deck Lid	30.064
Pivot, Windshield Wiper Arm	30.358	Prop, Rear Seat Back	30.560
Pivot Pin, Gear Shift Lever	9.300	Pulley and Hub, Crankshaft	1.350
Pivot Repair Kit, Steering Knuckle Support, Outer	13.008	Pulley and Hub, Water Pump	6.000
Plate, Brake Pedal Floor	15.112	Pump, Fuel	3.470
Plate, Brake Support, Front	15.000	Pump, Fuel and Vacuum	3.470
Plate, Brake Support, Rear	15.002	Pump, Oil	2.200
Plate, Clutch Housing Cover	8.130	Pump, Water	6.300
Plate, Clutch Pedal Floor Cover	8.170	R	
Plate, Clutch Pressure	8.104	Radiator	6.400
Plate, Clutch Release Bearing	8.120	Radiator Flush	40.134
Plate, Cylinder Block End, Front	1.105	Radiator Rust Resistor	40.134
Plate, Deck Lid Name	30.076	Radiator Stop Leak	40.134
Plate, Directional Signal Switch Wiring Hole Plug Retaining	14.120	Radio Package	40.100
		Rail, Inner Roof	30.052
		Rail, Outer Roof	30.052
		Rail, Overdrive Shift	9.250

ALPHABETICAL INDEX

NAME AND PART DESCRIPTION	GROUP NUMBER	NAME AND PART DESCRIPTION	GROUP NUMBER
Regulator, Front Door Window	30.208	Retainer, Storage Battery	7.500
Regulator, Generator Voltage	7.470	Retainer, Tail Light Lens	7.572
Regulator, Instrument Voltage	19.110	Retainer, Transmission Drive Pinion Bearing	9.115
Reinforcement, Front Suspension Lower Arm Inner Pivot	13.020	Retainer, Transmission Main Shaft Bearing	9.145
Reinforcement, Hood Lock Latch Support Plate Center	18.147	Retainer, Windshield Division Bar	30.306
Reinforcement, Upper Radiator Support.	18.147	Retainer, Windshield Wiper Link	30.358
Relay, Horn	7.525	Retainer Ring, Clutch Pressure Plate Lever	
Relay, Overdrive Solenoid	7.804	Retaining Ring, Headlight Sealed Beam .	7.540
Repair Kit, Carburetor	3.690	Ring, Directional Signal Switch Cancelling	40.142
Repair Kit, Crankshaft	1.300	Ring, Hood Ornament	18.110
Repair Kit, Flywheel	1.360	Ring, Horn Blowing	7.527
Repair Kit, Front Brake Cylinder	15.014	Ring, Piston	1.415
Repair Kit, Front Suspension Lower Arm Inner Pivot	13.020	Ring, Second Steel Section Compression Piston	1.417
Repair Kit, Front Suspension Upper Arm Inner Pivot	13.016	Ring, Steel Section Oil Control Piston . .	1.417
Repair Kit, Fuel Pump	3.480	Ring, Top Compression Piston	1.417
Repair Kit, Master Brake Cylinder	15.040	Ring, Wheel Trim	16.028
Repair Kit, Rear Brake Cylinder	15.014	Ring Gear, Flywheel	1.360
Repair Kit, Steering Gear Shaft and Roller	14.116	Ping Gear, Overdrive	9.245
Repair Kit, Steering Knuckle King Pin .	13.002	Ring Set, Piston	1.417
Repair Kit, Water Pump	6.300	Ring Set, Wheel Trim	40.122
Retainer, Accelerator Bell Crank	3.090	Rivet, Division Bar Glass Run	30.202
Retainer, Door Glass Channel to Door Nut	30.202	Rivet, Lock Cylinder Cover	30.068
Retainer, Door Handle Button Spring . .	30.114	Rivet, Rear Seat Back Prop Spring	30.560
Retainer, Exhaust Manifold	5.000	Rivet, Ventilator Division Bar Glass Run	30.206
Retainer, Front Sway Eliminator Bar . .	13.200	Rivet, Ventilator Division Bar Weatherstrip	30.206
Retainer, Fuel Pump Cam Lever Pin . .	3.472	Rivet, Ventilator Window Locking Bracket	30.206
Retainer, Gear Shift Lever	9.300	Rivet, Wheel Hub Cap Spring Clip	16.026
Retainer, Gear Shift Rod to Lever Sleeve	9.340	Rod, Accelerator Bell Crank to Carburetor	3.410
Retainer, Hand Brake Operating Lever .	15.008	Rod, Accelerator Bell Crank to Carburetor Extension Shaft	3.410
Retainer, Hand Brake Rear Cable	15.236	Rod, Accelerator Pedal	3.085
Retainer, Hood Lock Bolt Plate	18.148	Rod, Clutch Control Bell Crank to Release Lever	8.157
Retainer, Horn Blowing Medallion	7.527	Rod, Clutch Pedal Cross Shaft Adjusting	8.155
Retainer, Ignition Cables	7.360	Rod, Connecting	1.400
Retainer, Instrument Board Ash Receiver	30.406	Rod, Door Handle Button Push	30.114
Retainer, Instrument Board Cluster Lens	19.100	Rod, Gear Shift	9.340
Retainer, Intake and Exhaust Valve Guide	1.720	Rod, Hand Brake Equalizing Lever	15.230
Retainer, Intake Manifold	3.000	Rod, Master Brake Cylinder Operating .	15.100
Retainer, Luggage Shelf Trim Panel . . .	30.624	Rod, Master Brake Cylinder Piston Push	15.035
Retainer, Master Brake Cylinder Piston Stop Plate	15.035	Rod, Seat Track Adjuster Connecting . .	30.554
Retainer, Overdrive Free Wheeling Cam Roller Bearing	9.230	Roller and Cage, Steering Gear Worm Thrust Bearing	14.114
Retainer, Overdrive Governor Sleeve . .	9.265	Rotor, Distributor Cam	7.332
Retainer, Propeller Shaft Joint	11.030	Run, Front Door Glass Division Bar . . .	30.202
Retainer, Quarter Panel Window Ventilator Weatherstrip	40.161	Run, Front Door Window Glass	30.204
Retainer, Rear Axle Shaft Bearing	12.080	Run, Front Door Ventilator Division Bar Glass	30.206
Retainer, Rear Seat Back Ball Stud Bumper	30.560		
Retainer, Shock Absorber Cushion	20.002		
Retainer, Speedometer Cable Grommet .	9.282		

ALPHABETICAL INDEX

NAME AND PART DESCRIPTION	GROUP NUMBER	NAME AND PART DESCRIPTION	GROUP NUMBER
S			
Screen, Fresh Air Intake	40.010	Seal, Water Pump Impeller	6.300
Screen, Fuel Pump Bowl	3.490	Sealed Beam Unit, Foglight	40.112
Screw, Body Rocker Panel to Floor . . .	30.056	Sealed Beam Unit, Headlight	7.540
Screw, Brake Pedal Floor Plate	15.112	Sealed Beam Unit, Spotlight	40.104
Screw, Clutch Pedal Floor Plate	8.170	Sealzit, Windshield	40.133
Screw, Clutch Pressure Plate Lever		Seat, Clutch Pressure Plate Spring . . .	8.106
Adjusting	8.106	Seat, Front Shock Absorber Lower . . .	20.004
Screw, Distributor Breaker Contact		Seat, Headlight Sealed Beam	7.540
Lead	7.316	Seat Cover Set	40.132
Screw, Distributor Condenser	7.318	Shackle Kit, Rear Spring	12.220
Screw, Distributor Vacuum Chamber . .	7.334	Shaft, Carburetor Extension	3.450
Screw, Door Arm Rest	30.614	Shaft, Clutch Pedal Cross	8.155
Screw, Door Lock Striker Plate	30.104	Shaft, Distributor Drive	7.324
Screw, Door Upper Bumper	30.112	Shaft, Exhaust Manifold Heat Control	
Screw, Front Bumper Support Cover		Valve	5.010
Bracket	20.210	Shaft, Gear Shift	9.310
Screw, Front Fender Splash Shield . . .	18.010	Shaft, Overdrive Main	9.235
Screw, Headlight Beam Adjusting	7.540	Shaft, Overdrive Shift Control	9.255
Screw, Headlight Cable Ground	7.546	Shaft, Rear Axle	12.080
Screw, Headlight Cable Terminal Block .	7.550	Shaft, Rear Axle Differential Side	
Screw, Headlight Door	7.540	Pinion	12.020
Screw, Headlight Sealed Beam	7.540	Shaft, Transmission Main	9.120
Screw, Radiator Grille	6.490	Shaft, Transmission Reverse Idler Gear	9.175
Screw, Radiator Shroud	6.480	Shaft, Water Pump Drive	6.300
Screw, Rear License Plate Bracket . . .	20.115	Shaft and Bracket, Ventilator Handle . .	30.206
Screw, Rear Seat Back Ball Stud to		Shaft and Joints, Propeller	11.000
Bracket	30.560	Shaft and Roller, Steering Gear	14.116
Screw, Rear Stone Deflector	30.048	Shaft and Rotors, Oil Pump Drive	2.210
Screw, Steering Gear Shaft and Roller		Shaft and Yoke, Propeller	11.002
Adjusting	14.116	Shaver, Electric	40.149
Screw, Stone Deflector Panel	6.492	Shell, Body	30.050
Screw, Stone Shield	18.000	Shield, Directional Signal Light Wiring	
Screw, Valve Tappet Adjusting	1.740	Harness	40.142
Screw with L/W, Cowl Trim Panel	30.602	Shield, Front Fender Splash	18.010
Screw with L/W, Door Lock	30.104	Shim, Body Hold Down Bolt	30.014
Screw with L/W, Fuel and Vacuum		Shim, Crankshaft Thrustwasher	1.310
Valve Housing	3.474	Shim, Directional Signal Wiring	
Screw with L/W, Fuel Valve Housing		Harness Bracket	40.142
Cover	3.474	Shim, Door Lock Striker Plate	30.104
Screw with L/W, Hood Moulding	18.100	Shim, Front Suspension Lower Arm	
Seal, Brake Pedal Floor Plate	15.112	Inner Pivot	13.020
Seal, Clutch Pedal Cross Shaft	8.155	Shim, Front Suspension Upper Arm	
Seal, Clutch Pedal Floor Plate	8.170	Inner Pivot	13.016
Seal, Crankshaft Oil	1.303	Shim, Oil Pump Relief Valve	2.212
Seal, Door Handle Button	30.114	Shim, Radiator Shroud to Splash Shield .	6.480
Seal, Door Ventilator Window Glass . . .	30.206	Shim, Rear Axle Differential Bearing . .	12.035
Seal, Front Fender Splash Shield to		Shim, Rear Axle Pinion Bearing	12.050
Dash	18.010	Shim, Rear Axle Pinion Bearing, Rear .	12.060
Seal, Fender to Cowl	18.000	Shim, Rear Axle Shaft Bearing	12.080
Seal, Front Suspension Lower Arm	13.018	Shim, Steering Gear Column and Worm .	14.110
Seal, Front Suspension Upper Arm	13.014	Shim, Steering Gear Support	14.120
Seal, Front Wheel Inner Bearing	16.010	Shim, Steering Knuckle King Pin	
Seal, Fuel Filler Neck	30.040	Thrust Bearing	13.004
Seal, Rear Stone Deflector	30.048	Shock Absorber, Front	20.000
Seal, Steering Column Jacket	14.106	Shock Absorber, Rear	20.010
Seal, Steering Gear Shaft and Roller . . .	14.116	Shoe, Transmission Shifting	9.185
Seal, Steering Knuckle Support	13.008	Shoe Set, Brake	15.004
Seal, Transmission Shifting Lever and		Shroud, Radiator	6.000
Shaft	9.180	Sleeve, Body Wiring Harness Terminal .	30.702
		Sleeve, Chassis Wiring Harness	
		Terminal	7.700

ALPHABETICAL INDEX

NAME AND PART DESCRIPTION	GROUP NUMBER	NAME AND PART DESCRIPTION	GROUP NUMBER
Sleeve, Gear Shift Rod to Lever	9.340	Spark Plug	7.375
Sleeve, Headlight Cable	7.546	Speednut, Body Hold Down Bolt	30.012
Sleeve, Horn Blowing Ring Cable	7.536	Speednut, Deck Lid License Light	30.0702
Sleeve, Instrument Light Socket	7.643	Speednut, Front Fender Splash Shield	18.010
Sleeve, Overdrive Control	9.270	Speednut, Horn Bracket	7.520
Sleeve, Overdrive Governor	9.265	Speednut, Name Plate	18.135
Sleeve, Parking Light Cable	7.568		30.076
Sleeve, Transmission Second and High Synchronizer	9.130		30.412
Sleeve, Transmission Shifting Lever Poppet Ball	9.190	Speednut, Radiator Cradle to Shroud Supports	6.455
Slinger, Crankshaft Oil	1.310	Speednut, Radiator Grille Bar Support to Stone Deflector	6.490
Slinger, Rear Axle Pinion Bearing, Front	12.050	Speednut, Radiator Mounting	6.400
Slinger, Transmission Drive Pinion Bearing	9.105	Speednut, Radiator Shroud to Splash Shield	6.480
Slip Yoke and Plug, Propeller	11.005	Speednut, Rear License Plate Bracket	20.115
Snap Ring, Distributor Cam and Shaft	7.332	Speednut, Rear License Plate Mounting	20.119
Snap Ring, Overdrive Main Shaft Bearing	9.240	Speednut, Rear Stone Deflector to Body	30.048
Snap Ring, Overdrive Ring Gear	9.245	Speednut, Stone Deflector Panel	6.492
Snap Ring, Overdrive Stationary Gear	9.210	Speednut, Stone Shield to Fender	18.000
Snap Ring, Overdrive Stationary Gear Cover Plate	9.215	Speedometer Head	19.110
Snap Ring, Propeller Shaft Joint	11.030	Spot Remover	40.134
Snap Ring, Transmission Drive Pinion Bearing	9.110	Spotlight Package	40.104
Snap Ring, Transmission Main Shaft Bearing	9.140	Spotlitter Package	40.105
Snap Ring, Transmission Second and High Synchronizer	9.125	Spring, Accelerator Bell Crank	3.090
Snap Ring, Transmission Second and High Synchronizer Sleeve	9.130	Spring, Accelerator Linkage Tension	3.400
Snap Ring, Water Pump Drive Shaft	6.300	Spring, Brake Pedal Arm and Shaft Return	15.102
Socket, Courtesy Light Wiring Harness	40.158	Spring, Brake Shoe Pull Back	15.004
Socket, Headlight Beam Indicator Light	7.556	Spring, Clutch Pedal Assist	8.140
Socket, Instrument Lights	7.643	Spring, Clutch Pedal Cross Shaft	8.155
Socket, Oil Pressure and Battery Charge Indicator Light	7.643	Spring, Clutch Pedal Return	8.140
Solenoid, Overdrive	7.800	Spring, Clutch Pressure Plate	8.104
Solenoid, Starting Motor	7.265	Spring, Clutch Pressure Plate Lever	8.104
Solvent Fluid, Windshield Washer	40.116	Spring, Clutch Release Bearing	8.120
Spacer, Access Cover and Left Splash Shield to Dash	18.010	Spring, Distributor Drive Shaft Anti-Rattle	7.324
Spacer, Back-Up Light Switch	40.108	Spring, Distributor Main Drive Shaft	7.344
Spacer, Camshaft	1.500	Spring, Distributor Vacuum Chamber	7.338
Spacer, Crankshaft Timing Gear	1.600	Spring, Door Handle Button	30.114
Spacer, Deck Lid Latch Striker	30.074	Spring, Door Lock Remote Control Handle Escutcheon	30.106
Spacer, Distributor Cam and Shaft	7.332	Spring, Front Brake Cylinder Piston Return	15.020
Spacer, Fuel and Vacuum Pump to Block Spacer, Heater Mounting	3.470	Spring, Front Suspension	13.024
Spacer, Hood Moulding	40.002	Spring, Fuel Pump Cam Lever	3.472
Spacer, Horn Blowing Contact Ring	18.100	Spring, Gear Shift Lever Pivot Pin	9.300
Spacer, Horn Blowing Contact Ring	7.527	Spring, Gear Shift Lower Lever to Cam	9.320
Spacer, Ignition Coil	7.346	Spring, Gear Shift Shaft End to Lever	9.310
Spacer, Radiator Cradle	6.455	Spring, Hand Brake Equalizing Lever Return	15.230
Spacer, Rear Axle Pinion Bearing, Front	12.050	Spring, Headlight Beam Indicator Light Socket	7.556
Spacer, Steering Column Jacket Bearing	14.108	Spring, Headlight Sealed Beam	7.540
Spacer, Transmission Countershaft Gear Bearing	9.160	Spring, Hood Hinge	18.200
Spacer, Windshield Wiper Arm Pivot	30.358	Spring, Hood Lock Bolt Plate Release	18.148
		Spring, Hood Lock Latch	18.150
		Spring, Hood Lock Safety Catch	18.152
		Spring, Hood Ornament	18.110

ALPHABETICAL INDEX

NAME AND PART DESCRIPTION	GROUP NUMBER	NAME AND PART DESCRIPTION	GROUP NUMBER
Spring, Instrument Light Socket	7.643	Support, Rear Seat Back Prop	30.560
Spring, Intake and Exhaust Valve	1.720	Support, Spare Wheel Mounting	16.030
Spring, Lock Cylinder Cover	30.068	Support, Starting Motor	7.222
Spring, Master Brake Cylinder	15.035	Support, Steering Knuckle	13.008
Spring, Oil Pump Relief Valve	2.212	Switch, Back-Up Light	40.108
Spring, Overdrive Free Wheeling Cam Bearing	9.230	Switch, Courtesy Light	40.158
Spring, Overdrive Shift Control Shaft . .	9.255	Switch, Directional Signal Light	40.142
Spring, Parking Light Cable	7.568	Switch, Foglight	40.112
Spring, Rear	12.200	Switch, Headlight	7.553
Spring, Rear Brake Cylinder Piston Return	15.030	Switch, Headlight Dimmer	7.554
Spring, Rear Seat Back Prop	30.560	Switch, Heater	40.002
Spring, Seat Track Adjuster Latch	30.554	Switch, Ignition	7.350
Spring, Starting Motor Bendix Drive . . .	7.244	Switch, Overdrive Kickdown	7.806
Spring, Steering Column Jacket Bearing .	14.108	Switch, Overdrive Rail	7.802
Spring, Transmission Shifting Lever Poppet Ball	9.190	Switch, Spotlight	40.104
Spring, Vacuum Diaphragm	3.474	Switch, Starting	7.270
Spring, Ventilator Lower Pivot	30.206	Switch, Stop Light	7.650
Spring Set, Distributor Drive Shaft Governor Weight	7.324	Switch and Knob, Heater	40.002
Springwasher, Hand Brake Operating Lever	15.008	Swivel, Accelerator Bell Crank	3.090
Springwasher, Rear Deck Lid Prop to Lid	30.064	Synchronizer Unit, Transmission Second and High	9.125
Stand, Foglight Display	40.112	T	
Stand, Spotlight Display	40.104	Tacking Strip, Trim	30.636
Starting Motor	7.222	Tank, Fuel	3.520
Stop, Exhaust Manifold Counterweight . .	5.020	Tank, Windshield Washer	40.116
Stop, Ventilator Lower Pivot	30.206	Tappet, Valve	1.740
Strainer, Fuel Pump	3.474	Tee, Master Brake Cylinder Frame	15.062
Strap, Directional Signal Switch Mounting	40.142	Tee, Rear Axle Brake Tube	15.076
Strap, Master Brake Cylinder	15.035	Terminal, Body Wiring Harness	30.702
Striker, Deck Lid Latch	30.074	Terminal, Chassis Wiring Harness	7.700
Stud, Accelerator Bell Crank	3.090	Terminal, Headlight Beam Indicator Light Socket	7.556
Stud, Carburetor	3.690	Terminal, Instrument Lights Socket	7.643
Stud, Cylinder Block Front End Plate . .	1.105	Thermostat, Engine	6.410
Stud, Cylinder Head	1.200	Thermostat, Exhaust Manifold Heat Control	5.010
Stud, Deck Lid License Light Mounting .	30.0702	Thrustblock, Rear Axle Shaft	12.020
Stud, Door Glass Division Bar Adjusting	30.202	Thrustblock, Rear Axle Shaft	12.080
Stud, Exhaust Manifold	5.000	Thrustplate, Camshaft	1.500
Stud, Exhaust Manifold to Pipe	5.040	Thrustwasher, Crankshaft	1.310
Stud, Hood Ornament	18.110	Trustwasher, Distributor Drive Shaft . .	7.324
Stud, Ignition Coil	7.346	Thrustwasher, Steering Gear Shaft and Roller	14.116
Stud, Intake Manifold	3.000	Thrustwasher, Rear Axle Differential Side Gear	12.020
Stud, Timing Gear Cover	1.610	Thrustwasher, Rear Axle Differential Side Pinion	12.020
Support, Clutch Pedal Cross Shaft to Transmission	8.155	Thrustwasher, Transmission Countershaft Gear Cluster	9.155
Support, Front Bumper Bar	20.208	Tie Brace, Fender to Fender	18.000
Support, Front Shock Absorber	17.020	Tie Rod, Rear Fender	30.041
Support, Hood Lock Latch Support Plate	18.147	Tie Rod and Ball Stud, Steering	14.216
Support, Muffler to Frame Bracket	5.060	Tie Rod End, Steering	14.216
Support, Oil Pump Float	2.235	Transmission	9.000
Support, Radiator	17.005	Tube, Check Valve to Valve Cover	1.760
Support, Radiator Grille Bar	6.490	Tube, Cylinder Block Water Pump By-Pass	1.100
Support, Radiator Shroud to Cradle	6.480	Tube, Distributor Vacuum Chamber	7.340
Support, Rear Bumper	20.252	Tube, Fresh Air Intake	40.010
		Tube, Front Brake	15.064

ALPHABETICAL INDEX

NAME AND PART DESCRIPTION	GROUP NUMBER	NAME AND PART DESCRIPTION	GROUP NUMBER
Tube, Fuel Pump to Carburetor	3.560	Washer, Exhaust Manifold Heat Control Thermostat	5.010
Tube, Fuel Pump to Intake Manifold . . .	3.560	Washer, Front Seat Back Center Hinge .	30.616
Tube, Fuel Pump to Windshield Wiper. .	30.364	Washer, Front Seat Back Side Hinge . .	30.616
Tube, Fuel Tank Filler.	3.530	Washer, Gear Shift Lower Lever to Cam	9.320
Tube, Fuel Tank to Fuel Pump Line . . .	3.550	Washer, Generator Mounting Bolt.	7.400
Tube, Master Brake Cylinder to Frame Tee.	15.060	Washer, Horn Blowing Cable Terminal .	7.536
Tube, Oil Filler	2.412	Washer, Horn Blowing Contact Terminal	7.527
Tube, Rear Axle Brake.	15.078	Washer, Propeller Shaft Slip Yoke	11.005
Tube, Rear Brake Frame Tee to Rear Hose	15.070	Washer, Rear License Plate Bracket . .	20.115
U		Washer, Steering Gear	14.100
"U" Bolt, Propeller Shaft.	11.000	Washer, Transmission Countershaft Gear Bearing	9.160
"U" Bolt, Rear Spring Mounting Plate .	12.215	Washer, Ventilator Lower Pivot.	30.206
V		Washer, Water Pump	6.300
Valve, Exhaust	1.720	Weathercord, Door Opening.	30.604
Valve, Exhaust Manifold Heat Control. .	5.010	Weatherseal, Door Hinge	30.108
Valve, Heater Shut-Off.	40.002	Weatherseal, Door Inner Panel	30.102
Valve, Intake	1.720	Weatherstrip, Door Division Bar	30.202
Valve, Oil Pump Relief.	2.212	Weatherstrip, Door Glass	30.204
Valve, Windshield Washer Control	40.116	Weatherstrip, Door Glass Lower Channel	30.202
Ventilator Complete, Quarter Panel Window	40.161	Weatherstrip, Door Hinge Pillar	30.102
Ventilator Package, Door Frame and Front Window	40.113	Weatherstrip, Door Opening	30.102
Ventilator Package, Quarter Panel Window	40.161	Weatherstrip, Door Ventilator Frame . .	30.206
Ventshade	40.150	Weatherstrip, Front Door Glass.	30.101
W		Weatherstrip, Quarter Panel Glass. . . .	30.119
Washer, Brake Pedal Floor Plate Screw	15.112	Weatherstrip, Quarter Panel Window Ventilator Frame	40.161
Washer, Camshaft Timing Gear	1.600	Weatherstrip, Rear Deck Lid Opening. .	30.062
Washer, Clutch Pedal Cross Shaft Insulator	8.155	Weatherstrip, Rear Window Glass	30.502
Washer, Clutch Pedal Plate.	8.170	Weatherstrip, Ventilator Division Bar. .	30.206
Washer, Distributor Breaker Contact Arm	7.316	Weatherstrip, Windshield	30.302
Washer, Distributor Breaker Contact Lead	7.316	Well, Rear Floor Pan Tire	30.058
Washer, Distributor Vacuum Chamber Spring	7.338	Wheel, Steering.	14.126
		Wick, Distributor	7.302
		Windbreak, Rear Compartment	30.611
		Windshield Visor End Bracket Package. .	40.115
		Windshield Visor Package.	40.115
		Windshield Washer Package	40.116
		Wing Nut, Air Cleaner	4.000
		Wiring Package, Back-Up Light.	40.108
		Wrench, Wheel Bolt	20.300

ALPHABETICAL INDEX
NOTES

GROUP NUMBER	DESCRIPTION
1.000	Tube, Heat Pump to intake manifold
1.250	Tube, Radiator Filter
1.400	Tube, Heater Brake C. leads to frame
1.412	Tube, Oil Filter
1.413	Tube, Heat Brake Frame To C. Valve
1.414	Washer, Transmission, Cross Shaft
1.415	Washer, Radiator Lower Part
1.416	Washer, Oil Pan
1.417	Washer, Oil Pan
1.418	Washer, Oil Pan
1.419	Washer, Oil Pan
1.420	Washer, Oil Pan
1.421	Washer, Oil Pan
1.422	Washer, Oil Pan
1.423	Washer, Oil Pan
1.424	Washer, Oil Pan
1.425	Washer, Oil Pan
1.426	Washer, Oil Pan
1.427	Washer, Oil Pan
1.428	Washer, Oil Pan
1.429	Washer, Oil Pan
1.430	Washer, Oil Pan
1.431	Washer, Oil Pan
1.432	Washer, Oil Pan
1.433	Washer, Oil Pan
1.434	Washer, Oil Pan
1.435	Washer, Oil Pan
1.436	Washer, Oil Pan
1.437	Washer, Oil Pan
1.438	Washer, Oil Pan
1.439	Washer, Oil Pan
1.440	Washer, Oil Pan
1.441	Washer, Oil Pan
1.442	Washer, Oil Pan
1.443	Washer, Oil Pan
1.444	Washer, Oil Pan
1.445	Washer, Oil Pan
1.446	Washer, Oil Pan
1.447	Washer, Oil Pan
1.448	Washer, Oil Pan
1.449	Washer, Oil Pan
1.450	Washer, Oil Pan



BUILD



OWNER

CONFIDENCE...

WITH

*Factory Approved
and Inspected
Parts and Accessories*